

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Cecotec](#) /

› [Cecotec Cecofry FoodCourt 18000 Air Fryer and Oven Instruction Manual](#)

Cecotec Cecofry FoodCourt 18000

Cecotec Cecofry FoodCourt 18000 Air Fryer and Oven Instruction Manual

Model: Cecofry FoodCourt 18000 (A90_EU01_120299)

1. INTRODUCTION

Thank you for purchasing the Cecotec Cecofry FoodCourt 18000 Air Fryer and Oven. This appliance combines the functionality of an air fryer and a conventional oven, offering versatile cooking options. To ensure safe and optimal performance, please read this instruction manual thoroughly before first use and retain it for future reference.

2. SAFETY INSTRUCTIONS

- Always ensure the appliance is placed on a stable, heat-resistant surface, away from walls and other appliances to allow for proper ventilation.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Keep children and pets away from the appliance during operation. Surfaces become hot.
- Unplug the appliance from the power outlet when not in use and before cleaning. Allow it to cool completely before handling.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way. Contact customer support for assistance.
- Use only accessories recommended by the manufacturer.
- Do not block any ventilation openings.
- Exercise extreme caution when removing hot oil or other hot liquids.
- This appliance is for household use only. Do not use outdoors.

3. PRODUCT OVERVIEW

The Cecofry FoodCourt 18000 is a versatile cooking appliance designed for air frying, baking, roasting, and more. It features a dual-zone cooking system allowing for simultaneous preparation of different dishes.

Components:

- Main Unit (18L total capacity)
- 9L Air Fryer Basket with viewing window
- Removable Divider for air fryer basket
- 12-inch Pizza Stone
- Various racks and trays (specific types may vary)
- Control Panel with Color Screen

Control Panel:

The appliance features an intuitive color screen control panel for easy operation. It allows you to select cooking modes, adjust temperature and time, and utilize the synchronization function.



Image: Digital control panel with touch interface.

4. SETUP

Unpacking:

1. Carefully remove all packaging materials from the appliance and its accessories.
2. Check for any damage during transit. If any damage is observed, do not use the appliance and contact customer support.
3. Remove any stickers or labels from the appliance, except for the rating label.

Placement:

- Place the appliance on a flat, stable, and heat-resistant surface.
- Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance, and 30 cm (12 inches) above, for adequate air circulation.
- Do not place the appliance near flammable materials or heat sources.

Initial Cleaning:

Before first use, clean all removable parts (air fryer basket, divider, pizza stone, racks) with warm soapy water. Wipe the interior and exterior of the main unit with a damp cloth. Dry all parts thoroughly.

First Use (Burn-off):

It is recommended to run the appliance empty for approximately 10-15 minutes at 200°C (390°F) before cooking food for the first time. This helps to burn off any manufacturing residues and odors. Ensure the area is well-ventilated during this process.

5. OPERATING INSTRUCTIONS

General Operation:

1. Plug the appliance into a grounded power outlet. The control panel will illuminate.
2. Select your desired cooking mode (Air Fry, Bake, Roast, Pizza) using the touch controls.
3. Adjust the temperature and cooking time as needed.
4. Press the Start/Pause button to begin cooking.

Air Frying:

The 9-liter air fryer basket is ideal for crispy results with minimal oil. You can use the removable divider to cook two different items simultaneously.

1. Place food in the air fryer basket. Do not overfill.
2. Insert the basket into the designated slot.
3. Select the Air Fry mode, set temperature and time.
4. Monitor cooking progress through the viewing window. Shake or flip food halfway through for even cooking.



Image: Air fryer basket with cooked food.



Image: Air fryer basket with divider, cooking two different items.

Pizza Oven:

The dedicated 12-inch pizza stone ensures authentic, crispy pizza crusts.

1. Preheat the pizza stone inside the oven for at least 10-15 minutes.
2. Carefully place your pizza onto the hot stone using a pizza peel.
3. Select the Pizza mode and set the desired temperature and time.



Image: Air fryer basket and pizza stone accessories.

Simultaneous Cooking:

The 2-in-1 design allows you to cook different dishes at different temperatures and times, or synchronize their finish times.

- Use the separate compartments for air frying and oven functions.
- Utilize the synchronization feature on the control panel to ensure both dishes finish cooking at the same time. Refer to the on-screen prompts for specific instructions.



Image: Appliance cooking two items simultaneously with visible heating elements.

6. CLEANING AND MAINTENANCE

Before Cleaning:

Always unplug the appliance and allow it to cool completely before cleaning any part.

Exterior:

Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the stainless steel finish.

Interior:

Wipe the interior with a damp cloth and mild detergent. For stubborn food residues, a non-abrasive sponge can be used. Ensure the interior is dry before next use.

Accessories:

The air fryer basket, divider, and racks can be washed in warm soapy water or placed in the dishwasher (if dishwasher-safe, check product labeling). The pizza stone should be cleaned by scraping off any excess food and wiping with a damp cloth. Avoid using soap on the pizza stone, as it can be absorbed and affect food taste. Allow the stone to air dry completely.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working grounded outlet. Check the circuit breaker.
Food is not cooking evenly.	Overcrowding; insufficient shaking/flipping.	Do not overcrowd the basket. Shake or flip food halfway through cooking. Ensure proper air circulation.
Food is not crispy.	Too much moisture; insufficient cooking time/temperature.	Pat food dry before cooking. Increase cooking time or temperature slightly. Ensure a thin layer of oil is applied if necessary.
Smoke coming from the appliance.	Grease residue; high-fat food.	Clean the appliance and accessories thoroughly. For high-fat foods, use a drip tray or reduce the amount of oil.
Chicken or large items not browning sufficiently.	Temperature too low for desired browning.	For optimal browning of items like whole chicken, consider increasing the temperature to 230°C for the last 10-15 minutes of cooking, if the recipe allows. Ensure the item is flipped for even browning.

8. SPECIFICATIONS

Feature	Specification
Brand	Cecotec
Model Number	A90_EU01_120299
Total Capacity	18 Liters
Air Fryer Capacity	9 Liters
Pizza Stone Size	12 inches

Feature	Specification
Total Power Output	2700 Watts
Rated Power	1350 Watts
Voltage	240 Volts
Material	Stainless Steel, Ceramic
Color	Black
Product Dimensions (DxWxH)	41.3 x 40.4 x 38.9 cm
Item Weight	10.6 Kilograms
Special Features	2-in-1 Design (Air Fryer and Oven), Simultaneous Cooking, Pizza Stone

9. WARRANTY AND SUPPORT

This Cecotec appliance comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty duration and coverage. For technical support, service, or to inquire about replacement parts, please contact Cecotec customer service. Contact details can typically be found on the official Cecotec website or on your product's packaging. When contacting support, please have your model number (A90_EU01_120299) and purchase date available.