

## PROSTER PSTWT530-US

# PROSTER Clamp Meter PSTWT530-US Instruction Manual

1000A True RMS AC/DC Current Amp Meter with VFC, LOZ Mode, and Inrush Current Measurement

[Overview](#)   [Setup](#)   [Operation](#)   [Safety Information](#)   [Product](#)  
[Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. SAFETY INFORMATION

This PROSTER Clamp Meter is designed and manufactured according to IEC 61010-1, CAT IV 600V, CAT III 1000V safety standards. Adherence to these safety guidelines is crucial for preventing electric shock and damage to the meter.

- **Always** ensure the meter is in the correct measurement function and range before connecting to a circuit.
- **Do not** attempt to measure voltages or currents exceeding the specified maximum limits.
- **Exercise caution** when working with live circuits. Use appropriate personal protective equipment (PPE).
- **Never** measure current on multiple wires simultaneously with the clamp jaw; always isolate a single conductor for accurate and safe measurement.
- **Inspect** test leads and the meter for any damage before each use. Replace damaged components immediately.
- **Do not** operate the meter if it appears damaged or is not functioning correctly.
- **Ensure** the battery compartment is securely closed before operation.

## 2. PRODUCT OVERVIEW

The PROSTER Clamp Meter PSTWT530-US is a True-RMS 6000-count digital clamp meter designed for precise electrical measurements. It features auto-ranging capabilities and a wide array of functions suitable

for automotive, industrial, and home electrical testing.

## Key Features:

- **True-RMS Measurement:** Provides accurate readings for both sinusoidal and non-sinusoidal AC waveforms.
- **Wide Measurement Range:** Measures 1000A AC/DC Current, 1000V DC/AC Voltage, Resistance, Capacitance, Frequency, Temperature, Diodes, Continuity, and Duty-Cycle.
- **Inrush Current Test:** Captures the maximum current at equipment startup, aiding in motor and compressor diagnostics (60-1000A AC).
- **VFC Mode:** Enables accurate measurements on variable frequency drives.
- **LoZ Mode:** Low impedance voltage function to eliminate ghost voltages.
- **NCV Detection:** Non-Contact Voltage detection for identifying live wires safely.
- **Backlit LCD & Flashlight:** Enhances visibility in dimly lit environments.
- **Safety Ratings:** CAT IV 600V, CAT III 1000V with double insulation and overload protection.



Figure 2.1: The PROSTER Clamp Meter displaying its multi-functional capabilities, including continuity, AC/DC voltage, AC/DC current, frequency, duty cycle, resistance, diode, capacitance, peak, temperature, NCV test, and inrush current.

### 3. SETUP

#### 3.1 Battery Installation

1. Locate the battery compartment cover on the back of the meter.
2. Use a screwdriver to loosen the screw securing the cover.
3. Insert three (3) AAA batteries, ensuring correct polarity (+/-).
4. Replace the battery cover and tighten the screw.

#### 3.2 Connecting Test Leads

For voltage, resistance, capacitance, diode, continuity, and temperature measurements, connect the test leads:

- Insert the red test lead into the "VΩHz" input jack.
- Insert the black test lead into the "COM" input jack.




Figure 3.1: The PROSTER Clamp Meter configured for different measurements, including AC Voltage, DC Voltage, Temperature, Resistance, Capacitance, and Firewire Detection, demonstrating proper test lead connection for each function.

## 4. OPERATING INSTRUCTIONS

Turn the rotary dial to select the desired measurement function. Use the 'SELECT' button to toggle between AC/DC or other sub-functions within a dial setting.

### 4.1 AC/DC Current Measurement (Clamp)

1. Turn the rotary dial to the 'A~' (AC Current) or 'A=' (DC Current) position.
2. Press the clamp trigger to open the jaw.
3. Enclose a **single conductor** within the clamp jaw. Ensure the jaw is fully closed.
4. Read the current value on the display.



Figure 4.1: The PROSTER Clamp Meter with its jaw open, illustrating the maximum 42mm opening for current measurement and highlighting the IEC 61010-1, CAT IV 600V, CAT III 1000V safety standards.

### 4.2 AC/DC Voltage Measurement

1. Turn the rotary dial to the 'V~' (AC Voltage) or 'V=' (DC Voltage) position.

2. Connect the red test lead to the positive side of the circuit and the black test lead to the negative/ground.
3. Read the voltage value on the display.

### 4.3 Resistance, Capacitance, Diode, Continuity, Frequency, Duty Cycle

For these functions, turn the rotary dial to the corresponding symbol ( $\Omega$  for Resistance,  $+$  for Capacitance,  $\leftrightarrow$  for Diode/Continuity, Hz/% for Frequency/Duty Cycle). Use the 'SELECT' button to switch between modes if multiple functions share a dial position. Connect test leads to the circuit or component as appropriate.


### 4.4 Temperature Measurement

1. Turn the rotary dial to the '°C/°F' position.
2. Connect the K-type thermocouple to the meter's input jacks (red to V $\Omega$ Hz, black to COM).
3. Place the thermocouple tip on the object or area to be measured.
4. Read the temperature on the display.

### 4.5 Inrush Current Measurement

1. Turn the rotary dial to the 'A~' (AC Current) position.
2. Short press the 'INRUSH' button to activate the inrush measurement mode.
3. Clamp the meter around a single AC conductor of the device to be tested.
4. Activate the device. The meter will capture and display the peak startup current.

# PEAK FUNCTION & INRUSH CURRENT TEST

 **PEAK:** Record the instantaneous peak values in the equipment to ensure stable operation.


 **INRUSH:** Monitor voltage and sudden current fluctuations in the power system to protect equipment from power surge damage.



Figure 4.2: The PROSTER Clamp Meter demonstrating the Peak Function and Inrush Current Test, which records instantaneous peak values and monitors sudden current fluctuations to protect equipment.

## 4.6 VFC & LoZ Mode

- **VFC (Variable Frequency Control):** Select this mode when measuring AC voltage or current on variable frequency drives to ensure accurate readings.
- **LoZ (Low Impedance):** Use this mode for voltage measurements to eliminate false readings caused by ghost voltages.

## VFD FUNCTION

Precisely capture the current waveform driven by the inverter to ensure stable operation of the equipment.



Figure 4.3: The PROSTER Clamp Meter in use, demonstrating its VFD function to precisely capture current waveforms driven by an inverter, ensuring stable equipment operation.

### 4.7 NCV (Non-Contact Voltage) Detection

1. Turn the rotary dial to the 'NCV' position.
2. Move the meter's tip close to the conductor or outlet.
3. The meter will emit an audible beep and/or visual indication if voltage is detected.

# NON-CONTACT VOLTAGE TEST

Safe, Non-contact Voltage Detection With Visual And Audible Alarms



Figure 4.4: The PROSTER Clamp Meter performing a Non-Contact Voltage test near an electrical outlet, indicating voltage detection with visual and audible alarms for safe operation.

## 4.8 Additional Functions

- **Data Hold:** Press the 'HOLD' button to freeze the current reading on the display. Press again to release.
- **Backlight & Flashlight:** Press the backlight button to illuminate the display or activate the built-in flashlight for working in dark areas.
- **Auto Power Off:** The meter will automatically power off after approximately 15 minutes of inactivity to conserve battery life.

# With Backlight display & Flashlight

Measurements can be taken even in dark areas



Figure 4.5: The PROSTER Clamp Meter in a dimly lit electrical panel, demonstrating its backlit display and integrated flashlight for improved visibility during measurements.

## 5. MAINTENANCE

### 5.1 Cleaning

Wipe the meter with a damp cloth and mild detergent. Do not use abrasives or solvents. Ensure the meter is dry before storage or use.

### 5.2 Battery Replacement

When the low battery indicator appears on the display, replace the three (3) AAA batteries as described in Section 3.1. Remove batteries if the meter will not be used for an extended period.

### 5.3 Storage

Store the meter in a cool, dry place, away from direct sunlight and extreme temperatures. Use the provided EVA case for protection.

## 6. TROUBLESHOOTING

- **No display or faint display:** Check battery installation and replace batteries if necessary.
- **Incorrect readings:**
  - Ensure the correct function and range are selected.
  - For current measurements, verify the clamp jaw is fully closed around a single conductor.
  - Check test lead connections for proper insertion and damage.
  - Consider using LoZ mode for voltage measurements to eliminate ghost voltages.
- **Meter does not respond:** Turn the meter off and then on again. If the issue persists, remove and reinsert batteries.

## 7. SPECIFICATIONS

Feature	Specification
DC Voltage (DCV)	600mV/6V/60V/600V/1000V $\pm(0.5\%+5)$
AC Voltage (ACV)	600mV/6V/60V/600V/1000V $\pm(0.5\%+5)$
AC Current (ACA)	60A/600A/1000A $\pm(2.5\%+10)$
DC Current (DCA)	60A/600A/1000A $\pm(2.5\%+10)$
Resistance	600 $\Omega$ /6K $\Omega$ /60K $\Omega$ /600K $\Omega$ /6M $\Omega$ /60M $\Omega$ $\pm(1.0\%+2)$
Capacitance	10nF/100nF/1 $\mu$ F/10 $\mu$ F/100 $\mu$ F/10mF/100mF $\pm(4.0\%+15)$
Frequency	10Hz/100Hz/1kHz/10kHz/100kHz/1MHz/10MHz $\pm(0.5\%+4)$
Temperature	-20°C~1000°C / -4°F~1832°F $\pm(2.0\%+3)$
Duty Cycle	1%-99%
Max Display	6000 Counts
Diode Test	Approx. 2.8V
Continuity Test	Buzzer sounds below 50 $\Omega$ $\pm$ 30 $\Omega$
Low Battery Indicator	Approx. less than 2.4V
Data Hold	Yes
NCV	Yes
Auto Power Off	About 15 minutes

Feature	Specification
True RMS	Yes
Clamp Light	Yes
Backlight Display	Yes
Input Impedance	10MΩ
Sampling Rate	2 times/s
AC Frequency Response	Current 40-1kHz
Operation Method	Auto or manual range
Clamp Opening	42mm
Battery	4.5V (3*AAA battery)
Meter Weight	About 305g (including battery)
Meter Size	236mm × 85mm × 40mm
Safety Standard	IEC 61010-1, CAT IV 600V, CAT III 1000V
Included Components	Clamp Meter, Test Lead, K-Type Thermocouple, 1.5V AAA Batteries, Alligator Clip

## 8. WARRANTY & SUPPORT

### 8.1 Warranty Information

This PROSTER Clamp Meter PSTWT530-US comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper operation.

### 8.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact PROSTER customer support through the retailer's platform or the official PROSTER website. Please have your purchase receipt and product model number (PSTWT530-US) available when contacting support.

### 8.3 Official Product Video

Video 8.1: An official video from PROSTER CA demonstrating the features and operation of a PROSTER Digital Clamp Meter. This video provides a visual guide to understanding the meter's capabilities and usage.

