

[Manuals+](#)

[Q & A](#) | [Deep Search](#) | [Upload](#)

[Manuals.plus](#) /

› [SIMPLUS](#) /

› SIMPLUS Rice Cooker DFBA008GY00-US Instruction Manual

SIMPLUS DFBA008GY00-US

SIMPLUS Rice Cooker Instruction Manual

Model: DFBA008GY00-US

Brand: SIMPLUS

1. PRODUCT OVERVIEW

The SIMPLUS Rice Cooker is designed for efficient and versatile cooking, featuring a large capacity and multiple preset programs. It is suitable for preparing various rice types and other dishes with ease.



Image 1.1: Front view of the SIMPLUS Rice Cooker.

Key Features:

- **6 Preset Multi-Function Cooking:** Offers programs for basic rice, quick cook, porridge, rice reheating, and more.
- **Family Capacity:** 8 cups uncooked / 16-cup cooked capacity, suitable for 2-8 people.
- **Smart Precision Cooking:** 680W power with NTC temperature sensor for precise heat control, ensuring fluffy rice and preventing overflow.
- **Food-Grade Non-Stick Inner Pot:** PFOA/PFOS free for easy cleaning.
- **Intuitive Touch Control:** User-friendly interface with a 24-hour delay timer and keep warm/reheat functions.

2. COMPONENTS AND ACCESSORIES

The SIMPLUS Rice Cooker comes with the following items:

Accessories Included

Keeps your kitchen tidy by storing accessories in the cooker, making space for other tools.



Image 2.1: All included accessories for the rice cooker.

- Non-Stick Inner Pot
- Plastic Steamer
- Serving Spatula
- Measuring Cup
- Power Cord



Image 2.2: Detailed view of the rice cooker components and their placement.

3. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the non-stick inner pot, plastic steamer, serving spatula, and measuring cup with warm, soapy water. Rinse thoroughly and dry.
3. **Placement:** Place the rice cooker on a stable, flat, and heat-resistant surface. Ensure adequate ventilation around the unit.
4. **Connect Power:** Plug the power cord into the rice cooker and then into a suitable electrical outlet.

4. OPERATING INSTRUCTIONS

4.1 Basic Rice Cooking

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice.
2. **Rinse Rice:** Rinse the rice under cold water until the water runs clear.
3. **Add to Pot:** Place the rinsed rice into the non-stick inner pot.
4. **Add Water:** Refer to the water level markings inside the inner pot for the correct rice-to-water ratio. For general white rice, a common ratio is 1 cup of uncooked rice to 1.5-2 cups of water, but adjust based on rice type and desired texture.
5. **Place Pot:** Insert the inner pot into the main unit, ensuring it sits correctly.
6. **Close Lid:** Close the lid securely.
7. **Select Program:** Press the 'Menu' button to cycle through the 6 preset cooking programs (e.g., 'Rice' for basic cooking). The digital display will show the selected program.
8. **Start Cooking:** Press the 'Start/Cancel' button to begin cooking. The display will show the remaining cooking time.
9. **Keep Warm:** Once cooking is complete, the cooker will automatically switch to 'Keep Warm' mode, maintaining the rice's temperature for up to 24 hours.

6 Smart Functions

One-Touch Operation: Easy-to-use interface lets you start cooking instantly, no complicated steps.



Image 4.1: Overview of the 6 smart functions available on the control panel.

4.2 Using the Delay Timer

The 24-hour delay timer allows you to set the cooking to start at a later time.

1. Prepare rice and water as described in Section 4.1.
2. Close the lid.
3. Press the 'Timer' button. Use the '+' and '-' buttons to adjust the desired delay time (up to 24 hours).
4. Press 'Start/Cancel' to confirm the delay timer. The cooker will start automatically after the set delay.

4.3 Steaming Vegetables

The plastic steamer allows you to steam vegetables simultaneously with rice or separately.

1. Prepare rice and water in the inner pot.
2. Place vegetables in the plastic steamer.
3. Carefully place the plastic steamer on top of the inner pot with rice.

4. Close the lid and select the appropriate cooking program (e.g., 'Rice' or 'Steam' if available as a separate program).
5. Press 'Start/Cancel'.



Image 4.2: Example of using the steamer for one-pot meals.

4.4 Official Product Video

Your browser does not support the video tag.

Video 4.1: This video provides a visual demonstration of the SIMPLUS Rice Cooker's features and operation, including its various cooking modes and ease of use.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your rice cooker.

7-Step Automatic for Superior Rice Texture



Image 5.1: Features designed for easy maintenance and mess-free cooking.

1. **Unplug:** Always unplug the rice cooker from the power outlet before cleaning.
2. **Cool Down:** Allow the unit to cool completely before disassembling or cleaning.
3. **Inner Pot:** The non-stick inner pot should be hand washed with warm, soapy water. Avoid abrasive cleaners or scouring pads to prevent damage to the non-stick coating.
4. **Lid and Steam Vent:** The ultra-thin top cover is non-detachable, but the anti-spill valve is detachable for cleaning. Wipe the lid interior and exterior with a damp cloth. Clean the detachable anti-spill valve thoroughly.
5. **Accessories:** The plastic steamer, serving spatula, and measuring cup are also hand wash only.
6. **Exterior:** Wipe the exterior of the rice cooker with a damp cloth. Do not immerse the main unit in water or any other liquid.
7. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling and storing the rice cooker.

6. SPECIFICATIONS

Feature	Detail
Brand	SIMPLUS
Model Name	Rice Cooker
Item Model Number	DFBA008GY00-US
Capacity	4 Liters (8 Cups Uncooked / 16-Cup Cooked)
Product Dimensions	11.22"D x 8.7"W x 9.76"H
Power Source	Corded Electric
Product Care Instructions	Hand Wash
Color	Black
Special Feature	Non-Stick
Material	Metal (Lid Material: Aluminum)
Item Weight	7.04 pounds

