

C900 Pro-Max

Generic C900 Pro-Max Smart Watch

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Generic C900 Pro-Max Smart Watch. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully to ensure proper use and to fully utilize all features of your smartwatch.

What's in the Box

Upon unboxing your C900 Pro-Max Smart Watch, please verify that all components are present:

- C900 Pro-Max Smart Watch
- Watch Band (typically one or more, as per product packaging)
- Wireless Charging Cable
- Instruction Manual (this document)



Image: The C900 Pro-Max Smart Watch displayed with two different watch bands, illustrating the included accessories.

Setup

1. Charging the Smart Watch

Before first use, fully charge your C900 Pro-Max Smart Watch. Connect the wireless charging cable to a USB power adapter (not included) and place the back of the watch onto the charging pad. The watch display will indicate charging status. A full charge takes approximately 2 hours.

2. Powering On/Off

- **To Power On:** Press and hold the side button until the screen lights up.
- **To Power Off:** Press and hold the side button, then select the 'Power Off' option on the screen.

3. Pairing with Your Smartphone

The C900 Pro-Max Smart Watch is compatible with Android smartphones. To pair:

1. Ensure your smartphone's Bluetooth is enabled.
2. Download and install the companion application for your smartwatch from your phone's app store. Refer to the packaging or quick start guide for the app name.
3. Open the app and follow the on-screen instructions to search for and connect to your C900 Pro-Max Smart Watch.
4. Confirm the pairing request on both your phone and the watch.

Operating Instructions

1. Display Navigation

The C900 Pro-Max features a 2.19-inch touchscreen display for intuitive navigation:

- **Swipe Up/Down:** Scroll through menus or notifications.
- **Swipe Left/Right:** Access different widgets or quick settings.
- **Tap:** Select an item or open an application.
- **Side Button:** Press to return to the home screen or wake the display.



Image: The C900 Pro-Max Smart Watch display showcasing its application grid, including icons for various functions like calls, messages, and health tracking.

2. Health Monitoring

Your smartwatch is equipped with sensors to monitor key health metrics:

- **Heart Rate Monitor:** Access the heart rate application to measure your current heart rate. For continuous monitoring, ensure the watch is worn snugly on your wrist.
- **Step Counter:** The built-in pedometer automatically tracks your daily steps, distance, and estimated calories burned. This data is visible on the watch face or within the activity app.



Image: The C900 Pro-Max Smart Watch display showing active tracking data, including steps taken, distance covered in kilometers, and calories burned.

3. Smart Features

The C900 Pro-Max offers a range of smart functionalities:

- **Notifications:** Receive alerts for calls, messages, and app notifications directly on your wrist when paired with your smartphone.
- **Music Control:** Control music playback on your paired smartphone.
- **Remote Camera:** Use your watch as a remote shutter for your phone's camera.
- **Find Phone:** Locate your misplaced smartphone by triggering an alert sound from your watch.



Image: The C900 Pro-Max Smart Watch display showing various feature icons, such as step counter, distance, calories, blood oxygen, sleep monitor, alarm, and more, with descriptions in Spanish.

Maintenance

1. Cleaning

Regularly clean your smartwatch and watch band to prevent skin irritation and maintain device functionality:

- Wipe the screen and watch body with a soft, damp, lint-free cloth.
- For the watch band, use mild soap and water, then rinse thoroughly and dry completely before reattaching to the watch.
- Avoid using harsh chemicals or abrasive materials.

2. Battery Care

To prolong battery life:

- Avoid fully discharging the battery frequently.

- Charge the watch in a cool, dry environment.
- Do not expose the watch to extreme temperatures.

Troubleshooting

If you encounter issues with your C900 Pro-Max Smart Watch, try the following solutions:

- **Watch not powering on:** Ensure the watch is fully charged. Connect it to the wireless charger for at least 30 minutes.
- **Cannot pair with smartphone:**
 - Ensure Bluetooth is enabled on your phone and the watch.
 - Make sure the watch is within range of your phone.
 - Restart both your phone and the watch.
 - Clear Bluetooth cache on your phone (if applicable).
- **Inaccurate health data:** Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensors on the back of the watch.
- **Notifications not appearing:** Check app permissions on your smartphone to ensure the companion app has access to notifications. Verify that notifications are enabled within the watch's settings and the companion app.

If problems persist, consult the companion app's help section or contact customer support.

Specifications

Feature	Specification
Model Name	C900 Pro-Max
Display Size	2.19 Inches
Display Type	OLED
Operating System	Android
Connectivity	Bluetooth
Special Features	Wireless Charging, Heart Rate Monitor, Step Counter
Battery Capacity	100 Milliamp Hours
Charging Time	2 Hours
Compatible Devices	Smartphone
Item Weight	400 g

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer. Keep your proof of purchase for any warranty claims.

