

FUNMILY B0FCYBWG81

FUNMILY Foldable Treadmill User Manual

Model: B0FCYBWG81

1. INTRODUCTION

Thank you for choosing the FUNMILY Foldable Treadmill. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new fitness equipment. Please read this manual thoroughly before initial use and retain it for future reference.

2. SAFETY GUIDELINES

Your safety is paramount. Please observe the following precautions:

- Always attach the safety key clip to your clothing before starting the treadmill. In case of an emergency, the safety key will disengage, stopping the machine.
- Ensure the treadmill is placed on a flat, stable surface with adequate clearance around it.
- Keep children and pets away from the treadmill during operation.
- Do not operate the treadmill if it has a damaged cord or plug, or if it is not working properly.
- Consult a physician before beginning any exercise program.
- Maximum user weight capacity: 265 lbs.

3. PRODUCT FEATURES

The FUNMILY Foldable Treadmill is designed for a comprehensive home workout experience, incorporating advanced technology and user-friendly features:

- **Enhanced System Performance:** Upgraded with additional RAM and storage for smoother operation and improved user experience.
- **10-Inch HD Touchscreen:** Provides an intuitive interface for accessing built-in apps, personalized workout plans, and real-time data.
- **Wi-Fi Connectivity:** Seamlessly connect to online content and fitness applications.
- **3-Level 9% Manual Incline Adjustment:** Simulate varied terrains to enhance training diversity and challenge.
- **3.25 HP Low-Energy Motor:** Offers stable and powerful support with a speed range of 0.5 to 9.0 MPH, quieter operation, and longer lifespan.
- **Professional 7-Layer Shock-Absorbing Running Belt:** Reduces impact on knees and joints for comfortable and natural running.

- **36 Built-in Workout Programs:** Caters to various fitness levels, from beginners to advanced users.
- **Foldable Design:** Saves space and allows for easy storage and movement.

4. SETUP AND ASSEMBLY

The FUNMILY Treadmill requires minimal assembly, primarily involving a few screws to secure components.

4.1. Unpacking and Placement

Carefully remove the treadmill from its packaging. Place the treadmill on a level, solid surface. Ensure there is ample space around the unit for safe operation and access. The product dimensions are approximately 55 inches (D) x 27 inches (W) x 53 inches (H).

4.2. Power Connection

Connect the power cord to a grounded electrical outlet. Ensure the power switch, usually located near the base, is in the 'OFF' position before plugging in.

4.3. Attaching the Safety Key

Locate the red safety key. Attach the clip end to your clothing and insert the magnetic end into the designated slot on the console. The treadmill will not operate without the safety key properly in place.



Image: Safety key properly inserted into the console.

4.4. Folding and Unfolding the Treadmill

The treadmill features a soft automatic drop-down system for easy folding and unfolding, allowing for convenient storage.

BRAND NEW UPGRADE SYSTEM:

Enjoy a Smoother, Lag-Free Experience



Image: Treadmill in its folded position, highlighting its space-saving design.

Your browser does not support the video tag.

Video: Demonstration of the treadmill's folding and unfolding mechanism for easy storage and setup.

5. OPERATION GUIDE

Familiarize yourself with the control panel and various functions to optimize your workout.

5.1. Using the 10-Inch HD Touchscreen

The treadmill is equipped with a 10-inch HD touchscreen that provides access to various functions, including built-in apps, workout programs, and real-time data tracking. Navigate the interface by tapping on the icons.

10-INCH HD TOUCHSCREEN TREADMILL



Image: The 10-inch HD touchscreen displaying various applications and workout modes.



Image: User interacting with the responsive touchscreen interface.

5.2. Speed and Incline Adjustment

Adjust your workout intensity using the speed and incline controls. The treadmill offers a speed range of 0.5 to 9.0 MPH and a 3-level 9% manual incline. Controls are available on the touchscreen and conveniently on the handrails.



Image: Visual representation of speed modes and 9% manual incline adjustment.



Image: Detailed view of the 3-level manual incline adjustment mechanism.

5.3. Workout Programs and Modes

Choose from 36 built-in workout programs or utilize the three countdown modes for varied exercise routines. The treadmill also supports 3D virtual sports scenes for an immersive experience.



Image: Displaying various workout programs, social media integration, and 3D virtual scenes.

5.4. Heart Rate Monitoring

The treadmill features heart rate sensors integrated into the handrails to help you monitor your pulse during your workout.



Image: Heart rate sensors located on the handrails for convenient monitoring.

5.5. Additional Features

The console includes convenient cup holders for your hydration needs during exercise.



Image: Integrated cup holders on the console for user convenience.

6. MAINTENANCE AND CARE

Regular maintenance ensures the longevity and optimal performance of your treadmill.

6.1. Lubrication

The running belt requires periodic lubrication to reduce friction and wear. Use the provided lubricant and follow the instructions below:

1. Turn off and unplug the treadmill.
2. Lift the edge of the running belt.
3. Apply a small amount of lubricant evenly under the belt, towards the center of the deck.
4. Run the treadmill at a low speed for a few minutes to distribute the lubricant.



Image: Step-by-step guide for lubricating the treadmill belt.

6.2. Cleaning

Wipe down the treadmill surfaces with a damp cloth after each use to remove sweat and dust. Avoid using abrasive

cleaners or solvents.

6.3. Belt Adjustment

Periodically check the tension and alignment of the running belt. If the belt slips or drifts to one side, refer to the detailed instructions in the full user manual for adjustment procedures.

7. TROUBLESHOOTING

If you encounter issues with your treadmill, refer to the following common problems and solutions:

- **Treadmill not starting:** Ensure the power cord is securely plugged in, the power switch is on, and the safety key is correctly inserted.
- **Belt slipping:** The running belt may need tensioning. Refer to the belt adjustment section or the full manual.
- **Unusual noises:** Check for loose parts or objects under the belt. Lubrication may also be required.
- **Display not working:** Verify power connection and ensure no cables are loose.

For persistent issues or problems not listed here, please contact customer support.

8. TECHNICAL SPECIFICATIONS

Specification	Value
Brand	FUNMILY
Model	B0FCYBWG81
Color	Black
Product Dimensions	55"D x 27"W x 53"H
Material	Alloy Steel
Maximum Speed	9 Miles per Hour
Maximum Horsepower	3.25 Horsepower
Maximum Incline Percentage	9% (3-level manual)
Maximum Weight Recommendation	265 Pounds
Screen Size	10 Inches
Number of Programs	36
Power Source	Corded Electric
Included Components	Lubricant, Power Cord, Safety Key, Tool Kit, User Manual

9. WARRANTY AND CUSTOMER SUPPORT

The FUNMILY Foldable Treadmill comes with a 3-year warranty and free replacement parts service. This warranty covers manufacturing defects and ensures peace of mind for your purchase.

For any questions, concerns, or to claim warranty service, please contact FUNMILY customer support through the retailer where you purchased the product or visit the official FUNMILY website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question