

- Manuals.plus /
- › WELLENT /
- › WELLENT 11L Dual Basket Air Fryer XXL 2600W Digital Touchscreen Instruction Manual

WELLENT 11L Dual Basket Air Fryer XXL 2600W

WELLENT 11L Dual Basket Air Fryer XXL 2600W Digital
Touchscreen Instruction Manual

Model: 11L Dual Basket Air Fryer XXL 2600W

1. INTRODUCTION

Thank you for choosing the WELLENT 11L Dual Basket Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods, using rapid air circulation to achieve crispy results with significantly less oil. With its dual basket design and advanced features, you can prepare multiple dishes simultaneously, making meal preparation efficient and convenient. Please read this manual thoroughly before use to ensure safe and optimal operation.

Friggitrice ad Aria a Doppio Cestello Nuova Versione

Pronta per i Pranzi di Capodanno & Riunioni Familiari



2600W



Capacità **11L**



2 Zone di Cottura



Image 1: The WELLENT 11L Dual Basket Air Fryer in use, highlighting its capacity and versatility for family meals.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

3. PRODUCT OVERVIEW

The WELLENT 11L Dual Basket Air Fryer features two independent cooking zones, allowing for versatile meal preparation. Its digital touchscreen provides intuitive control over various cooking functions.

Key Components:

- Main Unit with Digital Touchscreen
- Left Basket (4L capacity)
- Right Basket (7L capacity)
- Crisper Plates for each basket



Image 2: Front view of the air fryer, illustrating the dual baskets and digital control panel.



Image 3: Illustration of the 7L and 4L basket capacities.

4. SETUP

1. **Unpack:** Carefully remove the air fryer and all accessories from the packaging.
2. **Clean:** Wash the baskets and crisper plates with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.

3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, ensuring adequate air circulation around the unit (at least 10 cm clearance from walls or other appliances).
4. **Power:** Plug the power cord into a grounded electrical outlet. The appliance is now in standby mode.

5. OPERATING INSTRUCTIONS

The WELLENT Air Fryer offers various cooking modes and preset programs for ease of use.

5.1 Digital Touchscreen Controls

The intuitive digital touchscreen allows you to select cooking modes, adjust time and temperature, and activate special functions.



Image 4: The digital touchscreen displaying the 10 preset cooking programs.

5.2 Cooking Modes

The air fryer supports three main cooking modes:

- **Single Basket Cooking:** Use one basket for smaller portions.
- **Dual Basket Cooking (Independent):** Cook two different dishes with separate time and temperature settings.

- **Dual Basket Cooking (Sync Finish):** Cook two different dishes with different settings, but the air fryer will automatically adjust to finish both at the same time.

5.3 Step-by-Step Operation

1. **Power On:** Press the power button (**U**) to turn on the appliance.
2. **Place Food:** Insert the crisper plate into the basket, then place your food into the basket. Slide the basket back into the air fryer.
3. **Select Basket:** If using only one basket, select basket 1 or 2 on the touchscreen. If using both, you can select each independently or use the DUAL/SYNC functions.
4. **Choose Program/Settings:**
 - **Preset Programs:** Select one of the 10 preset programs (Fries, Steak, Chicken, Fish, Veggies, Bacon, Cookies, Cake, Shrimp, Wings) by tapping the corresponding icon. The default time and temperature will be displayed.
 - **Manual Settings:** Alternatively, manually adjust the temperature (80-200°C) and time (1-60 minutes) using the temperature and time adjustment buttons.
5. **Start Cooking:** Press the Start/Pause button (▶/||) to begin cooking.
6. **Shake Reminder:** For certain programs or longer cooking times, the "SHAKE" icon will illuminate, and the air fryer will beep to remind you to shake or flip the food for even cooking.
7. **Sync Finish Function:** If cooking two different items that need to finish at the same time, set the programs for both baskets. Then, press the "SYNC" button. The air fryer will automatically adjust the cooking times to ensure both baskets complete simultaneously.
8. **Completion:** The air fryer will beep when cooking is complete. Carefully remove the baskets and transfer the food.

Your browser does not support the video tag.

Video 1: Demonstrates the various cooking modes, including single basket, dual basket with same settings, dual basket with different settings, and the Sync Finish function. This video illustrates the flexibility of the WELLENT Dual Basket Air Fryer for diverse cooking needs.

6. COOKING TIPS

- **Preheating:** The WELLENT Air Fryer generally does not require preheating, saving time.
- **Oil Usage:** For best results and crispiness, lightly toss food with a small amount of oil (1-2 tablespoons) before air frying.
- **Even Cooking:** Utilize the "Shake Reminder" feature and manually shake or flip food halfway through cooking for uniform crispiness.
- **360° Air Circulation:** The powerful 2600W dual heating elements and 360° hot air circulation ensure thorough and even cooking, resulting in perfectly crispy food.

Circolazione dell' aria a

Riscaldamento potente 2600W per una
cottura veloce e perfettamente croccante

360°



85% meno olio

80-200°C Controllo della temperatura

50% risparmio di tempo

1-60min Controllo del tempo

Image 5: Visual representation of the 360° air circulation technology.

Promemoria per agitare

Promemoria intelligente per girare, per garantire croccantezza e consistenza uniformi



Image 6: Demonstrating the 'Shake Reminder' feature for optimal cooking results.

7. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and optimal performance of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.

2. **Baskets and Crisper Plates:** The non-stick baskets and crisper plates are dishwasher safe. Alternatively, wash them with warm, soapy water and a non-abrasive sponge. Rinse and dry thoroughly.
3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water or any other liquid.
4. **Heating Element:** Use a soft brush to remove any food residue from the heating element.
5. **Storage:** Store the cleaned and dried air fryer in a cool, dry place.



Facile da pulire
Lavabile in lavastoviglie (Senza PFAS)

Image 7: Air fryer baskets are dishwasher safe for convenient cleaning.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; Power outlet malfunction; Power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the power button.
Food is not cooked evenly.	Baskets overloaded; Food not shaken/flipped; Incorrect temperature/time.	Do not overload baskets. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
White smoke coming from the appliance.	Grease residue from previous use; Fatty food cooking.	Clean the baskets and heating element thoroughly. For fatty foods, add a small amount of water to the bottom of the basket to prevent smoke.
Food is not crispy.	Not enough oil; Temperature too low; Cooking time too short.	Lightly toss food with oil. Increase temperature or cooking time.

9. SPECIFICATIONS

- **Brand:** WELLENT
- **Model:** 11L Dual Basket Air Fryer XXL 2600W
- **Capacity:** 11 Liters (4L + 7L Dual Baskets)
- **Power:** 2600W (Dual Heating Elements: 1150W Left, 1450W Right)
- **Color:** Black
- **Material:** Stainless Steel, Metal
- **Product Dimensions:** 41P x 43I x 31H cm (Depth x Width x Height)
- **Special Features:** Temperature Control, Dual Zone Functionality, Programmable, Automatic Shut-off, Timer, Shake Reminder, Digital Touchscreen

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact WELLENT customer service directly. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FNR5FMG3>

More documents and user manuals: <https://manuals.plus/>