

[Manuals.plus](#) /

› [Emphsism](#) /

› Emphsism 9L Dual Basket Air Fryer Instruction Manual

Emphsism B0FPCSF1M1

Emphsism 9L Dual Basket Air Fryer Instruction Manual

Model: B0FPCSF1M1

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the air fryer on a stable, heat-resistant surface, away from walls and other appliances to allow adequate air circulation.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The appliance features an automatic shutdown protection: when a basket is removed, the air fryer automatically pauses operation. Cooking resumes when the basket is reinserted.
- Integrated overheating protection will cut off power if the temperature exceeds safe limits.
- Before first use, remove all protective plastic films, clean the baskets with detergent, and preheat the air fryer.

Protezione Automatica Dallo Spegnimento

Interrompe automaticamente la cottura quando il cestello viene rimosso



Figure 1: Automatic shutdown protection when a basket is removed.

2. PRODUCT OVERVIEW

The Emphsism 9L Dual Basket Air Fryer is designed for healthy and efficient cooking, utilizing 360° hot air circulation to prepare crispy, low-fat meals without excessive oil. Its dual-zone design allows for simultaneous cooking of different dishes.

Key Features:

- **9L Capacity with Dual 4.5L Baskets:** Cook different foods simultaneously without flavor transfer.
- **Independent Temperature Control:** Each basket can be set with its own temperature (50-200°C) and time (1-60 minutes).
- **8 Preset Programs:** Includes Air Fry, Bake, Roast, Broil, Dehydrate, Reheat, Keep Warm, and Preheat for one-touch cooking.
- **Smart Finish Function:** Synchronizes cooking times for different foods in each basket to finish simultaneously.
- **Match Cook Function:** Easily duplicate settings from one basket to the other for larger batches of the same food.
- **LED Touch Screen:** Intuitive and easy-to-use digital interface.

- **2600W Power:** Ensures rapid heating and efficient cooking.



Figure 2: The Emphism 9L Dual Basket Air Fryer.



Figure 3: Advanced heating technology for efficient and healthy cooking.



Figure 4: Enjoy healthier meals with significantly less oil.

3. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Emphsism
Model	B0FPCSF1M1
Capacity	9 Liters (2 x 4.5 Liters baskets)
Wattage	2600 Watts
Temperature Range	50-200°C
Timer Range	1-60 Minutes
Dimensions (L x W x H)	38.5 x 36 x 32.5 cm
Weight	9.25 Kilograms
Material	Metal

4. GETTING STARTED (SETUP)

1. **Unpacking:** Carefully remove the air fryer and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, clean the baskets and any removable accessories with warm soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 15 cm (6 inches) of clear space around the back and sides of the appliance for proper ventilation.
4. **First Use Preheat:** It is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) during its first use to eliminate any manufacturing odors. A slight smell or smoke is normal during this initial process. Ensure the area is well-ventilated.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview

The Emphsism Air Fryer features an intuitive LED touch screen for easy operation. The control panel allows you to select cooking programs, adjust temperature and time for each basket independently, and utilize special functions.

8 Programmi Di Cottura E Touch Screen

Basta un clic e il cibo delizioso è pronto



Figure 5: LED Touch Screen with 8 Preset Programs.

5.2 Using Preset Programs

The air fryer comes with 8 convenient preset programs for common dishes:

1. Place food into one or both baskets.
2. Press the power button to turn on the appliance.
3. Select the desired basket (1 or 2) by pressing its corresponding button.
4. Press the 'Menu' button repeatedly or swipe through the options on the touch screen to select a preset program (e.g., Air Fry, Roast). The default time and temperature for that program will display.
5. You can adjust the time and temperature using the '+' and '-' buttons if needed.
6. Press the 'Start/Pause' button to begin cooking.

5.3 Dual Zone Cooking (Smart Finish & Match Cook)

The dual basket design allows for versatile cooking. You can cook two different foods at different settings or large quantities of the

same food.

Cucina Due Piatti Contemporaneamente

Rapido ed efficiente, ti fa risparmiare tempo prezioso



Figure 6: Cooking two different dishes simultaneously.

Controllo Indipendente A Doppia Zona

Imposta programmi di cottura diversi in base agli ingredienti



1-60 Min



50-200°C



Figure 7: Independent dual zone control for customized cooking.

Smart Finish Function:

This feature ensures that two different foods, cooked at different settings, finish cooking at the same time.

1. Place food in both baskets.
2. Set the cooking program, temperature, and time for Basket 1.
3. Set the cooking program, temperature, and time for Basket 2.
4. Press the 'SMART FINISH' button. The air fryer will automatically adjust the start times for each basket so they conclude simultaneously.
5. Press 'Start/Pause' to begin.

Match Cook Function:

Use this function to easily apply the same cooking settings to both baskets.

1. Place the same type of food in both baskets.

2. Set the cooking program, temperature, and time for Basket 1.
3. Press the 'MATCH COOK' button. The settings from Basket 1 will be copied to Basket 2.
4. Press 'Start/Pause' to begin.

5.4 Manual Cooking

For full control over your cooking, you can manually set the temperature and time.

1. Place food into one or both baskets.
2. Press the power button.
3. Select the desired basket (1 or 2).
4. Use the temperature '+' and '-' buttons to set the desired temperature (50-200°C).
5. Use the time '+' and '-' buttons to set the desired cooking time (1-60 minutes).
6. Press the 'Start/Pause' button to begin cooking.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your Emphsism Air Fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Baskets and Crisper Plates:** The non-stick baskets and crisper plates are dishwasher safe. Alternatively, wash them with warm soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely before reinserting.
3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scourers, as they can damage the surface. Never immerse the main unit in water or any other liquid.
4. **Interior:** For stubborn food residue inside the cooking chamber, wipe with a damp cloth and a small amount of mild detergent. Ensure the interior is dry before next use.
5. **Heating Element:** Gently clean the heating element with a soft brush to remove any food particles.

Rendi la Pulizia Facile E Semplice



Sciacqua sotto l'acqua corrente



Lava in lavastoviglie

Figure 8: Cleaning the crisper plates by hand or in a dishwasher.

7. TROUBLESHOOTING

If you encounter any issues with your Emphsism Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Air fryer does not turn on	Not plugged in; power outlet malfunction; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push baskets firmly into place until they click.
Food is not cooked evenly	Baskets overloaded; food not shaken/flipped; incorrect temperature/time.	Do not overload baskets. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
White smoke coming from appliance	Greasy food residue; oil/fat dripping onto heating element.	Clean the baskets and crisper plates thoroughly. Ensure excess oil is drained from food before cooking.
Air fryer smells during first use	Normal for new appliances.	Run the air fryer empty for 10-15 minutes at 180°C in a well-ventilated area. The smell will dissipate.

If the problem persists after trying these solutions, please contact customer support.

8. WARRANTY AND SUPPORT

Emphsism products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official Emphsism website. For technical support or service inquiries, please contact Emphsism customer service through the retailer where the product was purchased or via the contact information provided in your product documentation.