



[Manuals.plus](#) /

> [edx](#) /

> [edx Zero Gravity Reclining Chair \(Model Edx-zgc-001\) Instruction Manual](#)

**edx Edx-zgc-001**

# edx Zero Gravity Reclining Chair (Model Edx-zgc-001) Instruction Manual

Your guide to assembly, operation, and maintenance.

## 1. INTRODUCTION

Thank you for choosing the edx Zero Gravity Reclining Chair. This manual provides essential information for the safe and efficient use of your new chair. Please read it thoroughly before assembly and operation, and retain it for future reference.

The edx Zero Gravity Reclining Chair is designed for versatile use, offering comfort for both indoor and outdoor environments. It features a zero-gravity reclining mechanism, a removable cushion for enhanced comfort, and a convenient cup holder. Its foldable design allows for easy storage and transport.



*Image: The edx Zero Gravity Reclining Chair, fully assembled with its cushion, positioned on a wooden deck beside a swimming pool.*

## 2. SAFETY INSTRUCTIONS

- **Weight Capacity:** Do not exceed the maximum weight recommendation of 250 pounds (113 kg). Overloading can cause damage to the chair and potential injury.
- **Stable Surface:** Always place the chair on a flat, stable, and level surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the chair during assembly and when adjusting its position to prevent pinching or injury.
- **Moving Parts:** Be aware of moving parts when folding, unfolding, or reclining the chair. Keep hands and fingers clear of pinch points.
- **Inspection:** Before each use, inspect the chair for any loose parts, damage, or wear. Do not use if any components are compromised.
- **Reclining:** Adjust the reclining position slowly and carefully. Ensure the locking mechanism is engaged before fully relaxing in a reclined position.
- **Outdoor Use:** While suitable for outdoor use, avoid prolonged exposure to extreme weather conditions (heavy rain, strong winds, direct scorching sun) to extend the product's lifespan. Store indoors or cover when not in use.

### 3. PACKAGE CONTENTS

---

Please check the package to ensure all components are present and undamaged:

- edx Zero Gravity Reclining Chair Frame (1 unit)
- Removable Cushion (1 unit)
- Cup Holder Tray (1 unit)

### 4. SETUP

---

#### 4.1 Unfolding the Chair

1. Remove the chair from its packaging.
2. Gently pull the armrests outwards to begin unfolding the chair.
3. Continue to unfold until the chair is fully extended and stable on all four legs. Ensure all joints are securely locked into place.

#### 4.2 Attaching the Cushion

1. Place the removable cushion onto the chair frame.
2. Secure the cushion using any attached ties or straps to prevent it from shifting during use.

#### 4.3 Attaching the Cup Holder

1. Locate the attachment points on the side of the chair's armrest.
2. Slide the cup holder tray onto these points until it clicks securely into place.

Without the Cushion



Breathable  
& Cool



With the Cushion



Extra Soft  
& Warm

*Image: A split image showing the edx Zero Gravity Reclining Chair without its cushion, highlighting its breathable mesh, and with its cushion, emphasizing extra softness and warmth.*

## 5. OPERATING INSTRUCTIONS

### 5.1 Reclining the Chair

1. Sit comfortably in the chair.
2. To recline, gently push back with your feet while leaning back. The chair will smoothly glide into a reclined position.
3. To return to an upright position, gently push forward with your feet and lean forward.

### 5.2 Locking the Reclining Position

1. Once you have found your desired reclining angle (between 90 and 170 degrees), locate the locking levers under the armrests.
2. Push the levers downwards to engage the lock and secure the chair in that position.
3. To unlock, pull the levers upwards.



*Image: A man relaxing in the edx Zero Gravity Reclining Chair on a balcony, demonstrating the chair's adjustable reclining range from 90 to 170 degrees and highlighting the lockable function mechanism.*

### **5.3 Using the Cup Holder**

The attached cup holder provides a convenient place for beverages or small items. Ensure items placed in the cup holder are stable and do not exceed its capacity.

### **5.4 Folding for Storage and Transport**

1. Ensure the chair is in the fully upright position and unlocked.
2. Remove the cup holder and cushion if desired for more compact storage.
3. Gently push the armrests inwards while lifting the seat to initiate the folding action.
4. Continue to fold until the chair is compact. Secure any straps or latches if present to keep it folded.

# TAKE YOUR CHAIRS ANYWHERE



- ✔ Easy folding, convenient for storage & carrying
- ✔ Allowing you to enjoy comfortable reclining chairs anywhere

*Image: A man carrying the edx Zero Gravity Reclining Chair in its folded, compact state across a grassy area with a body of water in the background, illustrating its ease of transport.*

## 6. MAINTENANCE

### 6.1 Cleaning the Chair Frame

Wipe the chair frame with a damp cloth and mild soap. Rinse thoroughly and dry completely to prevent rust or water spots. Avoid abrasive cleaners or harsh chemicals.

### 6.2 Cleaning the Cushion

The cushion requires spot cleaning. Use a clean cloth with a mild detergent and water solution to gently clean soiled areas. Blot dry and allow to air dry completely before reattaching to the chair or storing.

### 6.3 Storage

When not in use, especially during inclement weather or off-season, store the chair in a dry, protected area. Folding the chair will save space. Consider using a protective cover for outdoor storage.

## 7. TROUBLESHOOTING

- **Chair does not recline smoothly:** Check for any obstructions in the reclining mechanism. Ensure the locking levers are fully disengaged. Lubricate moving parts with a silicone-based spray if necessary.
- **Chair feels unstable:** Ensure the chair is fully unfolded and all frame joints are securely locked. Verify it is placed on a flat, level surface. Check for any loose bolts or connections and tighten if needed.
- **Cushion slides off:** Ensure the cushion is properly secured to the chair frame using its ties or straps.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	Zero Gravity Recliner
Model Number	Edx-zgc-001
Brand	edx
Color	Black
Material	Textile (Frame), Foam Padding (Seat)
Frame Material Type	Wood (Note: Product images suggest metal frame, please verify if this is a discrepancy)
Product Dimensions (D x W x H)	32"D x 28"W x 40"H (81.3 cm D x 71.1 cm W x 101.6 cm H)
Item Weight	65 Pounds (29.5 kg)
Maximum Weight Recommendation	250 Pounds (113 kg)
Reclining Position Count	3 (Adjustable between 90-170 degrees)
Indoor Outdoor Usage	Outdoor
Required Assembly	Yes (Minor assembly/unfolding)
Product Care Instructions	Spot Clean



*Image: A detailed diagram illustrating the product dimensions of the edx Zero Gravity Reclining Chair, including its height, width, depth, and folded dimensions, along with a weight capacity of 275 lbs.*

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For product support, inquiries, or to report any issues, please contact the manufacturer or your point of purchase directly.