

[Manuals.plus](#) /

› [TIMEMORE](#) /

› TIMEMORE C5 Hand Coffee Grinder Instruction Manual

## TIMEMORE C5

# TIMEMORE C5 Hand Coffee Grinder Instruction Manual

Model: C5 | Brand: TIMEMORE

## INTRODUCTION

Thank you for choosing the TIMEMORE C5 Hand Coffee Grinder. This manual provides essential information for the safe and effective use of your new coffee grinder. The C5 model features a durable all-metal construction, a 42mm S2C-042-III conical burr for consistent grinding, and precise 0.031mm adjustment capabilities, making it suitable for various brewing methods.



Image: The TIMEMORE C5 Hand Coffee Grinder, showcasing its sleek design.

## SAFETY INFORMATION

---

- Read all instructions before using the grinder.
- Keep the grinder out of reach of children.
- Do not immerse the grinder in water or any other liquid.
- Use only whole roasted coffee beans. Do not grind other substances.
- Avoid touching the burrs when the grinder is assembled or in operation.
- Ensure the handle is securely attached before grinding.

## PACKAGE CONTENTS

---

Please check that all items are present in the package:

- TIMEMORE C5 Hand Coffee Grinder Body
- Grinder Handle
- Cleaning Brush
- Instruction Manual

## SETUP

---

Before first use, ensure all parts are clean and dry. The grinder comes pre-assembled, but you will need to attach the handle.

1. Unpack all components from the box.
2. Insert the handle onto the hexagonal shaft at the top of the grinder.
3. Secure the handle by gently pushing it down until it clicks into place.

# BUILT TO LAST A LIFETIME

All-Metal Constructure  
High-Precision Double Bearings



Image: Internal view of the grinder, highlighting the burr and bearing system.

## OPERATING INSTRUCTIONS

---

Follow these steps to grind your coffee beans:

1. **Adjust Grind Size:** Refer to the "Grind Adjustment" section to select your desired grind size.
2. **Add Coffee Beans:** Remove the lid and pour your desired amount of whole roasted coffee beans into the hopper. The C5 has a capacity of up to 30g.
3. **Attach Handle:** Place the handle back onto the shaft and ensure it is secure.
4. **Grind:** Hold the grinder firmly with one hand and turn the handle clockwise with the other. Continue grinding until all beans have passed through the burrs and into the catch cup.
5. **Collect Grounds:** Unscrew the catch cup from the bottom of the grinder to access your freshly ground coffee.



Image: Adding coffee beans to the grinder.



Image: The grinder in operation, ready for brewing.

## Video: Grinder Usage and Coffee Preparation

Your browser does not support the video tag.

Video: This video demonstrates the process of using the TIMEMORE C5 grinder, from adding beans to grinding and preparing a pour-over coffee.

## GRIND ADJUSTMENT

The TIMEMORE C5 offers precise grind adjustment with 0.031mm clicks. To adjust the grind size:

1. Remove the catch cup from the bottom of the grinder.
2. Locate the adjustment dial at the bottom of the main body, around the central shaft.
3. Turn the dial clockwise for a finer grind and counter-clockwise for a coarser grind. Each click represents a precise adjustment.

4. Refer to the markings (e.g., "FINE", "COARSE", "POUR OVER 10-14") for general guidance.

## Video: Grind Adjustment and Cleaning

Your browser does not support the video tag.

Video: This video illustrates how to adjust the grind size and perform basic cleaning of the TIMEMORE C5 grinder.

## MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your grinder.

- Disassembly:** Unscrew the catch cup. Remove the handle. The internal burr assembly can be carefully disassembled for thorough cleaning.
- Cleaning Burrs:** Use the provided cleaning brush to remove any residual coffee grounds from the burrs and internal components. A soft cloth can be used for external surfaces.
- Do Not Wash:** Do not wash the burrs or main body with water. Water can cause rust and damage the mechanism.
- Reassembly:** Reassemble all parts in reverse order, ensuring the adjustment dial is correctly positioned.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Grinding is difficult or slow.	Burrs are clogged with old coffee oils/grounds. Grind setting is too fine.	Clean the burrs thoroughly. Adjust to a coarser grind setting.
Inconsistent grind size.	Burrs are loose or damaged. Grinder not held steadily.	Ensure burrs are securely tightened. Hold the grinder firmly during operation. If burrs are damaged, contact support.
Handle detaches during grinding.	Handle not properly secured.	Ensure the handle is fully pushed onto the hexagonal shaft until it clicks.

## SPECIFICATIONS

**Brand:** TIMEMORE

**Model:** C5

**Burr Type:** Conical (S2C-042-III)

**Burr Size:** 42mm

**Grind Adjustment:** 0.031mm per click

**Material:** Aluminum alloy

**Capacity:** Up to 30g coffee beans

**Country of Origin:** China

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official TIMEMORE website. Keep your proof of purchase for warranty claims.

