

Tefal IZ5020

Tefal Clean It Portable Carpet & Upholstery Cleaner IZ5020 Instruction Manual

This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your Tefal Clean It IZ5020 portable carpet and upholstery cleaner. Please read thoroughly before first use.

1. IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this appliance.
- Do not immerse the appliance in water or other liquids.
- Always unplug from the electrical outlet when not in use and before cleaning or servicing.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use only cleaning products intended for use with this appliance.
- This appliance is equipped with an automatic shut-off feature to prevent overheating.

2. PRODUCT OVERVIEW

The Tefal Clean It IZ5020 is a portable carpet and upholstery cleaner designed for quick and efficient removal of daily dirt and stains.



Figure 1: Tefal Clean It IZ5020 Portable Carpet & Upholstery Cleaner. This image shows the compact design of the cleaner with its integrated hose, power cord, and handle.

Components:

- Main Unit with integrated motor and pump

- Clean Water Tank (2.3 L capacity)
- Dirty Water Tank (1.5 L capacity)
- Flexible Hose (1.75 m length)
- Power Cable (5 m length)
- Interchangeable Cleaning Heads/Accessories
- Self-Cleaning Accessory

3. SETUP

Follow these steps for initial setup before operating your cleaner:

1. **Unpack the Appliance:** Carefully remove all components from the packaging. Ensure all parts listed in the 'Product Overview' section are present.
2. **Fill the Clean Water Tank:** Remove the clean water tank from the main unit. Fill it with clean water and the recommended amount of carpet/upholstery cleaning solution. Do not overfill beyond the 'MAX' line. Securely reattach the tank to the main unit.
3. **Attach Cleaning Head:** Select the appropriate cleaning head for the surface you intend to clean (e.g., carpet, upholstery). Securely attach it to the end of the flexible hose.
4. **Connect to Power:** Plug the power cable into a suitable electrical outlet (220-240V).



Figure 2: Illustration of filling the clean water tank and emptying the dirty water tank. The image shows a hand filling a clear tank under a faucet and another hand emptying a dark, dirty water tank into a sink.

4. OPERATING INSTRUCTIONS

The Tefal Clean It IZ5020 offers versatile cleaning for various surfaces. Always test the cleaning solution on an inconspicuous area first to ensure colorfastness.

General Cleaning Procedure:

1. **Prepare the Area:** Remove any loose dirt or debris from the surface to be cleaned.
2. **Power On:** Turn on the appliance using the power switch.
3. **Spray Solution:** Hold the cleaning head over the stained area. Press the trigger on the cleaning head to spray the water and detergent solution onto the surface.
4. **Scrub:** Gently scrub the stained area with the brush on the cleaning head.
5. **Extract Dirty Water:** Release the spray trigger and slowly pull the cleaning head over the treated area to extract the dirty solution. Repeat this step until the dirty water being extracted appears clear.
6. **Repeat if Necessary:** For stubborn stains, repeat the spray, scrub, and extract steps.

Special Instructions for Pet Stains:

For pet-related dirt and stains, the cleaner allows for direct spraying onto the affected area for effective removal and a pleasant scent. Follow the general cleaning procedure, ensuring thorough extraction to remove all residue.

Versatile Cleaning:

The interchangeable cleaning heads make the IZ5020 suitable for:

- Carpets and Rugs
- Sofas and Upholstery
- Car Interiors
- Other fabric surfaces

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Tefal Clean It IZ5020.

After Each Use:

1. **Empty and Clean Dirty Water Tank:** Remove the dirty water tank and dispose of the contents. Rinse the tank thoroughly with clean water and allow it to air dry before reattaching.
2. **Rinse Clean Water Tank:** If any solution remains in the clean water tank, empty it and rinse with clean water.
3. **Self-Cleaning the Hose:** Attach the automatic self-cleaning accessory to the hose. Follow the instructions provided with the accessory to rinse the hose and internal components, preventing clogs and odors.
4. **Clean Cleaning Heads:** Remove the cleaning head and rinse it under running water. Remove any trapped debris or hair.
5. **Wipe Down Unit:** Wipe the exterior of the main unit with a damp cloth.

Storage:

Store the appliance in a dry, cool place. Ensure the power cable and hose are neatly wrapped around the designated storage areas on the unit for compact storage.

6. TROUBLESHOOTING

If you encounter issues with your Tefal Clean It IZ5020, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in; Power outlet malfunction; Automatic shut-off activated	Ensure plug is securely in outlet; Test outlet with another appliance; Allow unit to cool down if automatic shut-off engaged.
No spray or weak spray	Clean water tank empty; Tank not seated correctly; Spray nozzle clogged; Pump malfunction	Refill clean water tank; Re-seat tank firmly; Clean spray nozzle; Contact customer support if pump issue suspected.
Poor suction	Dirty water tank full; Tank not seated correctly; Hose or cleaning head clogged; Dirty water tank filter blocked	Empty dirty water tank; Re-seat tank firmly; Clear any clogs from hose/head; Clean dirty water tank filter.
Water leaking	Tanks not seated correctly; Tank seals damaged; Hose connection loose	Ensure tanks are securely in place; Inspect seals for damage and replace if necessary; Check hose connections.

7. SPECIFICATIONS

Brand	Tefal
Model Number	IZ5020
Color	Green
Product Weight	7 Kilograms
Clean Water Tank Capacity	2.3 Liters
Dirty Water Tank Capacity	1.5 Liters
Voltage	220-240 V
Filtration	HEPA Filter
Power Cable Length	5 meters
Hose Length	1.75 meters
Automatic Shut-off	Yes

8. WARRANTY AND SUPPORT

Warranty Information:

This Tefal Clean It IZ5020 appliance comes with a **24-month manufacturer's warranty** from the date of purchase, covering defects in materials and workmanship under normal household use.

15-Year Repairability:

Tefal is committed to making products repairable for 15 years at a reasonable cost. This commitment is part of our effort to

reduce waste and extend the lifespan of our products. Repairs can be carried out at our network of 6,200 authorized repair centers worldwide.

Customer Support:

For further assistance, technical support, or to locate an authorized service center, please refer to the contact information provided on the official Tefal website or your local product documentation.

© 2023 Tefal. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question