

PHILIPS HD1000/00

Philips HD1000/00 XL Sandwich Maker User Manual

Model: HD1000/00

INTRODUCTION

Thank you for choosing the Philips HD1000/00 XL Sandwich Maker. This appliance is designed to provide quick and easy preparation of delicious toasted sandwiches. Please read this user manual carefully before using the appliance and save it for future reference. Proper use and maintenance will ensure optimal performance and longevity of your sandwich maker.

IMPORTANT SAFETY INFORMATION

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PRODUCT OVERVIEW

The Philips HD1000/00 XL Sandwich Maker features a robust design for efficient sandwich preparation. Key components include:

- **XL Sized Plates:** Designed to accommodate larger bread slices, up to 11x11 cm.
- **Non-Stick Coated Plates:** For easy food release and simplified cleaning.
- **Easy Locking Mechanism:** Ensures the sandwich maker remains securely closed during operation.
- **Ready-to-Cook Indicator Light:** Illuminates when the appliance has reached the optimal temperature for cooking.
- **UHD Technology (Uniform Heat Dispersion):** Provides even heat distribution for consistent browning and crisp results.



Image: Overview of the Philips HD1000/00 XL Sandwich Maker highlighting its key features such as XL sized plates, easy locking, indicator light, non-stick coating, easy storage, and UHD technology.



Image: The open sandwich maker demonstrating its XL capacity, suitable for bread slices up to 11x11 cm.



Image: Illustration of the Uniform Heat Dispersion (UHD) Technology, ensuring even cooking and browning across the entire sandwich surface.

SETUP

1. **Unpack:** Carefully remove the sandwich maker and all packaging materials. Retain packaging for potential future transport or storage.
2. **Initial Cleaning:** Before first use, wipe the non-stick cooking plates with a damp cloth or sponge. Dry thoroughly.
3. **Placement:** Place the appliance on a stable, flat, heat-resistant surface, away from water and heat sources. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Ensure the voltage indicated on the appliance matches your local mains voltage before plugging in.

OPERATING INSTRUCTIONS

1. **Preheat:** Close the sandwich maker and plug it into a suitable power outlet. The indicator light will illuminate, signaling that the appliance is heating up.
2. **Ready Indicator:** Once the sandwich maker reaches the optimal cooking temperature, the indicator light will turn off or change color (depending on the model). This indicates it is ready for use.
3. **Prepare Sandwiches:** Lightly butter the outer sides of your bread slices. Place your desired fillings between two slices of bread.
4. **Place Sandwiches:** Open the sandwich maker. Carefully place the prepared sandwiches onto the lower cooking plates. Do not overfill.
5. **Close and Lock:** Gently close the top plate and press down until the easy locking mechanism engages. Do not force it shut if the sandwiches are too thick.
6. **Cook:** Allow the sandwiches to cook for approximately 2-3 minutes, or until golden brown and crisp. Cooking time may vary based on bread type, filling, and desired crispness.
7. **Remove Sandwiches:** Once cooked, carefully open the sandwich maker. Use a heat-resistant plastic or wooden spatula to remove the sandwiches. Avoid using metal utensils, as they can damage the non-stick coating.
8. **Repeat:** If making more sandwiches, close the lid and allow the appliance to reheat briefly until the indicator light signals readiness again.
9. **Finish:** After use, unplug the appliance from the power outlet and allow it to cool completely before cleaning or storing.



Image: Perfectly toasted golden brown sandwiches, achievable in approximately 3 minutes with the Philips HD1000/00.

CLEANING AND MAINTENANCE

Regular cleaning and maintenance will help prolong the life of your Philips HD1000/00 XL Sandwich Maker.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Cooking Plates:** Wipe the non-stick cooking plates with a soft, damp cloth or sponge. For stubborn food residue, dampen a cloth with a small amount of cooking oil and wipe the plates, then wipe clean with a damp cloth. Do not use abrasive cleaners, scouring pads, or metal utensils, as these can damage the non-stick coating.
3. **Clean Exterior:** Wipe the exterior of the appliance with a soft, damp cloth. Do not immerse the appliance in water or any other liquid.
4. **Storage:** Once clean and dry, the sandwich maker can be stored in a cool, dry place. Its compact design allows for convenient vertical storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not heat up.	Not plugged in or power outlet is faulty.	Ensure the appliance is securely plugged into a working power outlet. Check the circuit breaker.
Sandwiches are not golden brown or crisp.	Insufficient cooking time or appliance not fully preheated.	Allow the appliance to preheat fully until the indicator light signals readiness. Increase cooking time slightly. Ensure bread is lightly buttered.
Sandwiches stick to the plates.	Plates not properly cleaned or not buttered.	Ensure plates are clean before use. Lightly butter the outer sides of the bread slices.
Lid does not close properly.	Sandwich is overfilled.	Reduce the amount of filling in the sandwich. Do not force the lid shut.

SPECIFICATIONS

- **Model:** HD1000/00
- **Power:** 800 Watts
- **Voltage:** 230 Volts
- **Material:** Plastic (body), Non-Stick Coated (plates)
- **Color:** Black with Metallic Finish
- **Product Dimensions (D x W x H):** 14.5 x 28.6 x 30 Centimeters
- **Item Weight:** 1.6 Kilograms
- **Special Features:** Non-Stick Coating, UHD Technology, Easy Locking Mechanism, Ready-to-Cook Indicator
- **Included Components:** Sandwich Maker, User Manual

WARRANTY AND SUPPORT

This Philips HD1000/00 XL Sandwich Maker comes with a **2-year manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Versuni India home solutions Ltd., the manufacturer, or visit the official Philips support website for your region. Contact details can typically be found on the product packaging or the official Philips website.