

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [AUTUCU](#) /

> [AUTUCU N21NA Pro 10-Quart 8-in-1 Programmable Multi-Cooker Instruction Manual](#)

## AUTUCU N21NA Pro

# AUTUCU N21NA Pro 10-Quart 8-in-1 Programmable Multi-Cooker Instruction Manual

Model: N21NA Pro | Brand: AUTUCU

## INTRODUCTION

Thank you for choosing the AUTUCU N21NA Pro 10-Quart 8-in-1 Programmable Multi-Cooker. This appliance is designed to simplify your cooking experience with its versatile functions and user-friendly features. Please read this manual thoroughly before use to ensure safe and optimal operation.

### Key Features:

- **10-Quart Capacity:** Ideal for large families and gatherings, accommodating 8–10 servings.
- **Exclusive Ready-by Function:** Program the exact time your meal should be ready, and the cooker automatically calculates the start time.
- **8 Cooking Functions:** Multi-cooker, slow cooker, steamer, grill, sauté pan, warmer, baker, and oven-safe pot.
- **Safe & Nonstick:** PFOA-free ceramic coating on both the pot and grill pan.
- **Included Accessories:** Steaming plate, silicone spoon, and tongs.

## SETUP AND FIRST USE

Before using your AUTUCU N21NA Pro Multi-Cooker for the first time, please follow these steps:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean Components:** Wash the cooking pot, grill pan, steaming plate, lid, silicone spoon, and tongs with warm, soapy water. Rinse thoroughly and dry completely. The cooking pot and grill pan are dishwasher safe.
3. **Placement:** Place the main unit on a stable, flat, heat-resistant surface away from walls and other appliances to ensure proper ventilation.
4. **Power Connection:** Ensure the appliance is unplugged before placing the cooking pot or grill pan into the base. Connect the power cord to a grounded electrical outlet.



Figure 1: AUTUCU N21NA Pro Multi-Cooker with included grill pan, steaming plate, silicone spoon, and tongs.

## OPERATING INSTRUCTIONS

The AUTUCU N21NA Pro offers 8 versatile cooking functions. Use the control panel to select your desired function, time, and temperature.

### Control Panel Overview:

# Quick Tips for AUTUCU N21NA Pro



## The Ready-by function

Unlike a standard countdown timer, this function lets you program the exact time you want your meal to be ready.

### Functions:

Turn on the appliance, choose a function, set "Heat" and "Time", then press "Start"

### Ready-by:

Choose a function, press "Ready-by", set the finish time, then press "Start"

(Example: If a dish requires 2 hours of cooking and you set "Ready-by" for 3 hours, the appliance will start in 1 hour and finish in 3 hours total.)

### Notes:

Quick Steam: Always use the steaming plate and add water up to the "Quick Steam" line.

Pan Grill: Place the grill pan directly on the heating base.

Figure 2: Detailed view of the control panel, highlighting the 'Ready-by' function and other settings.

## Ready-by Function:

This exclusive feature allows you to set the exact time you want your meal to be ready. The cooker will automatically calculate when to start cooking based on the set finish time and the recipe's duration.

- Select a cooking function (e.g., Slow Cook).
- Press the "Ready-by" button.
- Set your desired finish time using the Time dial.
- Press "Start/Stop" to begin.

*Example: For a 2-hour recipe with a 3-hour Ready-by time, the cooker will start after 1 hour and finish precisely on time.*

## Slow Cook Function:

Perfect for tenderizing meats and simmering stews over extended periods.

- Place ingredients in the cooking pot.
- Select "Slow Cook" mode.
- Adjust time and heat settings (Low/High) as per your recipe.

- Press "Start/Stop".

# 8 Heat Modes

Slow Cook | Get Tender Beef in 4 Hours



## 10 QUART

Banquets & Gatherings:  
Stress-Free with AUTUCU



## COOK THE WHOLE CHICKEN

No Need to Cut the Chicken  
into Small Pieces



## TIPS

Low Setting: Chicken tender in 2 hours;  
beef soft and flavorful in 4–5 hours.  
High Setting: Cooks faster than Low for  
quicker meals.

Figure 3: Slow cooking a whole chicken with vegetables in the 10-quart pot.

### Quick Steam Function:

Use the included steaming plate for healthy steamed dishes.

- Add water to the "Quick Steam" line in the cooking pot.
- Place the steaming plate with food inside.
- Select "Quick Steam" mode.
- Adjust time and press "Start/Stop".

# The N21NA Pro All-in-One Multi-Cooker

Also Functions As a Steamer



Figure 4: Steaming various foods using the steaming plate accessory.

## Pan Grill Function:

Achieve perfect grilling results indoors with the dedicated grill pan.

- Place the grill pan directly on the heating base.
- Select "Pan Grill" mode.
- Adjust temperature and time.
- Press "Start/Stop".

# Just Bring the Friends

Master Grilling at Home with the N21NA Pro



Figure 5: Using the grill pan for various grilled dishes.

## Official Product Video:

Video 1: An overview of the AUTUCU 10 QT Multicooker, demonstrating its grill pan and steam rack features.

## MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your Multi-Cooker.

- **Always unplug** the appliance and allow it to cool completely before cleaning.
- **Cooking Pot & Grill Pan:** Both are PFOA-free ceramic coated and dishwasher safe. For best results and to preserve the non-stick coating, hand washing with warm, soapy water and a soft sponge is recommended.
- **Lid:** The glass lid is dishwasher safe.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.

# Easy to Clean Dishwasher Safe Pot Body



Figure 6: The cooking pot is dishwasher safe for easy cleaning.

# Nonstick PFOA-Free Cookware

Cook with Ease Clean in Seconds



Figure 7: The non-stick surface of the grill pan allows for quick and easy hand washing.

## TROUBLESHOOTING

If you encounter any issues with your AUTUCU N21NA Pro Multi-Cooker, please refer to the following common solutions:

- **Appliance not turning on:** Ensure the power cord is securely plugged into both the appliance and a working electrical outlet. Check your home's circuit breaker.
- **Food not cooking evenly:** Ensure ingredients are distributed evenly in the pot or pan. For slow cooking, ensure adequate liquid is present.
- **Food cooking too fast/slow:** Adjust the temperature and time settings according to your recipe and desired results. Note that some recipes may require slight adjustments based on ingredient density and quantity.
- **Non-stick coating issues:** Avoid using metal utensils that can scratch the coating. Use only silicone, wooden, or plastic utensils.

For further assistance, please contact AUTUCU customer support.

## SPECIFICATIONS

---

Feature	Detail
Brand	AUTUCU
Model Number	N21NA Pro
Capacity	10.2 Quarts
Product Dimensions	11.3"D x 19.6"W x 10.4"H
Item Weight	17.76 pounds
Wattage	1600 watts
Voltage	120 Volts
Material	PFOA-Free Ceramic Coated (Food-Contact Surfaces)
Control Method	Touch
Dishwasher Safe	Yes (Pot and Grill Pan)

## WARRANTY AND SUPPORT

---

The AUTUCU N21NA Pro Multi-Cooker comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For product support, troubleshooting, or warranty claims, please visit the official AUTUCU website or contact their customer service department.