

[manuals.plus](#) /

› [BOSGAME](#) /

› [BOSGAME E5 Mini PC User Manual - Ryzen 3 5300U, 16GB RAM, 1TB SSD](#)

## BOSGAME E5

# BOSGAME E5 Mini PC User Manual

**MODEL: E5**

**Brand: BOSGAME**

## 1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your BOSGAME E5 Multi-Functional Mini PC. The BOSGAME E5 is equipped with a Ryzen 3 5300U 4-core 8-thread processor, 16GB DDR4 RAM, and a 1TB PCIe 3.0x4 SSD, offering robust performance for various tasks. It supports triple display output via HDMI, DisplayPort, and USB-C, and features Wi-Fi 5 and Bluetooth 5.0 connectivity.



*Image 1.1: The BOSGAME E5 Mini PC, a compact and powerful desktop computer.*

## 2. WHAT'S IN THE Box

Verify that all items are present in the package before proceeding with the setup.

- BOSGAME E5 Mini PC x1
- User Manual x1
- HDMI 2.0 Cable x1
- 19V 3.42A Power Adapter x1
- VESA Mount & Screws x1

# DUAL 2.5G RJ45 LAN

Equipped with RTL8125-powered dual 2.5G RJ45 ports,  
It ensures hardware-accelerated,  
Driver-optimized networking for seamless software router integration.



Network  
Reliability



Enhanced  
Performance



Bandwidth  
Aggregation



Load  
Balancing

*Image 2.1: Contents of the BOSGAME E5 Mini PC package, including the device, cables, power adapter, and VESA mount.*

## 3. SETUP INSTRUCTIONS

### 3.1 Connecting Peripherals

- 1. Connect Display:** Use the provided HDMI 2.0 cable to connect your monitor to the HDMI port on the Mini PC. Alternatively, use a DisplayPort or USB-C cable for compatible displays. The Mini PC supports up to three

displays simultaneously at 4K@60Hz.

2. **Connect Keyboard and Mouse:** Plug your USB keyboard and mouse into the available USB 3.2 Type-A ports on the front or rear of the Mini PC.
3. **Connect Network (Optional):** For a wired internet connection, connect an Ethernet cable from your router to one of the 1000Mbps RJ45 LAN ports on the rear. For wireless connectivity, the device supports Wi-Fi 5.
4. **Connect Power:** Plug the 19V 3.42A power adapter into the DC-in port on the rear of the Mini PC, then plug the adapter into a power outlet.

## 3.2 First Boot and Operating System Setup

5. **Power On:** Press the power button located on the front of the Mini PC. The power indicator light will illuminate.
6. **Initial Setup:** Follow the on-screen instructions to complete the Windows 11 Pro operating system setup. This includes selecting your language, region, and creating a user account.
7. **Network Configuration:** During the OS setup, you will be prompted to connect to a network. If using Wi-Fi, select your network and enter the password. If using a wired connection, it should connect automatically.

# RYZEN 3 5300U PROCESSOR

**4C 8T**


4MB L3 Cache

**3.8 GHz**

Max. Boost Clock

**15-35W**

Default 35W TDP



## Cinebench R23 ( Multi-Core ) date



\*This data is based on test results obtained in a laboratory environment.  
Actual data may vary depending on actual usage conditions.

*Image 3.1: Overview of the BOSGAME E5 Mini PC's front and rear ports, highlighting various connectivity options.*

## 4. OPERATING INSTRUCTIONS

### 4.1 Power On/Off

- Power On:** Press the power button on the front panel.
- Shut Down:** In Windows, click the Start button, then Power, and select 'Shut down'.
- Restart:** In Windows, click the Start button, then Power, and select 'Restart'.

## 4.2 Display Configuration

The BOSGAME E5 supports up to three independent displays at 4K@60Hz. Connect your monitors using the HDMI 2.0, DisplayPort, and USB-C outputs. Once connected, Windows will automatically detect the displays. You can configure display settings (resolution, orientation, extended/duplicated desktop) via the Windows Display Settings.



## CONNECTIVITY FOR ALL NEEDS



4K monitor



Printer



surveillance camera



NAS



HD TV



Game controller



Projector



Speakers

*Image 4.1: Illustration of the BOSGAME E5 Mini PC supporting a triple display setup for enhanced productivity.*

## 4.3 Network and Wireless Connectivity

- **Wired LAN:** Utilize the dual 1000Mbps RJ45 LAN ports for high-speed, stable wired network connections.

- **Wi-Fi 5:** Connect to wireless networks using the integrated Wi-Fi 5 module. Access Wi-Fi settings through the Windows taskbar network icon.
- **Bluetooth 5.0:** Pair Bluetooth-enabled devices such as keyboards, mice, headphones, or speakers via the integrated Bluetooth 5.0. Manage Bluetooth devices in Windows Settings.



Image 4.2: Visual representation of the BOSGAME E5 Mini PC's wireless capabilities, including Wi-Fi 5 and Bluetooth 5.0 for various peripherals.

## 5. MAINTENANCE

## 5.1 Memory and Storage Upgrade

The BOSGAME E5 comes with 16GB DDR4 RAM and a 1TB M.2 2280 PCIe SSD. The storage is expandable up to 4TB. For detailed instructions on upgrading RAM or SSD, please refer to the official BOSGAME support resources or consult a qualified technician.



Image 5.1: Illustration of the internal memory (DDR4) and M.2 NVMe PCIe SSD components of the BOSGAME E5 Mini PC.

## 5.2 Internal Structure Overview

Understanding the internal layout can assist with maintenance and upgrades. The Mini PC features a plastic base, SSD heatsink, SYS Fan, SO-DIMM DDR4 3200MHz slots, motherboard, CPU, heat conducting phase change material, M.2 2280 NVMe PCIe3.0 slot, heat sink with double heatpipe and single air vent, CPU Smart Fan, and a plastic body.




Image 5.2: Exploded view diagram illustrating the internal components and structure of the BOSGAME E5 Mini PC.

## 6. TROUBLESHOOTING

- **No Display:** Ensure the monitor is powered on and correctly connected to the Mini PC via HDMI, DisplayPort, or USB-C. Try a different cable or display port.
- **No Power:** Verify the power adapter is securely connected to both the Mini PC and a working power outlet. Check if the power indicator light is on.
- **No Internet Connection:** For wired connections, check the Ethernet cable and router status. For Wi-Fi, ensure the correct network is selected and the password is entered accurately. Restart the Mini PC and your router.
- **Slow Performance:** Close unnecessary applications. Check for background updates. Ensure sufficient free storage space.
- **Peripheral Not Detected:** Try connecting the peripheral to a different USB port. Ensure drivers are up to date.


## 7. SPECIFICATIONS

Feature	Detail
Processor	AMD Ryzen 3 5300U (4-core, 8-thread, up to 3.8GHz)
Graphics	Radeon Graphics (Max Graphics Frequency 1500MHz)
RAM	16GB DDR4
Storage	1TB M.2 2280 PCIe 3.0x4 SSD (Expandable up to 4TB)
Display Output	1x HDMI 2.0, 1x DisplayPort, 1x USB-C (Triple Display 4K@60Hz)
USB Ports	3x USB 3.2 Type-A, 1x USB 2.0 Type-A, 1x USB-C
Network	2x 1000Mbps RJ45 LAN, Wi-Fi 5
Bluetooth	Bluetooth 5.0
Audio	3.5mm Combo Jack (CTIA specifications)
Operating System	Windows 11 Pro
Dimensions	6.54 x 6.38 x 4.21 inches (Package)
Weight	2.42 pounds

## 8. WARRANTY AND SUPPORT

BOSGAME provides free and reliable lifetime after-sales service for the E5 Mini PC. All products hold FCC, ROHS, and CE certifications. Additionally, a 1-year professional factory support and 24/7 online customer service are available to assist with any inquiries or issues.

For further assistance, please visit the official BOSGAME website or contact customer support directly.

	<p><b><a href="#">BOSGAME MGI i5 12500H PRO Product and Safety Information</a></b></p> <p>Comprehensive product and safety information for the BOSGAME MGI i5 12500H PRO mini PC, including setup, connectivity, safety guidelines, and FCC compliance details.</p>
	<p><b><a href="#">BOSGAME H66/H68/H77 Mini PC User Manual and Technical Specifications</a></b></p> <p>Official user manual for BOSGAME H66, H68, and H77 mini PCs, detailing technical specifications, safety precautions, connection steps, warranty, and FCC compliance.</p>
	<p><b><a href="#">Bosgame EffiZen Series C1 Mini PC Instruction Manual</a></b></p> <p>Comprehensive instruction manual for the Bosgame EffiZen Series C1 Mini PC, covering setup, usage, maintenance, and support.</p>
	<p><b><a href="#">Bosgame EffiZen Series AS1 Mini PC Instruction Manual</a></b></p> <p>Official instruction manual for the Bosgame EffiZen Series AS1 Mini PC, detailing setup, hardware installation (SSD, RAM), VESA mounting, usage guidelines, and support resources.</p>
	<p><b><a href="#">EffiZen Series P2 Mini PC Instruction Manual - Bosgame</a></b></p> <p>Official instruction manual for the Bosgame EffiZen Series P2 Mini PC. Learn about setup, usage, maintenance, compliance, and warranty information.</p>
	<p><b><a href="#">BOSGAME PTX20 Mini PC Technical Specifications and Overview</a></b></p> <p>Detailed technical specifications, dimensions, and operational notes for the BOSGAME PTX20 Mini PC manufactured by Shenzhen Weikesen Electronic Technology Co., Ltd.</p>