

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NARVI](#) /

› [NARVI 8L 2200W Digital Air Fryer NF19 User Manual](#)

## NARVI NF19

# NARVI 8L 2200W Digital Air Fryer NF19 User Manual

Model: NF19 | Brand: NARVI

## IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, injury, or property damage.

- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children should not play with this appliance.
- Keep the appliance and its cord out of reach of children under 8 years old.
- If the power cord or product is damaged, it must be replaced by a special power cord or assembly from the manufacturer or professionals.
- Household use only.
- To protect against electric shock, do not immerse cord, plugs, or main unit in water or other liquid.
- Unplug from outlet when not in use and before cleaning. Allow it to cool before putting on or taking off parts.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not place the appliance on or near a hot gas or electric burner.
- Extreme caution must be taken when moving an appliance containing hot oil or other hot liquids.
- The appliances are not intended to be operated by means of an external timer.
- Caution! Hot surfaces.
- During use, do not cover the ventilation openings with cloth etc. to avoid accidents or product damage.
- During use, do not touch the internal parts of the appliance.
- Do not use this appliance if the plug, power cord or other parts are damaged in any way.
- Do not plug or unplug the appliance or operate the control panel with wet hands.
- Do not place the appliance against a wall or on top of other devices. Leave at least 20 cm of free space on the back, above and sides of the appliance.
- Do not place anything on top of the appliance.
- Do not leave the appliance running unattended.
- Be careful of hot steam and hot air when removing the frying pot from the appliance.
- If dark smoke is coming from the appliance, unplug it immediately. Wait for the smoke to stop before removing the pot from the appliance.

## PRODUCT OVERVIEW

The NARVI 8L 2200W Digital Air Fryer NF19 is designed for healthier cooking with its 360° hot air circulation technology. It features a sleek black and stainless steel design, a digital touch panel, and a visible window to monitor your food.

## Key Components

- Main Unit:** Houses the heating elements and control panel.
- Removable Basket:** Non-stick coated, suitable for various foods.
- Grill Rack:** For optimal air circulation within the basket.
- Digital Touch Panel:** Intuitive interface for settings and pre-programmed menus.
- Visible Window:** Allows monitoring of cooking progress without opening the basket.



Image: The NARVI 8L 2200W Digital Air Fryer NF19, showcasing its sleek design and digital display.

# USO SENCILLO PANEL DIGITAL TÁCTIL



## 10 MENÚS

Image: Close-up of the intuitive digital touch panel, highlighting the 10 automatic menu options.

# VENTANA VISIBLE



## RÁPIDO Y DELICIOSO

Image: The air fryer featuring its transparent visible window, allowing users to check food without interrupting the cooking process.

# DESMONTABLE



## FÁCIL LIMPIEZA MANTENIMIENTO

Image: The removable air fryer basket, designed for easy cleaning and maintenance.

## SETUP AND FIRST USE

Before using your NARVI Air Fryer for the first time, please follow these steps:

- Unboxing:** Carefully remove the air fryer from its packaging. Ensure all components, including the main unit, removable basket, and grill rack, are present and undamaged.
- Initial Cleaning:** Wash the removable basket and grill rack with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
- Placement:** Place the air fryer on a stable, heat-resistant surface, ensuring there is at least 20 cm of clear space around the back, sides, and top for proper ventilation.
- Power Connection:** Plug the appliance into a grounded electrical outlet.
- First Run (Optional):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) to eliminate any manufacturing odors. A slight smell may be present, which is normal.

## OPERATING INSTRUCTIONS

### Digital Control Panel

The air fryer features an intuitive digital touch panel for easy operation. You can select from 10 automatic menus or manually adjust the temperature and time.

- Power Button:** Press to turn the appliance on or off.
- Temperature Control:** Use the '+' and '-' buttons to adjust the cooking temperature from 80°C to 200°C.
- Timer Control:** Use the '+' and '-' buttons to set the cooking time up to 60 minutes.
- Menu Button:** Cycle through the 10 pre-programmed cooking functions for common foods like fries, chicken, meat, fish, and vegetables.
- Light Button:** Activates the interior light to illuminate the cooking chamber, allowing you to view food through the visible window.

### Dual Heating Technology

The NARVI Air Fryer utilizes a unique dual heating element system, with heating coils both above and below the food. This, combined with 360° hot air circulation, ensures even cooking, crispy results, and reduced cooking time compared to traditional air fryers with only one heating element.

Video: Demonstration of the Aigostar air fryer's dual heating elements, illustrating how heat is distributed for even cooking. This feature is similar to the NARVI air fryer's dual grill technology.

Video: An overview of the Taylor Swoden air fryer, highlighting its digital controls and dual heating capability, which provides faster and more uniform cooking results.

## COOKING GUIDE

Achieve perfect results with your air fryer by following these general guidelines:

- Preheating:** For best results, preheat the air fryer for 3-5 minutes before adding food.
- Food Preparation:** Ensure food is dry before cooking for crispier results. Lightly brush with oil if desired, especially for fresh vegetables or meats.
- Do Not Overfill:** Avoid overcrowding the basket to allow hot air to circulate freely, ensuring even cooking. Cook in batches if necessary.
- Shaking/Flipping:** For many foods, especially fries or smaller items, shaking the basket halfway through the cooking process is recommended. For larger items, flipping them ensures even browning.

- **Monitoring:** Utilize the visible window and interior light to check on your food's progress without opening the basket and losing heat.
- **Adjusting Settings:** Feel free to adjust the temperature and time based on your personal preferences and the specific food item.



Image: A variety of chicken and vegetables cooked to perfection inside the air fryer basket.

## Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Cleaning the Basket and Grill Rack:** The removable basket and grill rack are non-stick coated and are dishwasher safe. Alternatively, wash them with warm, soapy water and a non-abrasive sponge. Rinse and dry thoroughly.
3. **Cleaning the Interior:** The interior chamber is made of stainless steel, which is easy to clean. Wipe it with a damp cloth and mild detergent. For stubborn residue, use a soft brush. Avoid abrasive cleaners or metal scouring pads.
4. **Cleaning the Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use harsh chemicals or abrasive materials.

5. **Storage:** Store the cleaned and dried air fryer in a cool, dry place.

**Libre BPA/  
PFOA**

**Apta para  
lavavajillas**



Image: The air fryer basket is designed to be BPA/PFOA free and is safe for dishwasher cleaning.



Image: A view of the air fryer's stainless steel interior, highlighting its durable and easy-to-clean surface.

## TROUBLESHOOTING

If you encounter any issues with your air fryer, refer to the following common problems and solutions:

- Appliance does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check if the main unit is properly assembled and the basket is fully inserted.
- Food is not cooked evenly:** Do not overfill the basket. Shake or flip food items halfway through cooking. Ensure the grill rack is correctly positioned.
- Food is not crispy:** Ensure food is dry before cooking. Lightly brush with oil if necessary. Increase cooking time or temperature slightly.
- White smoke coming from the appliance:** This may be caused by fatty ingredients or oil residue. Clean the basket and interior thoroughly. If dark smoke appears, unplug immediately.
- Appliance emits unusual odors:** A new appliance may emit a slight odor during initial use. Ensure proper ventilation. If odors persist, clean the unit thoroughly.

For issues not listed here, please contact customer support.

## SPECIFICATIONS

Feature	Specification
Brand	NARVI
Model Name	Narvi NF19
Capacity	8 Liters
Power	2200 Watts
Color	Black and Steel
Material	Stainless Steel
Temperature Range	80°C to 200°C
Timer	Up to 60 minutes
Dimensions	32.6 x 32.5 x 30 cm
Weight	5.2 kg

## WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in the packaging for specific terms and conditions. For technical support, spare parts, or any inquiries, please contact NARVI customer service through their official website or the contact information provided in your purchase documentation.