

Acezoe P11ProG

Acezoe P11 Pro Walking Pad Treadmill

INSTRUCTION MANUAL

Important Safety Instructions

Please read all instructions carefully before using this walking pad treadmill. Retain this manual for future reference.

- Ensure the treadmill is placed on a flat, stable surface.
- Keep children and pets away from the treadmill during operation.
- Always wear appropriate athletic footwear.
- Do not operate the treadmill if it is damaged or malfunctioning.
- Disconnect power before cleaning or maintenance.
- Maximum user weight capacity is 300 lbs (136 kg).
- Use the safety key at all times during operation.

Product Overview

Key Features

- **Adjustable Handlebar:** 5 height levels (38.5"–48.5") for varied user heights and comfort.
- **Adjustable Incline:** 3 manual levels (1%, 6%, 12%) for diverse workout intensity.
- **Smart App Connectivity:** Connects to fitness apps for tracking, training plans, and interactive workouts.
- **Enhanced Shock Absorption:** 7-layer cushioning belt with 6 silicone absorbers and 2 soft rubber pads for joint protection.
- **Powerful 2.5HP Motor:** Supports up to 300 lbs, speeds from 0.6–6.2 MPH, with quiet operation (<45db).
- **Compact & Foldable Design:** Easy to store under furniture or vertically, with transport wheels.

Components

- Treadmill Unit
- Adjustable Handlebar
- Remote Control
- Power Cord
- Safety Key

Compact Design & Space Saving



Figure 1: Acezoe P11 Pro Treadmill in its two primary configurations: walking mode (handlebar folded) and running mode (handlebar raised).

Setup and Assembly

1. Unpacking

Carefully remove the treadmill from its packaging. Inspect all components for any damage. Ensure all parts listed in the components

section are present.

2. Handlebar Adjustment

To adjust the handlebar height, loosen the locking knobs on both sides of the handlebar. Slide the handlebar to your desired height (levels 1-5 are marked). Ensure both sides are adjusted evenly. Tighten the locking knobs securely before use.



Figure 2: Illustration of the adjustable handlebar, demonstrating various height settings for different user preferences.

3. Incline Adjustment

The treadmill features 3 manual incline levels: 1%, 6%, and 12%. To change the incline, lift the rear of the treadmill and adjust the support legs to the desired level. Ensure both sides are set to the same incline level for stability.

Adjustable 1%-6%-12%Incline

Simulate Real Climbing Burns 50% More Calories



With Incline+
1 %



120
Kcal/H

With Incline+
6 %



220
Kcal/H

With Incline+
12 %



340
Kcal/H

Figure 3: Visual representation of the manual incline settings (1%, 6%, 12%) and their impact on calorie expenditure.

4. Placement

Place the treadmill on a firm, level surface with at least 2 feet (0.6 meters) of clear space on each side and 6 feet (1.8 meters) behind it for safety.

Operating Instructions

1. Power On/Off

Plug the power cord into a grounded outlet. Flip the main power switch located at the front of the treadmill to the 'ON' position. The LED display will illuminate. To turn off, flip the switch to 'OFF' and unplug the unit.

2. Using the Control Panel

The integrated control panel allows direct control of the treadmill. Press the 'Start/Stop' button to begin or end a workout. Use the '+' and '-' buttons to adjust speed. The 'P/M' button cycles through different modes or programs. The display shows speed, time, distance, and calories burned.

3. Using the Remote Control

The remote control provides convenient access to basic functions. Use the 'Start/Stop' button to begin or end your workout. The arrow buttons ('+' and '-') adjust the speed. The remote can also be used to pause the workout.

Your Smart Workout Companion

Start your Fitness Journey with Apps



Figure 4: The treadmill's control panel and remote control, illustrating the various buttons for speed adjustment, start/stop, and mode selection.

4. App Connectivity

Download the dedicated fitness app from your smartphone's app store. Enable Bluetooth on your device and open the app. Follow the in-app instructions to pair with your Acezoe P11 Pro treadmill. The app allows for advanced workout tracking, program selection, and virtual scenic routes.

2.5HP Powerful & Quiet Motor

One-Click Mute



Motor



0.6-6.2mph



300lbs



<45db



Figure 5: The treadmill connected to a fitness app, showing real-time workout data and virtual running environments.

Maintenance

1. Cleaning

Regularly wipe down the treadmill with a damp cloth after each use. Avoid using abrasive cleaners or solvents that could damage the surfaces. Ensure no moisture enters the motor housing or electrical components.

2. Lubrication

The running belt requires periodic lubrication to ensure smooth operation and prolong its lifespan. Refer to the specific lubrication instructions provided with your treadmill, typically every 3-6 months depending on usage. Use only silicone-based treadmill lubricant.

3. Belt Adjustment

If the running belt becomes misaligned or slips, it may require adjustment. Use the provided hex key to turn the tension bolts at the rear of the treadmill. Turn clockwise to tighten and counter-clockwise to loosen. Adjust in small increments (quarter turns) until the belt is centered and properly tensioned. Do not overtighten.

Troubleshooting

Problem	Possible Cause	Solution
Treadmill does not power on	Power cord not plugged in, power switch off, circuit breaker tripped.	Check power cord connection, ensure power switch is ON, reset circuit breaker.
Running belt slips or hesitates	Belt too loose, belt needs lubrication.	Adjust belt tension (see Maintenance), lubricate belt (see Maintenance).
Unusual noise during operation	Loose parts, motor issue, belt friction.	Inspect for loose screws, lubricate belt, contact customer support if noise persists.
Remote control not responding	Dead battery, remote out of range, interference.	Replace remote battery, ensure remote is within operating range, remove obstructions.

Product Specifications

Feature	Detail
Brand	Acezoe
Model Name	P11ProG
Product Dimensions	53.94"D x 28.27"W x 5.12"H
Folded Size	50" x 25" x 5.1"
Item Weight	65 Pounds
Material	Alloy Steel
Maximum Weight Recommendation	300 Pounds
Motor Horsepower	2.5 HP
Speed Range	0.6 - 6.2 MPH
Maximum Incline Percentage	12% (3 manual levels: 1%, 6%, 12%)
Display Type	LED
Metrics Measured	Distance, Speed, Calories Burned
Connectivity Technology	Bluetooth

Feature	Detail
Power Source	Corded Electric
Included Components	Remote Control

Warranty and Customer Support

The Acezoe P11 Pro Walking Pad Treadmill comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. For warranty claims or technical assistance, please contact Acezoe customer support. Acezoe is committed to providing responsive customer service. Our team is available to assist with any questions or issues you may encounter.

- **Service Duration:** 12 Months Lifetime Service
- **Response Time:** 24 Hours Rapid Response & Problem Solving Team

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question