

[Manuals.plus](#) /

› [Creality](#) /

› Creality PTC Chamber Heater 400W User Manual

Creality PTC Chamber Heater 400W

Creality PTC Chamber Heater 400W User Manual

Model: PTC Chamber Heater 400W

Brand: Creality

1. PRODUCT OVERVIEW

The Creality PTC Chamber Heater 400W is designed to optimize 3D printing environments by providing controlled heating within the printer's enclosure. This device helps to maintain a stable temperature, which is crucial for printing with various filament types, reducing common issues like warping and improving overall print quality.



Image 1.1: The Creality PTC Chamber Heater, showcasing its compact design, remote control, and primary benefits including chamber temperature control, reduced warping, filament drying, and dual safety protection.

Key Features:

- **Efficient Chamber Heating:** Equipped with a 400W PTC heater and dual axial fans, it provides 70°C high-temperature hot air circulation, reducing warping, shrinkage, and layer lines.
- **Precision Temperature Control:** Features an independent temperature controller with flexible settings, supporting 45-70°C temperature control and a 1-48 hour timer. Includes power-off memory.
- **Filament Drying & Stability:** Active chamber heating minimizes warping and improves print quality for materials like ABS, PA, and PC. Continuous drying prevents moisture-induced problems such as drawing, clogging, and layer shifting.
- **Dual Safety Protection:** Built-in overheat and short-circuit protection. Automatically stops upon fan failure detection and shuts off heating if PTC temperature becomes too high.

2. SETUP AND INSTALLATION

Proper installation ensures optimal performance and safety of your PTC Chamber Heater. Follow these steps carefully.

Installation Steps:

1. **Choose Location:** Select a suitable location within your 3D printer enclosure for mounting the heater. Ensure adequate clearance for airflow and maintenance.
2. **Mounting:** Use the provided mounting points and hardware to secure the heater. Refer to the mounting diagram for precise measurements.
3. **Connect Power:** Plug the heater's power cable into a compatible power outlet.
4. **Connect Controller:** Connect the independent temperature controller to the heater unit.

Dual Safety Protection

Automatically stops when fan failure is detected



Automatically shuts off heating when PTC temperature is too high.




Image 2.1: Quick Installation diagram illustrating the M3 screw mounting points and the flat mounting dimensions (201.5mm length, 91.5mm width, with screw distances of 38mm and 88mm).

3. OPERATING INSTRUCTIONS

The PTC Chamber Heater is designed for user-friendly operation with its independent temperature controller.

Temperature and Timer Settings:

- **Power On/Off:** Press the power button on the controller to turn the unit on or off.
- **Set Temperature:** Use the '+' and '-' buttons to adjust the desired chamber temperature between 45°C and 70°C. The display will show the current setting.
- **Set Timer:** Use the timer button to set the operating duration from 1 to 48 hours. The heater will automatically shut off after the set time.
- **Power-Off Memory:** The unit retains the last temperature and timer settings even after being powered off.
- **Unit Switch:** The controller allows switching between Celsius (°C) and Fahrenheit (°F) display units.



Image 3.1: The independent temperature controller in use, displaying a set temperature of 70°C. This controller allows for precise

adjustment of heating parameters.

Benefits of Active Heating:

- **Reduced Warping:** Maintaining a consistent chamber temperature significantly reduces material warping, especially with sensitive filaments like ABS, PA, and PC.
- **Improved Layer Adhesion:** Stable temperatures promote better layer bonding, leading to stronger and more durable prints.
- **Filament Drying:** Continuous drying during printing prevents moisture absorption, which can cause print defects such as stringing, clogging, and poor surface finish.



Image 3.2: Visual comparison demonstrating the positive impact of filament drying on print quality. The 'After Drying' print shows significantly smoother surfaces and fewer imperfections compared to the 'Before Drying' print.

4. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your Creality PTC Chamber Heater.

- **Cleaning:** Periodically clean the exterior of the heater and the intake filter to prevent dust buildup, which can impede airflow and reduce efficiency. Use a soft, dry cloth.
- **Fan Inspection:** Ensure the axial fans are free from obstructions and rotate smoothly.
- **Cable Check:** Inspect all power and control cables for any signs of wear or damage. Replace if necessary.
- **Storage:** If storing the heater for an extended period, ensure it is clean, dry, and stored in a safe environment.




Image 4.1: Detailed view of the heater's components, including the controller with °C/°F unit switch, the insulation rubber sleeve for safety, and the intake filter which should be kept clean for optimal performance.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your PTC Chamber Heater.

Common Issues and Solutions:

- **Heater Not Turning On:**

- Check if the power cable is securely plugged into both the heater and the power outlet.
- Ensure the controller is properly connected to the heater unit.
- Verify that the power outlet is functional.

- **Insufficient Heating:**

- Confirm the set temperature is appropriate for your printing environment and filament.
- Check for any obstructions blocking the heater's air intake or exhaust.
- Ensure the printer enclosure is adequately sealed to retain heat.

- **Unusual Noises:**

- Inspect the fans for any foreign objects or dust buildup. Clean if necessary.
- Ensure the heater is securely mounted and not vibrating against the enclosure.

- **Safety Shutdown:** The heater is equipped with dual safety protection. If the unit unexpectedly shuts off, it may be due to:

- **Fan Failure:** The unit automatically stops if fan failure is detected. Check fans for obstructions.
- **Overheat Protection:** Heating automatically shuts off if the PTC temperature becomes too high. Allow the unit to cool down before restarting. Ensure proper ventilation.

Filament Drying for Perfect Prints

Continuous drying of consumables during the printing process prevents moisture-induced problems such as drawing, clogging, and layer shifting, and minimizes the impact of external environmental factors on 3D consumable printing.



Image 5.1: Illustration of the dual safety protection mechanisms. The top panel shows fans with a warning symbol indicating automatic shutdown upon fan failure. The bottom panel shows the PTC heating element with a green indicator, signifying automatic shutdown if the PTC temperature exceeds safe limits.

6. SPECIFICATIONS

Feature	Specification
Model	PTC Chamber Heater 400W
Heating Power	400W
Temperature Range	45-70°C (113-158°F)
Timer Settings	1-48 hours

Feature	Specification
Package Dimensions	10.94 x 9.69 x 3.39 inches
Item Weight	3.03 pounds
Manufacturer	Creality
Safety Features	Overheat Protection, Short-circuit Protection, Fan Failure Detection

7. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Creality website or contact your retailer. Keep your purchase receipt for warranty claims.

- **Online Resources:** Visit the Creality official website for FAQs, firmware updates, and additional support documentation.
- **Customer Service:** Contact Creality customer service for direct assistance with product issues or inquiries.

© 2025 Creality. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

