

TOPUTURE TP4

TOPUTURE 4 in 1 Walking Pad Treadmill with Incline and Handle

Model: TP4 | Brand: TOPUTURE

1. INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your TOPUTURE 4 in 1 Walking Pad Treadmill. Please read this manual thoroughly before initial use and retain it for future reference.



Image: The TOPUTURE 4 in 1 Walking Pad Treadmill shown in two modes: as a traditional treadmill with a handle for running, and as a flat walking pad under a desk for walking while working.

2. KEY FEATURES

- **4-in-1 Versatility:** Functions as a walking pad, climbing mode, working mode (under desk), and running mode.
- **Adjustable Incline:** Features a 9% manual incline to simulate climbing, enhancing calorie burn.
- **Powerful & Quiet Motor:** Equipped with a 2.5HP motor for sufficient power with low noise operation (below 45dB).
- **Dual LED Display:** Two LED screens (on handlebar and base) provide real-time data for time, speed, distance, and calories burned.
- **Mute Control:** Remote control includes a mute button to silence operational beeps.
- **Double Shock Absorption:** Features a 5-layer anti-slip belt, 6 silicone shock absorbers, and 2 soft rubber pads to protect joints.

- **Compact & Foldable Design:** Folds to 50"x23"x4.5" and weighs 47 lbs, with transport wheels for easy movement and storage.
- **App & Bluetooth Connectivity:** Connects to fitness apps like Fitshow to record and track exercise data.



Image: An exploded view showing the powerful 2.5HP motor and internal shock absorption components, emphasizing low noise operation.

3. SETUP

1. **Unboxing:** Carefully remove the treadmill from its packaging. The unit comes largely pre-assembled.
2. **Handlebar Setup:** Lift the handlebar into the upright position. Secure it by tightening the two wing bolts on each side.

3. **Power Connection:** Locate the power input port at the base of the treadmill. Connect the provided power cord securely.
4. **Safety Key:** Attach the red magnetic safety key to the designated spot on the handlebar console. For safety, clip the other end of the cord to your clothing. The treadmill will not operate without the safety key in place.
5. **Initial Power On:** Flip the main power switch located near the power input port to the 'ON' position. The LED displays will illuminate.



Image: Visual guide for unfolding the treadmill and securing the handlebar for use.

4. OPERATING INSTRUCTIONS

4.1 Modes of Operation

- **Walking Mode (0.6-5 MPH):** Ideal for casual walking or under-desk use.
- **Running Mode (5-7.6 MPH):** For more intense cardio workouts.
- **Climbing Mode:** Achieved by engaging the manual incline.
- **Working Mode:** With the handlebar folded down, the treadmill functions as a walking pad suitable for use under a standing desk.



Image: Depiction of the treadmill's four primary usage modes, illustrating its versatility.

4.2 Adjusting Speed and Incline

- **Speed Adjustment:** Use the '+' and '-' buttons on the handlebar console or the remote control to increase or decrease speed.
- **Incline Adjustment:** The treadmill features a manual 9% incline. To engage, lift the rear of the treadmill and pull out the support legs. Insert the provided pin into the designated hole to secure the legs. Ensure both sides are adjusted evenly.



Image: Step-by-step instructions for manually setting the treadmill's incline.

4.3 Display and Controls

- **Dual LED Screens:** Monitor your workout data (time, speed, distance, calories) on both the handlebar and base displays.
- **Remote Control:** Use the magnetic remote to start/stop, adjust speed, and mute beeps.
- **App Connectivity:** Download the Fitshow app and connect via Bluetooth to track your exercise activities and progress.

Dual LED Screen Display

Clear display of data



Image: Detailed view of the dual LED display and control buttons on the handlebar, showing various workout metrics.

4.4 Safety Features

- **Safety Key:** The magnetic safety key must be attached for operation. If detached, the treadmill will immediately stop.
- **Mute Function:** Use the remote control's mute button to prevent disturbing beeps.

5. STORAGE AND PORTABILITY

The TOPUTURE treadmill is designed for easy storage and portability. To store the treadmill, simply loosen the handlebar bolts and fold the handlebar down. The compact size and built-in transport wheels allow it to be easily moved and stored under a bed, sofa, or in a closet.



Image: Visual representation of the treadmill folding for space-saving storage and its transport wheels for easy relocation.

6. MAINTENANCE

- **Lubrication:** Regularly apply lubricating oil to the running belt to ensure smooth operation and extend the treadmill's lifespan. The treadmill features a convenient drip tube design on the side to avoid spills during lubrication.
- **Belt Adjustment:** Periodically check and adjust the running belt tension and alignment as needed using the provided L-wrench.
- **Cleaning:** Keep the treadmill clean by wiping it down with a damp cloth after each use.



Image: Instructions for adding lubricating oil and adjusting the running belt.

7. SPECIFICATIONS

Feature	Specification
Brand	TOPUTURE
Model Name	TP4
Product Dimensions	50"D x 23"W x 4.5"H
Item Weight	21.6 Kilograms (approx. 47.6 lbs)

Feature	Specification
Material	Alloy Steel
Maximum Speed	7.6 Miles per Hour
Maximum Horsepower	2.5 Horsepower
Maximum Incline Percentage	9% (Manual)
Maximum Weight Recommendation	130 Kilograms (approx. 300 lbs)
Running Area	40"x16"
Assembly Required	No (Pre-assembled)
Power Source	Corded Electric
Connectivity Technology	Bluetooth
Included Components	Safety Key, Power Cord, Remote Control, User Manual, L-Wrench



Image: The treadmill highlighting its maximum weight capacity of 300 lbs.

8. TROUBLESHOOTING

- **Treadmill Not Starting:** Ensure the power cord is securely plugged in, the main power switch is ON, and the magnetic safety key is correctly attached to the console.
- **Belt Slipping:** The running belt may require tension adjustment. Refer to the Maintenance section for instructions on adjusting the belt.
- **Unusual Noise:** Check for any loose parts. If the noise persists, ensure the belt is properly lubricated. If the issue continues, contact customer support.
- **Display Not Working:** Verify the power connection and ensure the treadmill is turned on. If the display remains blank, contact customer support.

9. WARRANTY AND SUPPORT

Your TOPUTURE 4 in 1 Walking Pad Treadmill comes with a **1-year warranty**. For any warranty claims, after-sales service, or technical support, please contact TOPUTURE customer service via email:

US/CA: toputure_service@outlook.com
UK/EU: toputure.service@gmail.com

You can also scan the QR code on the product label to download the FITSHOW APP for additional features and workout tracking.






Image: TOPUTURE Brand Logo.

10. OFFICIAL PRODUCT VIDEO

Video: An official product video showcasing the TOPUTURE 4 in 1 Treadmill with Incline, demonstrating its features and various modes of use.

Related Documents - TP4

The image shows the cover of the user manual for the Toputure TP3 Incline Walking Pad. It features a line drawing of the walking pad and the text 'USER MANUAL Model TP3 INCLINE WALKING PAD'.	<p>Toputure TP3 Incline Walking Pad User Manual</p> <p>Comprehensive user manual for the Toputure TP3 Incline Walking Pad, covering installation, safety precautions, features, operation, maintenance, and troubleshooting. Includes technical specifications, error codes, and FCC compliance information.</p>
The image shows the cover of the user manual for the Toputure TP3 Incline Walking Pad. It features a line drawing of the walking pad and the text 'USER MANUAL Model TP3 INCLINE WALKING PAD'.	<p>Toputure TP3 Incline Walking Pad User Manual</p> <p>User manual for the Toputure TP3 Incline Walking Pad, covering installation, usage, maintenance, and troubleshooting.</p>
The image shows the cover of the user manual for the Toputure TP1 Folding Treadmill. It features a line drawing of the treadmill and the text 'USER MANUAL Model TP1 FOLDING TREADMILL'.	<p>Toputure TP1 Folding Treadmill User Manual</p> <p>Comprehensive user manual for the Toputure TP1 Folding Treadmill, covering installation, operation, safety, maintenance, and troubleshooting.</p>

 <p>The image shows the cover of the Toputure TP1 Folding Treadmill User Manual. It features a line drawing of the treadmill in its folded position. The Toputure logo is at the top left. Below the drawing, a yellow banner contains the text 'USER MANUAL' and 'Model TP1'. At the bottom, it says 'FOLDING TREADMILL'.</p>	<p>Toputure TP1 Folding Treadmill User Manual</p> <p>Comprehensive user manual for the Toputure TP1 Folding Treadmill, covering installation, operation, maintenance, and troubleshooting.</p>
 <p>The image shows the cover of the Toputure TP2 Home Treadmill User Manual. It features a line drawing of the treadmill in its unfolded position. The Toputure logo is at the top left. Below the drawing, a yellow banner contains the text 'USER MANUAL' and 'Model TP2'. At the bottom, it says 'HOME TREADMILL'.</p>	<p>Toputure TP2 Home Treadmill User Manual</p> <p>Comprehensive user manual for the Toputure TP2 Home Treadmill, covering installation, operation, maintenance, safety, and troubleshooting. Includes detailed instructions, parameters, and fault diagnostics.</p>
 <p>The image shows the cover of the Toputure TP2 Home Treadmill User Manual. It features a line drawing of the treadmill in its unfolded position. The Toputure logo is at the top left. Below the drawing, a yellow banner contains the text 'USER MANUAL' and 'Model TP2'. At the bottom, it says 'HOME TREADMILL'.</p>	<p>Toputure TP2 Home Treadmill User Manual</p> <p>User manual for the Toputure TP2 Home Treadmill, covering installation, operation, maintenance, and safety guidelines.</p>