

## Megachef MGSL-5000

# MegaChef 3.5 Quart Rectangle Casserole Slow Cooker

Model: MGSL-5000

## INTRODUCTION

---

Thank you for purchasing the MegaChef 3.5 Quart Rectangle Casserole Slow Cooker. This appliance is designed to simplify your cooking process, allowing you to prepare delicious meals with minimal effort. Please read this instruction manual thoroughly before first use to ensure safe and efficient operation. Keep this manual for future reference.

## IMPORTANT SAFEGUARDS

---

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the slow cooker.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the base unit, cord, or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "OFF", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Avoid sudden temperature changes, such as adding refrigerated foods into a heated crock.
- The stoneware crock is designed for use in this appliance only. It must never be used on a stovetop or in a microwave oven.
- Do not place a hot slow cooker on a wet or cold surface.
- Do not use a cracked crock or a loose lid.
- Do not wrap the cord around the appliance when storing.

## COMPONENTS

---

Familiarize yourself with the parts of your MegaChef Slow Cooker:

- **Tempered Glass Lid:** Allows monitoring of cooking progress. Features a latch and hook locking system for secure transport.
- **Stoneware Crock:** Removable, oven-safe, and dishwasher-safe cooking vessel.
- **Heating Base:** The main unit containing the heating element and control knob.
- **Control Knob:** Used to select temperature settings (OFF, LOW, HIGH, WARM).
- **Carry Handles:** Integrated handles on the heating base for portability.



Figure 1: Exploded view showing the lid, stoneware crock, and heating base.



Figure 2: Front view of the slow cooker, highlighting the control knob and temperature settings.

## SETUP

---

### Before First Use

1. Remove all packaging materials and labels from the slow cooker.

2. Wash the stoneware crock and tempered glass lid in warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the exterior of the heating base with a damp cloth. Do not immerse the heating base in water.
4. Ensure all parts are dry before assembly and use.

## Assembly

1. Place the heating base on a flat, stable, heat-resistant surface.
2. Insert the clean stoneware crock into the heating base.
3. Place the tempered glass lid onto the stoneware crock.

## OPERATING INSTRUCTIONS

---

### Cooking with Your Slow Cooker

1. Prepare your ingredients and place them into the stoneware crock. Do not overfill; ensure there is at least 1 inch of space from the top rim.
2. Place the lid securely on the crock. If transporting, engage the latch and hook locking system.
3. Plug the power cord into a 120V AC electrical outlet.
4. Turn the control knob to your desired setting:
  - **LOW:** For slow cooking over a longer period (approx. 170-190°F).
  - **HIGH:** For faster cooking (approx. 190-212°F).
  - **WARM:** To keep cooked food at serving temperature (approx. 145-165°F). Do not use the WARM setting for cooking.
5. Cook for the time specified in your recipe. Avoid lifting the lid frequently, as this releases heat and extends cooking time.
6. Once cooking is complete, turn the control knob to "OFF" and unplug the slow cooker from the outlet.
7. Allow the appliance to cool before cleaning.



Figure 3: Detail of the control knob for selecting temperature settings.



Figure 4: The latch and hook locking system on the lid for secure transport.



Figure 5: The slow cooker in use, demonstrating its capacity for prepared meals.

## CARE AND MAINTENANCE

---

### Cleaning

1. Always unplug the slow cooker and allow it to cool completely before cleaning.
2. The stoneware crock and tempered glass lid are dishwasher safe or can be washed by hand with warm, soapy water. Avoid abrasive cleaners or scouring pads that may scratch surfaces.
3. To clean the heating base, wipe the exterior with a soft, damp cloth. Do not immerse the heating base in water or any other liquid.
4. For stubborn food residue on the stoneware crock, fill it with warm, soapy water and let it soak for a few hours before cleaning.

### Storage

Ensure all parts are clean and dry before storing. Store the slow cooker assembled with the lid on the crock, or store components separately in a dry place.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Slow cooker does not turn on.	Not plugged in; power outlet not working; control knob set to OFF.	Ensure the unit is securely plugged into a working outlet. Turn the control knob to LOW, HIGH, or WARM.
Food is not cooking properly.	Lid not sealed correctly; incorrect temperature setting; crock overfilled.	Ensure the lid is seated firmly. Verify the correct temperature setting for your recipe. Do not overfill the crock. Avoid lifting the lid frequently.
Exterior of the unit is hot.	Normal operation.	This is normal. Always use the handles when moving the slow cooker. Do not touch hot surfaces.
Lid is difficult to remove after cooking.	Steam has created a vacuum seal.	Gently twist the lid or wait a few minutes for the unit to cool slightly, which may release the seal.

## SPECIFICATIONS

---

<b>Model Number</b>	MGSL-5000
<b>Capacity</b>	3.5 Quarts
<b>Product Dimensions (D x W x H)</b>	11.5" x 19.5" x 5.2"
<b>Voltage</b>	120V
<b>Frequency</b>	60Hz
<b>Wattage (High)</b>	270 Watts
<b>Wattage (Low)</b>	230 Watts
<b>Wattage (Warm)</b>	150 Watts
<b>Material</b>	Stoneware, Glass, Metal
<b>Dishwasher Safe Parts</b>	Stoneware Crock, Tempered Glass Lid

## WARRANTY AND SUPPORT

---

For warranty information or product support, please refer to the documentation included with your purchase or contact MegaChef customer service. Keep your purchase receipt as proof of purchase.

