

[Manuals.plus](#) /

> [MMS](#) /

> MMS15U 1.5 Ton Mini Excavator Instruction Manual

MMS MMS15U

MMS15U 1.5 Ton Mini Excavator Instruction Manual

Brand: MMS | Model: MMS15U

[Overview](#) [Setup](#) [Introduction](#) [Safety Information](#) [Components](#)
[Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your MMS15U 1.5 Ton Mini Excavator. Please read this manual thoroughly before operating the machine to ensure proper usage and to prevent injury or damage.

The MMS15U is a compact and powerful mini excavator designed for various tasks including backyard landscaping, garden path construction, and work in tight spaces. It features a 13.5 HP B&S gasoline engine, an extended hydraulic thumb, and a quick-change coupler for enhanced versatility.



Figure 1: MMS15U 1.5 Ton Mini Excavator. This image shows the overall view of the excavator, highlighting its compact design and main components.

2. SAFETY INFORMATION

Operating heavy machinery requires strict adherence to safety protocols. Failure to follow these guidelines can result in serious injury or death.

2.1 General Safety Precautions

- Always wear appropriate personal protective equipment (PPE), including hard hat, safety glasses, hearing protection, and steel-toed boots.
- Read and understand all warning labels on the machine.
- Ensure the work area is clear of bystanders, especially children and pets.
- Inspect the excavator before each use for any damage, loose parts, or fluid leaks.
- Never operate the machine under the influence of alcohol or drugs.

- Maintain a safe distance from power lines, underground utilities, and unstable ground.
- Always lower the boom and bucket to the ground and engage the parking brake before leaving the operator's seat.

2.2 Engine Safety

- Operate the engine in a well-ventilated area to prevent carbon monoxide poisoning.
- Refuel in a well-ventilated area with the engine off and cool. Avoid spilling fuel.
- Keep flammable materials away from the engine and exhaust system.

3. COMPONENTS OVERVIEW

Familiarize yourself with the main components of the MMS15U Mini Excavator.



Figure 2: Key Components of the MMS15U Mini Excavator. This diagram illustrates the joystick, B&S engine, rubber track, thumb clamp, three-valve hydraulic valve, and 15-inch narrow bucket.

- **B&S Gasoline Engine:** Provides reliable power for excavation tasks.

- **Hydraulic Pilot System:** Delivers precise and smooth control of the excavator's movements.
- **Extended Hydraulic Thumb Clamp:** Aids in gripping and moving various materials.
- **Mechanical Quick Coupler:** Allows for fast and easy attachment changes.
- **Upgraded Yellow Teeth Bucket:** Designed for efficient digging and material handling.
- **Rubber Tracks:** Provide traction and protect surfaces during operation.
- **Dozer Blade:** Used for backfilling, grading, and stabilizing the machine.



Figure 3: Enhanced Upgrades. This image details the extended hydraulic thumb clamp, yellow bucket with side teeth, and mechanical quick coupler.

B&S Gasoline Engine XR2100

Fuel Efficient / Low Emissions / High Productivity



Brand	BRIGGS & STRATTON	Rotational speed	3600 RPM
Model	XR2100	Rated power	13.5HP

Figure 4: B&S Gasoline Engine XR2100. This image shows the 13.5 HP Briggs & Stratton engine, known for fuel efficiency and low emissions.

4. SETUP

Before operating your MMS15U Mini Excavator, perform the following setup procedures.

4.1 Initial Checks

1. **Unloading:** The excavator is delivered with unloading included. Ensure the machine is safely removed from the transport vehicle on a level, stable surface.
2. **Fluid Levels:** Check engine oil, hydraulic fluid, and fuel levels. Refer to the specifications for correct fluid types and capacities. It is recommended to change the hydraulic fluid and engine oil before initial use.
3. **Battery Connection:** Ensure the battery terminals are clean and securely connected.
4. **Greasing:** Lubricate all grease points on the boom, arm, and bucket linkages using a small grease gun.
5. **Attachment Installation:** If not pre-installed, attach the 15-inch digging bucket, extended hydraulic thumb clamp,

and quick change coupler. Ensure all pins and fasteners are secure.

Stay Informed at a Glance: Visual Hydraulic Oil Gauge

Easily monitor your excavator's hydraulic oil level with the side-mounted visual gauge. This allows for quick, accurate checks to maintain optimal performance and prevent potential issues.



Figure 5: Hydraulic Oil Tank. This image shows the location of the hydraulic oil tank, which is crucial for checking fluid levels.



Figure 6: Operator Console. This image displays the ergonomic layout of the control levers and buttons for single-person operation.

5. OPERATION

This section outlines the basic steps for operating the MMS15U Mini Excavator.

5.1 Starting the Engine

1. Ensure the parking brake is engaged and all controls are in the neutral position.
2. Turn the ignition key to the "ON" position.
3. Engage the choke if the engine is cold.
4. Turn the ignition key to the "START" position. Release once the engine starts.
5. Allow the engine to warm up for a few minutes before operating.

5.2 Operating Controls

The MMS15U utilizes a hydraulic pilot system for precise control. The joysticks and foot pedals control the boom, arm, bucket, swing, and track movements.

- **Left Joystick:** Controls boom and swing.
- **Right Joystick:** Controls arm and bucket.
- **Foot Pedals:** Control track movement (forward/reverse) and dozer blade.
- **Hydraulic Thumb Control:** Typically a separate lever or button for gripping.

5.3 Digging and Excavating

1. Position the excavator on stable, level ground.
2. Lower the dozer blade for stability if needed.
3. Use the joysticks to position the bucket for digging.
4. Slowly engage the controls to begin digging. Avoid sudden movements.
5. When lifting material, ensure the load is within the machine's capacity.

Your browser does not support the video tag.

Video 1: 1.5 Tons Mini Excavator Operation. This video demonstrates the basic operational movements of the MMS15U mini excavator, including arm, boom, and bucket articulation.



Figure 7: Versatile Applications. This image shows the MMS15U mini excavator being used in various scenarios, including construction,

6. MAINTENANCE

Regular maintenance is crucial for the longevity and optimal performance of your MMS15U Mini Excavator.

6.1 Daily Checks

- Check engine oil level.
- Check hydraulic fluid level using the visual sight gauge.
- Inspect tracks for damage or excessive wear.
- Check for any fluid leaks (oil, hydraulic fluid, fuel).
- Ensure all lights and safety devices are functional.




Figure 8: Effortless Engine Access. This image illustrates how the operator's seat can be lifted to provide easy access to the engine compartment for maintenance.



Figure 9: Hydraulic System. This image highlights the high-quality cylinders and external hydraulic lines designed for stable working performance and ease of maintenance.

6.2 Scheduled Maintenance

- **Engine Oil Change:** Refer to the engine manufacturer's manual for recommended intervals (typically every 50-100

hours).

- **Hydraulic Fluid Change:** Replace hydraulic fluid and filter as per manufacturer recommendations.
- **Air Filter:** Inspect and clean or replace the air filter regularly, especially in dusty conditions.
- **Fuel Filter:** Replace the fuel filter at recommended intervals.
- **Greasing:** Lubricate all pivot points and moving parts daily or every 8 hours of operation.

7. TROUBLESHOOTING

This section provides solutions for common operational issues.

Problem	Possible Cause	Solution
Engine fails to start	No fuel, dead battery, spark plug issue, clogged fuel filter.	Check fuel level, charge/replace battery, inspect/replace spark plug, replace fuel filter.
Loss of hydraulic power	Low hydraulic fluid, clogged hydraulic filter, hydraulic pump issue.	Check and refill hydraulic fluid, replace hydraulic filter, contact service if pump is suspected.
Overheating engine	Low coolant, clogged radiator, excessive load.	Check coolant level, clean radiator fins, reduce load, allow engine to cool.
Tracks not moving	Track motor issue, hydraulic pressure loss, debris in tracks.	Inspect tracks for obstructions, check hydraulic system, contact service.

8. SPECIFICATIONS

Detailed technical specifications for the MMS15U Mini Excavator.



Model	MS15	Min.Rotation radius	61 inch
Engine	B&S XR2100	Max.Digging depth	72.8 inch
Power	9.5kw/3600r	Max.Digging height	96.5 inch
Working Weight	3307lbs/1500kg	Max.Digging radius	117.7 inch
Overall dimension	100.4*37*92.5 inch	Chassis ground clearance	14.8 inch
Travel speed	3.5 km/h	Track width	7.1 inch

Figure 10: MMS15U Dimensions and Key Specifications. This image provides a visual representation of the excavator's dimensions and a table of key performance metrics.

Feature	Detail
Model	MMS15U
Engine	B&S XR2100 Gasoline Engine, 13.5 HP
Item Weight	3300 pounds (1500 kg)
Product Dimensions (L x W x H)	100.4 x 48 x 92.5 inches
Power Source	Fuel-powered
Rated Power	10.5 KW
Material	Manganese steel
Included Components	15" Digging Bucket, Extended Hydraulic Thumb Clamp, Quick Change

Feature	Detail
Max. Digging Depth	72.8 inches (1850 mm)
Max. Digging Height	96.5 inches (2450 mm)
Max. Digging Radius	117.7 inches (2990 mm)
Travel Speed	3.5 km/h
Track Width	7.1 inches (180 mm)
Min. Rotation Radius	61 inches (1550 mm)
Chassis Ground Clearance	14.8 inches (375 mm)

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact MMS Excavator directly. The product typically includes a manufacturer's warranty covering defects in materials and workmanship.

Customer Support: For technical assistance, parts, or service inquiries, please contact MMS Excavator customer service. Keep your model number (MMS15U) and purchase date ready when contacting support.

