

[Manuals.plus](#) /

› [MUXWELL](#) /

› MUXWELL HU-053A DIY FLC Meter Soldering Kit Instruction Manual

MUXWELL HU-053A

MUXWELL HU-053A DIY FLC Meter Soldering Kit Instruction Manual

Frequency, Inductance, and Capacitance Meter Assembly and Operation Guide

1. INTRODUCTION

This manual provides detailed instructions for assembling and operating your MUXWELL HU-053A DIY Frequency, Inductance, and Capacitance (FLC) Meter Soldering Practice Kit. This kit is designed for electronics enthusiasts and beginners to gain hands-on experience with electronic components, soldering techniques, and circuit assembly. Upon completion, you will have a functional FLC meter capable of measuring frequency, inductance, and capacitance.

DIY soldering & assembly FLC Meter

- ◆ Frequency Test
- ◆ Capacitance Test
- ◆ Inductance Test



Figure 1: Fully assembled MUXWELL HU-053A FLC Meter displaying a capacitance reading. The clear enclosure protects the internal components and LCD screen.

2. SAFETY INFORMATION

Please read and understand all safety instructions before beginning assembly. Improper use or assembly can result in injury or damage to the device.

- **Soldering Safety:** Always work in a well-ventilated area. Use appropriate eye protection to shield against solder splashes and fumes. Avoid touching the hot soldering iron tip or recently soldered components. Allow components to cool before handling.
- **Electrical Safety:** Ensure the power supply is disconnected before making any connections or adjustments to the circuit. Do not exceed the specified voltage (5V DC) for the device.
- **Component Handling:** Some electronic components can be sensitive to static electricity. Handle components by their bodies, not their leads, and consider using anti-static precautions.
- **General Safety:** Keep small components away from children. Dispose of electronic waste responsibly.

3. PACKAGE CONTENTS

Verify that all components listed below are present in your kit before starting assembly. If any parts are missing or damaged, please contact MUXWELL customer support.



Figure 2: Overview of all components included in the kit, such as the PCB, LCD screen, resistors, capacitors, inductors, switches, and the acrylic enclosure parts.

- Printed Circuit Board (PCB)
- LCD Display Module
- Acrylic Enclosure Parts (top, bottom, sides)
- Various Resistors, Capacitors, and Inductors
- Integrated Circuits (ICs) and Sockets
- Diodes and Transistors
- Push Buttons and Rotary Switch
- Test Socket (ZIF socket)
- Power Jack and USB Cable
- Mounting Hardware (screws, nuts, standoffs)
- Instruction Manual (this document)

4. SETUP AND ASSEMBLY

Follow these steps carefully to assemble your FLC meter. It is recommended to organize your components before you begin soldering.


4.1. Component Identification and Preparation


1. Identify all components using the provided component list and the markings on the PCB.
2. Bend the leads of through-hole components (resistors, diodes, capacitors) as needed to fit into their designated holes on the PCB.

4.2. PCB Assembly (Soldering)

Solder components onto the PCB in a systematic order, typically starting with the lowest profile components first to make soldering easier.

1. **Resistors:** Solder all resistors into their marked positions. Resistors are not polarized, so orientation does not matter.
2. **Diodes:** Solder diodes, paying close attention to their polarity. The band on the diode must match the band marking on the PCB.
3. **Capacitors:** Solder ceramic capacitors (non-polarized) and then electrolytic capacitors (polarized). For electrolytic capacitors, the longer lead is positive (+), and the shorter lead (or the side with a stripe) is negative (-). Match this to the PCB markings.
4. **Transistors and IC Sockets:** Solder transistors, ensuring correct orientation (flat side or pin 1 marking). Solder the IC sockets before inserting the actual ICs to prevent heat damage to the ICs.
5. **Switches and Connectors:** Solder the push buttons, rotary switch, power jack, and test socket (ZIF socket).
6. **LCD Module:** Solder the pin header to the LCD module, then solder the LCD module to the main PCB. Ensure the pins align correctly.





Once all components are soldered to the PCB, assemble the acrylic enclosure.

1. Remove the protective film from all acrylic parts.
2. Mount the assembled PCB onto the bottom acrylic plate using the provided standoffs and screws.
3. Attach the side panels to the bottom plate, ensuring all cutouts align with the ports and switches on the PCB.
4. Place the top acrylic plate, securing it with the remaining screws. Ensure the LCD screen is visible and buttons/switches are accessible through the cutouts.



Figure 4: Rear view of the FLC Meter, showing the PCB mounted within the clear acrylic enclosure.

5. OPERATING INSTRUCTIONS

This section details how to power on and use your MUXWELL HU-053A FLC Meter for measurements.




Figure 5: Labeled diagram indicating the Power Input (5Vdc), Power On/Off switch, Mode Select Switch, Calibration/Range Selection, Amplifier Voltage Adjustment, Brightness Adjustment, Positive/Negative Pins, Test Socket, and Test Connector.

5.1. Powering On

1. Connect the provided USB cable to the **Power Input (5Vdc)** port on the meter (refer to Figure 5).
2. Connect the other end of the USB cable to a 5V DC power source (e.g., a USB wall adapter, computer USB port).
3. Flip the **Power On/Off** switch to the 'ON' position. The LCD screen should illuminate and display the initial measurement screen.

5.2. Mode Selection

The meter can measure Frequency, Inductance, and Capacitance. Use the **Mode Select Switch** (rotary switch) to choose the desired measurement mode.

- Rotate the switch to select between Frequency (Hz), Inductance (H), and Capacitance (F) modes. The selected mode will be indicated on the LCD.

5.3. Performing Measurements

To measure a component, insert its leads into the **Test Socket** or connect to the **Test Connector**.

1. Capacitance (Cx) Measurement:

- Select the Capacitance mode using the Mode Select Switch.
- Discharge the capacitor before testing to prevent damage to the meter.
- Insert the capacitor leads into the **Test Socket** (Positive Pins and Negative Pins) or connect to the **Test Connector**.

- The capacitance value will be displayed on the LCD.

2. Inductance (Lx) Measurement:

- Select the Inductance mode using the Mode Select Switch.
- Insert the inductor leads into the **Test Socket** or connect to the **Test Connector**.
- The inductance value will be displayed on the LCD.

3. Frequency (Fx) Measurement:

- Select the Frequency mode using the Mode Select Switch.
- Connect the signal source to the **Test Connector**.
- The frequency value will be displayed on the LCD.

5.4. Adjustments

- **Brightness Adjustment:** Use the small potentiometer labeled 'Brightness Adjustment' to adjust the contrast of the LCD display for optimal viewing.
- **Amplifier Voltage Adjustment:** This potentiometer allows fine-tuning of the internal amplifier voltage, which may be necessary for certain measurements or calibration.
- **Calibration/Range Selection:** The button labeled 'Calibration/Range Selection' can be used for zeroing the meter or selecting different measurement ranges, depending on the mode. Refer to the on-screen prompts for specific calibration procedures.

6. MAINTENANCE

Proper maintenance ensures the longevity and accuracy of your FLC meter.

- **Cleaning:** Use a soft, dry cloth to clean the enclosure and LCD screen. Avoid abrasive cleaners or solvents.
- **Storage:** Store the meter in a dry, dust-free environment when not in use.
- **Component Check:** Periodically inspect soldered joints for any signs of cold solder joints or corrosion.

7. TROUBLESHOOTING

If you encounter issues with your FLC meter, refer to the following common problems and solutions.

- **Meter does not power on:**
 - Check if the USB power cable is securely connected and the power source is active.
 - Ensure the Power On/Off switch is in the 'ON' position.
 - Inspect the power jack and associated solder joints on the PCB.
- **LCD screen is blank or unreadable:**
 - Adjust the 'Brightness Adjustment' potentiometer.
 - Verify the LCD module is correctly seated and its pin headers are properly soldered.
 - Check for any short circuits or open circuits around the LCD connections.
- **Inaccurate or erratic readings:**
 - Ensure the component is properly inserted into the Test Socket or connected to the Test Connector.
 - Perform a calibration if available for the selected mode (refer to section 5.4).

- Check for cold solder joints or incorrect component values/orientations on the PCB.
- Ensure the component being tested is within the meter's specified measurement range.

8. SPECIFICATIONS

Key technical specifications for the MUXWELL HU-053A FLC Meter.

- ◆ **Power Supply:** 5Vdc
- ◆ **Frequency range:** 20Hz ~ 400kHz
- ◆ **Inductance Range:** 1uH ~ 1H
- ◆ **Capacitance Range:** 1uF~12000uF
1pF~2200pF




Figure 6: Visual representation of the meter's dimensions and its operational ranges for power, frequency, inductance, and capacitance.

Feature	Specification
Model Number	HU-053A
Power Supply	5V DC (via USB)

Frequency Range	20 Hz ~ 400 kHz
Inductance Range	1 uH ~ 1 H
Capacitance Range	1 pF ~ 2200 pF (low range), 1 uF ~ 12000 uF (high range)
Display Type	Digital LCD
Dimensions (L x W x H)	106mm x 91mm x 28mm (approx. 4.1"D x 3.5"W x 2"H)
Item Weight	91 Grams

9. WARRANTY AND SUPPORT

MUXWELL products are designed for quality and reliability. For specific warranty information, please refer to the product packaging or contact your retailer. If you require technical assistance or have questions regarding your MUXWELL HU-053A FLC Meter, please contact MUXWELL customer support through the platform where you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question