

[Manuals.plus](#) /

› [Juboos](#) /

› Juboos Model 536 Digital Kids Alarm Clock User Manual

Juboos 536

Juboos Model 536 Digital Kids Alarm Clock

User Instruction Manual

IMPORTANT SAFETY INFORMATION

- Keep the device away from water and high humidity.
- Do not expose the device to extreme temperatures or direct sunlight.
- Use only the specified power adapter or USB cable for charging.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Keep out of reach of small children to prevent choking hazards from small parts.

PACKAGE CONTENTS

- Juboos Model 536 Digital Kids Alarm Clock (1 unit)
- USB-C Charging Cable (1 unit)
- User Manual (this document)

PRODUCT OVERVIEW

The Juboos Model 536 is a digital alarm clock designed for children, featuring dual alarms, a snooze function, 8 RGB night light colors, and a 12/24 hour display system. It also includes adjustable volume, brightness, and a countdown timer.



Fußball Bunte Lichter Kinderwecker



Doppelwecker



Schlummerfunktion



Nachtlicht



6 Klingeltöne



12/24 Std



Einstellbare
Lautstärke



Einstellbare
Helligkeit



Countdown



USB-Aufladung



Vibrieren,
um den Bildschirm
zu beleuchten

Overview of the Juboos Kids Alarm Clock features, including dual alarm, snooze, night light, 6 ringtones, 12/24 hour display, adjustable volume, adjustable brightness, countdown timer, USB charging, and vibration to illuminate the screen.



Diagram showing the dimensions of the Juboos Kids Alarm Clock: 10.4cm (4.1in) width, 11.5cm (4.5in) height, and 6.3cm (2.5in) depth. Also shows the product packaging dimensions.

SETUP

1. Initial Power On and Charging

Connect the provided USB-C charging cable to the charging port on the back of the alarm clock and plug the other end into a compatible USB power adapter (not included) or a computer USB port. The display will light up, indicating it is charging. A full charge is recommended before first use.

2. Setting the Time

1. Press and hold the 'SET' button (usually located on the back or bottom) until the hour digits begin to flash.
2. Use the '+' and '-' buttons to adjust the hour.
3. Press 'SET' again to move to the minute setting, then use '+' and '-' to adjust the minutes.
4. Press 'SET' one more time to confirm and exit time setting mode.

3. 12/24 Hour Format Selection

While in time setting mode (when the hour or minute digits are flashing), press the '12/24H' button (if available, or the '+' button might toggle this) to switch between 12-hour (with AM/PM indicator) and 24-hour formats. Confirm your selection by pressing 'SET'.

OPERATING INSTRUCTIONS

1. Alarm Settings (Dual Alarms & Snooze)

The alarm clock supports two independent alarms (Alarm 1 and Alarm 2) and a snooze function.

Doppelter Wecker

Unterscheidung zwischen Wochentagen und Wochenenden



Montag bis Freitag



Montag bis Samstag



Montag bis Sonntag

Schlummern für weitere 5 Minuten

Wenn der Wecker ertönt, drücken Sie die Taste auf der Oberseite des Weckers, um in den Schlummermodus zu wechseln.



Illustration demonstrating the dual alarm function with options for weekdays (Monday-Friday), Monday-Saturday, or Monday-Sunday. Also shows the snooze function, activated by pressing the top button for an additional 5 minutes of sleep.

- Setting an Alarm:** Press the 'ALARM 1' or 'ALARM 2' button. The alarm time will flash. Use '+' and '-' to set the desired hour and minute. Press the alarm button again to confirm.
- Alarm Frequency:** After setting the time, you may be able to select the alarm frequency (e.g., 1-5 for weekdays, 1-6 for Monday-Saturday, 1-7 for everyday). Use '+' or '-' to cycle through options and confirm with the alarm button.
- Activating/Deactivating Alarm:** Press the 'ALARM 1' or 'ALARM 2' button briefly to toggle the alarm on or off. An

alarm icon will appear on the display when active.

4. **Snooze Function:** When an alarm sounds, press the large button on the top of the alarm clock to activate snooze. The alarm will pause for approximately 5 minutes and then sound again.
5. **Stopping an Alarm:** To turn off the alarm completely when it sounds, press any other button (e.g., 'SET' or a volume button) or wait for it to automatically stop after a set duration.

2. Night Light Function (RGB & Timed)

The alarm clock features a colorful RGB night light with adjustable brightness and a timed shut-off option.

Siebenfarbiges Licht schaltbar

如主/



Die Schriftfarbe und die Lichtfarbe können nach Ihren Wünschen angepasst werden



Depiction of the seven-color adjustable night light feature, showing low, medium, and high brightness settings. The display color and light color can be customized.

1. **Turning On/Off Night Light:** Press the 'LIGHT' button (or a dedicated light icon button) to turn the night light on or off.
2. **Changing Colors:** While the night light is on, press the 'LIGHT' button repeatedly to cycle through the available RGB colors.
3. **Adjusting Brightness:** Use the brightness control button (often labeled with a sun icon or integrated with '+' / '-') to

adjust the intensity of the night light.

Timed Night Light Function

Zeitgesteuertes 120-Minuten-Nachtlicht



① Externe
Stromversorgung
anschießen



② Drücken und
halten Sie die obere
Taste, bis das Display
L0:15 anzeigt



③ Drücken Sie „+“ und „-“,
um die Timerlänge bis zu
120 Minuten einzustellen



Hinweis: Die zeitgesteuerte Nachtlichtfunktion erfordert den Anschluss an eine externe Stromquelle

Instructions for the timed 120-minute night light: 1. Connect external power supply. 2. Press and hold the top button until the display shows 'L0:15'. 3. Use '+' and '-' buttons to set the timer duration up to 120 minutes. Note: The timed night light requires an external power source.

To set a timed duration for the night light (up to 120 minutes):

1. Ensure the alarm clock is connected to an external power supply via the USB-C cable.

2. Press and hold the top button (often the snooze button) until the display shows a timer setting, typically starting with 'L0:15' (for 15 minutes).
3. Use the '+' and '-' buttons to adjust the desired duration for the night light, up to 120 minutes. The night light will automatically turn off after the set time.

3. Alarm Tones and Volume

You can select from various alarm tones and adjust the alarm volume.



A child is lying in bed, stretching their arms, looking happy. A large digital alarm clock is shown in the foreground, displaying '7:11' and '10:30' in colorful digits. The clock has a rainbow-colored ring around the display and is surrounded by musical notes. In the background, a teddy bear is on the left, and a cat is peeking from behind a curtain on the right.

U01-Volume of the Tone-U09



A volume bar with 11 colored segments (red, pink, purple, blue, cyan, green, yellow, orange) is shown, flanked by speaker icons and minus/plus signs. Below the bar are six circular icons representing different alarm tones: a bird (Vogel), Santa Claus (Weihnachten), zzz (Piep), a city skyline (Weich), a city skyline (Begeisterung), and a colorful geometric pattern (Glücklicht).

Vogel Weihnachten Piep Weich

Begeisterung Glücklicht

Visual representation of the adjustable volume levels (U01-U09) and various alarm tones, including bird, Christmas, beep, soft, enthusiasm, and happy melodies.

- 1. **Selecting Alarm Tone:** When setting an alarm, after setting the time, you may be prompted to select a tone. Use '+' and '-' to cycle through the available melodies (e.g., bird, Christmas, beep, soft, enthusiasm, happy). Confirm with the alarm button.
- 2. **Adjusting Volume:** During alarm setting, or via a dedicated volume button, you can adjust the alarm volume from U01 (lowest) to U09 (highest).

4. Countdown Timer

The alarm clock includes a countdown timer function for various activities.

- 1. **Activating Countdown:** Press the 'TIMER' or 'COUNTDOWN' button. The display will show a default countdown time.
- 2. **Setting Countdown Time:** Use the '+' and '-' buttons to set the desired countdown duration in minutes and seconds.
- 3. **Starting/Pausing Countdown:** Press the 'TIMER' or 'START/PAUSE' button to begin or pause the countdown.
- 4. **Stopping Countdown:** Press and hold the 'TIMER' button to stop and reset the countdown.

MAINTENANCE

Cleaning

To clean the alarm clock, gently wipe the surface with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Do not use abrasive cleaners, solvents, or immerse the device in water.

Battery Care

The alarm clock is powered by a built-in rechargeable battery. To prolong battery life, avoid fully discharging the battery frequently. Recharge the device when the low battery indicator appears. If storing the device for an extended period, charge it periodically to maintain battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is blank.	Battery is depleted or not charged.	Connect the alarm clock to a power source using the USB-C cable and allow it to charge.
Alarm does not sound.	Alarm is not activated, volume is too low, or incorrect alarm time set.	Ensure the alarm is turned on (alarm icon visible). Check alarm volume settings. Verify the alarm time is correctly set.
Night light is not working.	Night light is off or timed function requires external power.	Press the 'LIGHT' button to turn it on. If using the timed function, ensure the device is connected to an external power supply.
Buttons are unresponsive.	Temporary software glitch.	Try resetting the device by pressing and holding the 'SET' button for several seconds, or by allowing the battery to fully discharge and then recharging.

SPECIFICATIONS

- **Brand:** Juboos
- **Model Number:** 536
- **Display Type:** Digital
- **Special Feature:** Alarm, Snooze, Night Light, Countdown Timer
- **Product Dimensions:** 2.76"W x 3.94"H (7.0cm W x 10.0cm H)
- **Shape:** Round
- **Frame Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Batteries Included:** No (Features a built-in rechargeable battery)
- **Power Source:** USB-C (Cable included, adapter not included)
- **Night Light:** 8 RGB Colors, Adjustable Brightness, Timed Function (up to 120 minutes)
- **Alarm Tones:** 6 selectable melodies
- **Time Format:** 12/24 Hour System

WARRANTY INFORMATION

Juboos products are covered by a limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims. This warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear. For specific warranty terms and conditions, please refer to the product packaging or contact customer support.

CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your Juboos Model 536 Digital Kids Alarm Clock, please contact our customer support team. For the most up-to-date contact information, please visit the official Juboos website or refer to the contact details provided on your product packaging.

When contacting support, please be prepared to provide your product model number (536) and a detailed description of the issue.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question