

Manuals.plus /

› Audster /

› Audster AUD-S410 Portable Bluetooth Speaker Alarm Clock User Manual

Audster AUD-S410

Audster Portable Bluetooth Speaker Alarm Clock

Model: AUD-S410

Brand: Audster

INTRODUCTION

This manual provides instructions for the Audster Portable Rechargeable Bluetooth Speaker Alarm Clock (Model AUD-S410). This device combines a Bluetooth speaker, FM radio, alarm clock, and multi-color LED night light into a single portable unit. Please read this manual thoroughly before use to ensure proper operation and to maximize your experience.

PRODUCT OVERVIEW & COMPONENTS

Familiarize yourself with the device's layout and controls.



Image: Front Panel Controls. This image displays the front of the Audster AUD-S410, highlighting the digital display and control buttons. Labels indicate 'ALARM SET', 'MODE', 'TIMER', 'BACK', 'FORWARD', and 'LIGHT OPTIONS'. Dimensions are also shown: Width 5.43 inches, Height 1.81 inches, Depth 2.65 inches.

Product Parameter



Image: Rear Panel Ports. This image shows the rear of the Audster AUD-S410, detailing the AUX Input, TF Card slot, and DC 5V Type-C charging port. Metric dimensions are also provided: 138 mm width, 69 mm height, 46 mm depth.

Key Features:

- **Digital Display:** Large, easy-to-read LED display for time and settings.
- **Control Buttons:** Dedicated buttons for setting alarms, changing modes, adjusting time, and controlling LED lights.
- **Bluetooth 5.0:** For wireless audio streaming.
- **FM Radio:** Integrated tuner for local radio stations.
- **Multi-Color LED Lights:** Customizable lighting effects.
- **Rechargeable Battery:** For portable use.
- **Connectivity:** AUX Input, TF Card slot, USB Type-C charging port.

SETUP

1. Charging the Device

Before initial use, fully charge the device. Connect the provided USB Type-C cable to the DC 5V charging port on the back of the unit and plug the other end into a compatible USB power adapter (not included).

- The charging indicator will illuminate during charging.
- The indicator will turn off or change color once fully charged.

2. Power On/Off

Press and hold the Power button (often integrated with the Mode button) to turn the device ON or OFF.

3. Setting the Time

In time display mode:

1. Press the 'SET' button to enter time setting mode. The hour digits will flash.
2. Use the 'BACK' or 'FORWARD' buttons to adjust the hour.
3. Press 'SET' again to move to minute setting. The minute digits will flash.
4. Use the 'BACK' or 'FORWARD' buttons to adjust the minutes.
5. Press 'SET' a third time to confirm and exit time setting.
6. To switch between 12-hour and 24-hour format, press the '12H/24H' button (if available, or cycle through with 'SET' button).

OPERATING INSTRUCTIONS

1. Bluetooth Speaker Mode

1. Turn on the device.
2. Press the 'MODE' button until 'BT' (Bluetooth) appears on the display. The device will enter pairing mode, indicated by a flashing Bluetooth icon or sound.
3. On your mobile device, enable Bluetooth and search for available devices.
4. Select 'AUD-S410' from the list. Once connected, a confirmation sound will play, and the Bluetooth icon will stop flashing.
5. You can now play audio from your connected device. Use the 'BACK' and 'FORWARD' buttons on the speaker to skip tracks, and the volume controls on your mobile device to adjust volume.

2. FM Radio Mode

1. Turn on the device.
2. Press the 'MODE' button until 'FM' appears on the display.
3. To auto-scan and save stations: Press and hold the 'MODE' button (or a dedicated scan button if available). The device will scan for and save all available FM stations.
4. To manually tune or switch stations: Use the 'BACK' or 'FORWARD' buttons to navigate through saved stations or fine-tune the frequency.

3. Alarm Clock Function

The device supports setting multiple alarms.

1. Press the 'ALARM SET' button (often labeled with an alarm icon). The alarm time will flash.
2. Use the 'BACK' or 'FORWARD' buttons to adjust the alarm hour.
3. Press 'ALARM SET' again to move to minute setting.
4. Use the 'BACK' or 'FORWARD' buttons to adjust the alarm minutes.
5. Press 'ALARM SET' again to select the alarm sound (if applicable) or to enable/disable the alarm.
6. Press 'ALARM SET' a final time to confirm and exit.
7. To snooze: When the alarm sounds, press any button (except power) to activate snooze. The alarm will sound again after a few minutes.
8. To turn off the alarm: Press and hold the 'ALARM SET' button when the alarm is sounding, or turn off

the alarm in the settings.

4. LED Light Modes

Customize the ambiance with the integrated multi-color LED lights.

1. Press the 'LED' or 'LIGHT OPTIONS' button to cycle through different light modes and colors.
2. Continue pressing to find your desired light effect or to turn the lights off.



Image: Device with LED Lights. This image shows the Audster AUD-S410 displaying the time '08:00' with its vibrant multi-color LED lights illuminated around the display, creating a colorful glow.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Battery is depleted.	Connect the device to a power source using the USB Type-C cable and allow it to charge.
Bluetooth pairing fails.	Device is not in pairing mode; Bluetooth is off on mobile device; device is too far from mobile device.	Ensure the speaker is in Bluetooth mode and discoverable. Check Bluetooth settings on your mobile device. Move the devices closer together.
No sound from speaker.	Volume is too low; device is not connected; incorrect mode selected.	Increase volume on both the speaker and the connected device. Verify Bluetooth connection or correct mode (FM, AUX, TF).
FM radio reception is poor.	Weak signal; interference.	Reposition the device to improve signal reception. Avoid placing near other electronic devices that may cause interference.
Time resets to 12:00 or does not hold correct time.	Internal battery for timekeeping is low or faulty; power interruption.	Ensure the main battery is charged. If the issue persists after charging, the internal timekeeping mechanism may require service.
Alarm does not sound.	Alarm is not set or is disabled; volume is too low.	Verify alarm settings and ensure it is enabled. Check the alarm volume.

SPECIFICATIONS

- **Brand:** Audster
- **Model Number:** AUD-S410
- **Color:** Black
- **Display Type:** Digital LED
- **Connectivity Technology:** Bluetooth 5.0
- **Special Features:** Bluetooth Speaker, Alarm Clock, Multi-Color LED Lights, FM Radio, Rechargeable, Portable
- **Power Source:** Battery Powered (Rechargeable)
- **Product Dimensions (W x H):** 5.43" x 1.81" (138mm x 69mm)
- **Item Weight:** Approximately 1 Pound
- **Material:** Plastic
- **UPC:** 738676659856

WARRANTY INFORMATION

The manufacturer's warranty description for this product states: **None**.

CUSTOMER SUPPORT

For further assistance or inquiries, please visit the official Audster store:

Visit the Audster Store on Amazon

