

KXAITO 8128

KXAITO Digital Sports Watch Model 8128 User Manual

Model: 8128

INTRODUCTION

Thank you for choosing the KXAITO Digital Sports Watch, Model 8128. This manual provides detailed instructions for the proper setup, operation, and maintenance of your watch. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

This watch features a digital display with LED night light, 5ATM water resistance, and multiple functions including alarm, chronograph, stopwatch, countdown timer, and dual time display.

PRODUCT OVERVIEW

The KXAITO Digital Sports Watch is designed for durability and functionality. It features a square 44mm case, a shatterproof plexiglass mirror, and a comfortable silica gel band.

Watch Components



Image: Watch with labeled buttons (Light, Mode, Start, Reset).

- **Light Button:** Activates the LED night light for visibility in low-light conditions.
- **Mode Button:** Cycles through different watch modes (Time, Alarm, Stopwatch, Countdown, Dual Time).

- **Start Button:** Used to start/stop functions in various modes (e.g., stopwatch, setting values).
- **Reset Button:** Used to reset values or confirm settings in various modes.

Key Features

- **Digital Display with LED Night Light:** Large, easy-to-read display with one-key cold light activation.
- **5ATM Water Resistant:** Suitable for washing hands, rain, and shallow water activities.
- **Multi-functional:** Includes alarm, chronograph, stopwatch, countdown timer, calendar, dual time, and 12/24 hour format.
- **Durable Construction:** Square 44mm case, plexiglass mirror, alloy case, stainless steel back, and silica gel band.
- **Lightweight and Comfortable:** Weighs 47 grams with an anti-slip button design.

SETUP

Initial Time and Date Setting

1. In Timekeeping Mode, press the **Mode** button repeatedly until the seconds begin to flash. This indicates you are in setting mode.
2. Press the **Start** button to cycle through the settings: Seconds → Hour → Minute → Year → Month → Day.
3. Use the **Reset** button to adjust the flashing value. Hold the **Reset** button to increase values rapidly.
4. Once all settings are adjusted, press the **Mode** button to exit the setting mode and return to Timekeeping Mode.
5. To switch between 12-hour and 24-hour format, press the **Reset** button while the hour is flashing.





Image: KXAITO Digital Sports Watch showing the time display.

OPERATING INSTRUCTIONS

Mode Selection

Press the **Mode** button to cycle through the following modes:

- Timekeeping Mode (default display)
- Alarm Mode
- Stopwatch Mode
- Countdown Timer Mode
- Dual Time Mode

Using the LED Night Light

Press the **Light** button (top left) to illuminate the display. The light will stay on for a few seconds, providing clear visibility in dark environments.

LED NIGHT LIGHT DISPLAY

ONE KEY TO TURN ON THE COLD LIGHT DIGITAL DISPLAY MODE SOFT LIGHT IS NOT BLINDING, 24 HOURS FOR YOU TO ACCURATELY READ THE TIME



Image: The watch display illuminated by the LED night light.

Setting and Using the Alarm

1. From Timekeeping Mode, press the **Mode** button until "AL" or the alarm time is displayed.
2. Press the **Start** button to select the hour or minute to set. The selected value will flash.
3. Use the **Reset** button to adjust the flashing hour or minute.
4. Press the **Mode** button to confirm and exit alarm setting.
5. To turn the alarm ON/OFF, press the **Start** button in Alarm Mode. An alarm icon will appear/disappear on the display.
6. To activate the hourly chime, press the **Reset** button in Alarm Mode. A chime icon will appear/disappear.

Using the Stopwatch (Chronograph)

1. From Timekeeping Mode, press the **Mode** button until "ST" or "STOP" is displayed.
2. Press the **Start** button to begin timing.
3. Press the **Start** button again to pause timing.

4. Press the **Reset** button to reset the stopwatch to zero.
5. To resume timing after pausing, press the **Start** button.

Using the Countdown Timer

1. From Timekeeping Mode, press the **Mode** button until "TR" or "TIMER" is displayed.
2. To set the countdown time, press and hold the **Start** button until the hour/minute flashes.
3. Use the **Reset** button to adjust the flashing value (hour, then minute).
4. Press the **Start** button to move between hour and minute settings.
5. Press the **Mode** button to confirm the countdown time.
6. Press the **Start** button to begin the countdown.
7. Press the **Start** button again to pause the countdown.
8. Press the **Reset** button to reset the countdown to the set time.

Dual Time Function

The dual time function allows you to keep track of a second time zone.

1. From Timekeeping Mode, press the **Mode** button until "DT" or "DUAL" is displayed.
2. Press and hold the **Start** button until the hour/minute flashes.
3. Use the **Reset** button to adjust the flashing value (hour, then minute).
4. Press the **Start** button to move between hour and minute settings.
5. Press the **Mode** button to confirm the dual time setting.

MAINTENANCE

Water Resistance (5ATM)

Your KXAUTO watch is 5ATM (50 meters) water resistant. This means it is suitable for daily use and can withstand splashes, rain, and brief immersion in shallow water. It is **not** recommended for showering with hot water, diving, or prolonged underwater activities. Do not operate buttons while the watch is wet or submerged.

5ATM METER WATERPROOF

WASH HANDS, FACE, AND RAIN CAN BE WORN WITH
CONFIDENCE, WATERPROOF AND FEARLESS



Image: Watch demonstrating its 5ATM water resistance.

Cleaning Your Watch

To clean your watch, wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the watch case or band. Ensure the watch is dry before storing.

Battery Information

The watch is powered by 1 Nonstandard Battery (included). When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure water resistance is maintained.

TROUBLESHOOTING

Display is Blank or Dim

- Check the battery. A dim or blank display often indicates a low battery.
- Ensure the watch has not been exposed to extreme temperatures.

Buttons are Unresponsive

- Ensure the watch is not wet. Water can interfere with button operation.
- Try pressing the buttons firmly.
- If the issue persists, a battery replacement might be necessary.

Time is Incorrect

- Refer to the "Initial Time and Date Setting" section to re-adjust the time.
- Ensure the 12/24 hour format is set correctly for your preference.

Water Inside the Watch

- If water or condensation appears inside the watch, stop using it immediately.
- This indicates a breach in the water resistance seal. Seek professional repair to prevent further damage.
- Avoid operating buttons underwater or when the watch is wet.

SPECIFICATIONS

Feature	Detail
Model Name	8128
Brand	KXAITO
Display Type	Digital
Case Material	Plastic
Band Material	Silica Gel
Case Diameter	44mm (1.73 Inches)
Case Thickness	1.5 cm (0.59 Inches)
Band Width	21mm (0.82 Inches)
Item Weight	47 grams (1.66 Ounces)
Water Resistance Depth	5ATM (50 Meters / 164 Feet)
Movement Type	Electronic
Battery	1 Nonstandard Battery (included)
Crystal Type	Plexiglass
Clasp Type	Buckle

PRODUCT SIZE PARAMETER



Image: Product size parameters and dimensions.

WARRANTY AND SUPPORT

Warranty Information

This KXAITO Digital Sports Watch comes with a **Limited Manufacturer Warranty**. Please retain your proof of purchase for any warranty claims. The warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For further assistance, technical support, or warranty inquiries, please contact KXAITO customer service. Refer to the product packaging or the official KXAITO website for the most current contact information.

You can also visit the KXAITO Store on Amazon for more product information: [KXAITO Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GJ59M99R>

More documents and user manuals: <https://manuals.plus/>