



[Manuals.plus](#) /

> [AIRMSEN](#) /

> AIRMSEN 6.4QT Glass Air Fryer Instruction Manual

AIRMSEN PAF-6003BD

AIRMSEN 6.4QT Glass Air Fryer Instruction Manual

Model: PAF-6003BD

INTRODUCTION

Thank you for choosing the AIRMSEN 6.4QT Glass Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods with less oil, utilizing 360° hot air circulation for even and crispy results. Please read this manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.



Image: The AIRMOSEN 6.4QT Glass Air Fryer in operation, showing steaks cooking inside the transparent glass basket with visible heating elements and control panel.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the cord, plugs, or the appliance housing in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The appliance automatically pauses when the lid is lifted for added safety. Ensure the lid is securely closed

before resuming operation.

- Anti-scalding handles and a thick, heat-insulating base are designed to protect hands and countertops from burns. Always use caution.
- Do not place the appliance against a wall or against other appliances. Leave at least 4 inches of free space on the back and sides and 4 inches of free space above the appliance.
- Do not place anything on top of the appliance.
- Do not use the appliance for any purpose other than described in this manual.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

PRODUCT COMPONENTS

The AIRMSEN 6.4QT Glass Air Fryer consists of the following main parts:

- **Control Panel:** Located on the lid, with digital display and touch controls for time, temperature, and preset modes.
- **Lid Assembly:** Contains the heating element, fan, and control panel.
- **Glass Basket:** A 6.4-quart capacity, food-grade borosilicate glass container for cooking.
- **Cooking Rack/Tray:** Inserted into the glass basket to elevate food for optimal air circulation.
- **Base Unit:** Provides stability and houses the main power connection.

6.4QT Large Capacity

Spacious square design for family-size cooking



Image: The AIRMSSEN 6.4QT Glass Air Fryer showing its overall dimensions (13.78 in height, 12.77 in width, 10.63 in depth) and the 6.4QT capacity, capable of holding a 5 lb chicken, 4 chicken breasts, a 7-inch pizza, or 2 lb french fries.

SETUP

1. **Unpack:** Carefully remove all packaging materials and any promotional labels or stickers from the air fryer.
2. **Clean:** Before first use, wash the glass basket and cooking rack with warm, soapy water. Wipe the lid assembly and base unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is adequate space (at least 4 inches) around the appliance for proper ventilation. Do not place it near flammable materials or heat sources.
4. **Assemble:** Place the cooking rack inside the glass basket. Position the lid assembly securely onto the glass basket.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet. The appliance is now ready for use.

OPERATING INSTRUCTIONS

Multiple Presets & Customization

Adjust Temp & Time **105-400°F | 1-60 min**



Image: Close-up of the AIRMSEN Glass Air Fryer's digital control panel, showing the display, power button, temperature and time adjustment buttons, and four preset icons for Cake, Fries, Steak, and Chicken.

The control panel features a digital display and touch-sensitive buttons for easy operation.

- **Power Button:** Turns the appliance on/off and starts/pauses cooking.
- **Temperature (TEMP) Button:** Adjusts the cooking temperature (105-400°F).
- **Time (TIME) Button:** Adjusts the cooking time (1-60 minutes).
- **Preset Modes:** Icons for Chicken, Fries, Cake, and Steak. Selecting a preset automatically sets a recommended time and temperature.
- **+/- Buttons:** Used to increase or decrease time and temperature settings.

General Operation

1. **Preparation:** Place food on the cooking rack inside the glass basket. Do not overfill the basket to allow for proper air circulation.
2. **Power On:** Plug in the air fryer. The display will illuminate. Press the Power button to enter standby mode.

3. Set Time and Temperature (Manual Mode):

- Press the TEMP button, then use the +/- buttons to set the desired temperature.
- Press the TIME button, then use the +/- buttons to set the desired cooking time.

4. **Use Preset Modes:** Alternatively, select one of the four preset icons (Chicken, Fries, Cake, Steak). The appliance will automatically set a recommended time and temperature for that food type. You can adjust these settings manually after selecting a preset if needed.

5. **Start Cooking:** Press the Power button again to start the cooking cycle. The fan and heating element will activate.

6. **Pause Function:** The air fryer will automatically pause operation if the lid is lifted during cooking. Close the lid to resume cooking.



Image: A woman demonstrating the lid-open pause feature of the AIRMSEN Glass Air Fryer. The appliance automatically pauses when the lid is lifted and restarts when closed, enhancing safety during cooking.

7. **Shaking/Tossing Food:** For even cooking, especially with smaller items like fries, it is recommended to shake or toss the food halfway through the cooking time. Carefully lift the lid, remove the basket, shake, and then return the basket and close the lid.

8. **End of Cooking:** Once the set time has elapsed, the air fryer will beep and automatically shut off.

9. **Remove Food:** Carefully remove the cooked food using heat-resistant tongs or utensils. Be cautious of hot steam.
10. **Power Off:** Unplug the appliance from the wall outlet after use.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your AIRMSEN Air Fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Glass Basket and Cooking Rack:** The glass basket and cooking rack are dishwasher-safe. Alternatively, wash them with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely. The glass material is scratch-resistant and resists oil buildup.



Image: A woman easily placing the glass basket and cooking rack of the AIRMSEN Glass Air Fryer into a dishwasher, highlighting their dishwasher-safe design for convenient cleaning.

3. **Lid Assembly and Base Unit:** Wipe the exterior of the lid assembly and base unit with a damp cloth. Do not immerse these parts in water or any other liquid. For stubborn stains, use a mild detergent.
4. **Interior of Lid:** Gently wipe the interior of the lid, including the heating element and fan area, with a damp cloth to remove any food residue. Ensure no water drips into the electrical components.

5. **Storage:** Ensure all parts are clean and dry before storing. Store the air fryer in a cool, dry place. Its compact design allows for convenient storage in cabinets or on countertops.

TROUBLESHOOTING

If you encounter any issues with your AIRMSEN Glass Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Power outlet malfunction.	Ensure the power cord is securely plugged into a working electrical outlet. Try a different outlet.
Food is not cooked evenly.	Basket is overfilled. Food not shaken/tossed.	Do not overfill the glass basket. Cook in smaller batches if necessary. Shake or toss food halfway through cooking for even results.
Food is not crispy.	Temperature too low or time too short. Too much moisture in food.	Increase temperature or cooking time. Pat food dry before air frying. A light coating of oil can also help.
White smoke coming from the appliance.	Grease residue from previous use. High-fat food cooking.	Clean the glass basket and heating element thoroughly after each use. This is normal for high-fat foods; ensure proper ventilation.
Appliance pauses unexpectedly.	Lid was lifted during operation.	This is a safety feature. Close the lid securely to resume cooking.

SPECIFICATIONS

- **Model Name:** PAF-6003BD
- **Capacity:** 6.4 Quarts (6.5 Quarts listed in some specifications)
- **Power:** 1600W (Output Wattage: 1300 Watts)
- **Voltage:** 110 Volts
- **Temperature Range:** 105°F - 400°F
- **Timer Range:** 1 - 60 minutes
- **Control Method:** Push Button / Touch Control
- **Material:** Glass (Borosilicate)
- **Product Dimensions (D x W x H):** 11" x 13" x 14"
- **Item Weight:** 11 Pounds
- **Special Features:** Timer, Automatic Pause on Lid Lift, Dishwasher-Safe Components

WARRANTY AND SUPPORT

The AIRMSEN 6.4QT Glass Air Fryer is backed by a **1-year warranty** from the date of purchase. This warranty

covers manufacturing defects under normal household use.

For warranty claims, technical support, or any questions regarding your product, please contact AIRMSEN customer support. Please have your model number (PAF-6003BD) and proof of purchase ready when contacting support. Contact information can typically be found on the AIRMSEN official website or through your retailer's customer service portal.