

[Manuals.plus](#) /

› [Hisense](#) /

› Hisense 50S7SG CanvasTV Series 4K UHD Google Smart Art TV Instruction Manual

Hisense 50S7SG

Hisense 50S7SG CanvasTV Series 4K UHD Google Smart Art TV Instruction Manual

INTRODUCTION

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your Hisense 50S7SG CanvasTV Series 4K UHD Google Smart Art TV. The CanvasTV is designed to seamlessly integrate art and entertainment into your living space, featuring a Hi-Matte Display to reduce glare, an Art Mode for displaying digital artwork, and an UltraSlim Wall Mount for a flush installation. Please read this manual thoroughly before using your television to ensure proper and safe operation.



Figure 1: Hisense 50S7SG CanvasTV showcasing digital art in a living room setting.

WHAT'S IN THE BOX

Carefully unpack your Hisense CanvasTV and ensure all components are present. The package should contain the following items:

- Hisense 50S7SG CanvasTV Unit
- Power Cable
- Remote Control
- TV Stand (if not wall-mounting)
- Quick Start Guide (QSG)
- UltraSlim Wall Mount Kit
- Teak Frame (for aesthetic enhancement)

SETUP

1. Unpacking and Placement

Remove the TV from its packaging. It is recommended to have two people for safe handling. Choose a suitable location for your TV, considering viewing angles, power access, and ventilation. Ensure the surface is stable if using the stand, or the wall is structurally sound if wall-mounting.

2. Stand Installation (Optional)

If you choose not to wall-mount, attach the included TV stand according to the instructions in the Quick Start Guide. Ensure all screws are securely fastened.

3. UltraSlim Wall Mount and Teak Frame Installation

The CanvasTV comes with an UltraSlim Wall Mount designed for a flush, art-like appearance. Follow the detailed instructions provided with the wall mount kit for secure installation. Once mounted, the magnetic Teak Frame can be easily attached to the TV's edges to complete the aesthetic.

Video 1: This video demonstrates the installation process of the Hisense CanvasTV, including mounting it on the wall and initial setup steps.

4. Initial Power On and Network Connection

Connect the power cable to the TV and a power outlet. Press the power button on the remote control. Follow the on-screen prompts to select your language, connect to your Wi-Fi network, and complete the initial Google TV setup.

Video 2: This video shows the initial power-on sequence and the process of customizing remote control buttons for quick access to applications.

OPERATING

1. Basic Controls

Use the included remote control to navigate the TV's interface. The remote features dedicated buttons for power, volume, channel selection, input source, and direct access to streaming services and Art Mode.

2. Google TV Interface


Your CanvasTV runs on Google TV, providing a centralized platform for streaming content from various apps and services. The interface offers personalized recommendations and voice control via Google Assistant.

Video 3: This video provides an overview of the Google TV interface, demonstrating navigation through apps and content.

3. Art Mode


Transform your TV into a digital art display when not in use. Access Art Mode to browse over 1,000 free artworks across various styles or upload your own photos via USB or the Art Gallery app. You can set up slideshows or select individual pieces to display.

Art Gallery



Bring the gallery home with 1,000+ free artworks

Show off your taste in art when you're not watching TV. Select a single picture or create a slideshow that matches your mood.



Memories on demand

Share all your favorite photos on the big screen by connecting a USB or use the Art Gallery app to upload your photos.

Figure 2: The Art Gallery feature allows selection from a wide range of digital artworks.

Video 4: This video showcases the Art Mode functionality, demonstrating how to browse and select different art pieces for display.

4. Hi-Matte Display

The Hi-Matte Display features an anti-glare panel that significantly reduces reflections and glare from ambient light sources, ensuring a clear and immersive viewing experience for both TV content and digital art.



Figure 3: The Hi-Matte Display minimizes reflections, enhancing the visual quality of displayed content.

5. AI Ambient Light Sensor

The built-in AI Ambient Light Sensor automatically detects the room's lighting conditions and adjusts the TV's brightness and color temperature accordingly. This ensures optimal picture quality and a natural viewing experience throughout the day.




Figure 4: The AI Ambient Light Sensor dynamically adjusts display settings for optimal viewing.

6. Motion Detector

The Motion Detector feature activates the display when movement is detected in the room and turns it off when no one is

present. This conserves energy and ensures the Art Mode is only active when appreciated.




Figure 5: The Motion Detector intelligently manages display activity to save energy.

7. Sound Features

Experience immersive audio with 2.0.2 Multi-Dimensional Sound and DTS Virtual:X technology. This system delivers room-filling sound with virtual height effects, enhancing your movie, gaming, and music experiences.




Figure 6: The 2.0.2 Multi-Dimensional Sound system provides an immersive audio experience.

MAINTENANCE

1. Cleaning the Screen and Frame

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a screen-specific cleaning solution. Avoid harsh chemicals. For the frame, use a dry, soft cloth to remove dust.

2. Software Updates

Ensure your TV's software is up-to-date for optimal performance and security. The TV will typically prompt you for available updates. You can also manually check for updates in the settings menu.

TROUBLESHOOTING

If you encounter issues with your Hisense CanvasTV, refer to the following common problems and solutions:

Problem	Possible Solution
No Power	Check if the power cable is securely connected to both the TV and the power outlet. Ensure the outlet is functional.
No Picture, but Sound is Present	Verify the input source is correctly selected. Check external device connections (HDMI, etc.).
No Sound, but Picture is Present	Check the volume level and mute status. Ensure external audio devices are properly connected and configured.
Remote Control Not Working	Replace the batteries. Ensure there are no obstructions between the remote and the TV. Re-pair the remote if necessary.
Wi-Fi Connection Issues	Restart your router and modem. Check Wi-Fi settings on the TV and ensure the password is correct.

SPECIFICATIONS

Below are the technical specifications for the Hisense 50S7SG CanvasTV:

Feature	Detail
Screen Size	50 inches
Brand	Hisense
Display Technology	LED, QLED
Resolution	4K UHD
Refresh Rate	60 Hz
Special Features	Art Mode, Game Mode, Hi-Matte Display, AI Ambient Light Sensor, Motion Detector
Included Components	TV, Power Cable, QSG, Remote Control, Stand, UltraSlim Wall Mount
Connectivity	Bluetooth 5.4, Ethernet, HDMI (4 ports), USB (2 ports), Wi-Fi
Product Dimensions (DxWxH)	1.1"D x 43.8"W x 25.7"H
Item Weight	31.7 pounds (with stand), 29.1 pounds (without stand)
HDR Format Supported	Dolby Vision, Dolby Vision IQ, HDR10+, HDR10, HLG
Audio Output Mode	Surround (2.0.2 channel with DTS Virtual:X)
Operating System	Google TV

Feature	Detail
VESA Mount Standard	300 x 200 mm

WARRANTY AND SUPPORT

Warranty Information

Your Hisense 50S7SG CanvasTV is covered by a 2-year manufacturer's warranty. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or warranty service, please contact Hisense customer support. Refer to the Quick Start Guide or the official Hisense website for the most current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GRGTZKHT>

More documents and user manuals: <https://manuals.plus/>