



[Manuals.plus](#) /

> [X-PRO](#) /

> X-PRO Bali 50cc Gas Moped User Manual

X-PRO MC-D001

X-PRO Bali 50cc Gas Moped User Manual

Model: MC-D001

1. INTRODUCTION

Welcome to the X-PRO Bali 50cc Gas Moped user manual. This guide provides essential information for the safe operation, maintenance, and troubleshooting of your new moped. Please read this manual thoroughly before operating the vehicle to ensure proper use and to maximize its lifespan.

1.1 Safety Information

WARNING: Operating a moped can be dangerous. Always wear a helmet and appropriate safety gear. Follow all local traffic laws and regulations.

Familiarize yourself with all controls and features before riding. Never operate the moped under the influence of alcohol or drugs. Regular maintenance is crucial for safe operation.

Important Note: The Manufacturer Statement of Origin (MSO) and Bill of Sale paperwork will be sent separately. These documents are required for vehicle registration.

2. PRODUCT OVERVIEW

The X-PRO Bali 50cc Gas Moped is designed for urban commuting, offering a blend of efficiency and ease of use. It features a reliable 4-stroke engine, automatic transmission, and essential safety components.

2.1 Key Features

- **Engine:** 49.5cc air-cooled 4-stroke engine for smooth power and fuel efficiency.
- **Starting System:** Convenient electric start with a backup kick-start.
- **Transmission:** CVT automatic transmission for simple, twist-and-go operation.
- **Braking:** Front disc brake and rear drum brake for reliable stopping power.
- **Tires:** 10-inch DOT-approved tires for solid traction.
- **Lighting:** LED lights for enhanced visibility.

- **Storage:** Built-in under-seat storage compartment.

2.2 Components

Below are images illustrating key components and features of the X-PRO Bali 50cc Moped.



Figure 2.1: The X-PRO Bali 50cc Gas Moped, showcasing its design and street-legal features. Max load capacity is 330 lbs.

URBAN FREEDOM. EVERYDAY CONFIDENCE.

50cc Gas Moped Scooter
Your reliable ride for city life.



FUEL EFFICIENT
Save more on every ride



50CC POWER
Smooth, responsive
city performance



RELIABLE & DURABLE
Built for daily commutes
and long-lasting use



BRIGHT LED LIGHTS
See and be seen
day and night



COMPACT & AGILE
Easy to park, easy to
maneuver in traffic



PERFECT FOR
CITY COMMUTES



LOW RUNNING COST
HIGH SAVINGS



ECO-FRIENDLY
50CC ENGINE



LOW MAINTENANCE
EASY TO OWN

Figure 2.2: Key features of the moped, highlighting its suitability for city life with fuel efficiency, responsive power, and bright LED lights.



Figure 2.3: Detailed view of the moped's starting systems (electric and kick start) and the front disc brake, emphasizing safety and convenience.




Figure 2.4: Various detailed views of the moped's features, including the LED headlight for night visibility, instrument panel, cup holder, comfortable seat, storage, and front disc brake.

3. SETUP AND ASSEMBLY

The X-PRO Bali 50cc Moped requires some assembly upon arrival. This typically includes attaching the handlebar, wheels, brakes, hub odometer counter, and connecting the battery. Specific steps may vary slightly by model.

3.1 Assembly Steps

1. **Uncrating:** Carefully remove the moped from its shipping crate.
2. **Handlebar Installation:** Securely attach the handlebar. Ensure all bolts are tightened to the manufacturer's specifications.
3. **Wheel Installation:** Install the front wheel, ensuring the axle is properly seated and secured.

4. **Brake Connection:** Connect and adjust the brake cables/lines. Test brake function immediately after connection.
5. **Battery Connection:** Connect the battery terminals. Ensure correct polarity (red to positive, black to negative).
6. **Initial Fluid Checks:** Verify engine oil level and add fuel.

3.2 Assembly Video Guide

For a visual guide on the assembly process, please refer to the official X-PRO Bali 50 Moped Assembly Video below.

Video 3.1: Official X-PRO Bali 50 Moped Assembly Video. This video provides a step-by-step visual demonstration of the assembly process, including uncrating, handlebar, wheel, and battery installation.

4. OPERATING INSTRUCTIONS

Understanding how to properly operate your X-PRO Bali 50cc Moped is crucial for a safe and enjoyable riding experience.

4.1 Pre-Ride Checks

- **Fuel Level:** Ensure sufficient fuel is in the tank.
- **Tire Pressure:** Check tire pressure before each ride. Refer to specifications for correct PSI.
- **Brakes:** Test front and rear brakes for proper function and responsiveness.
- **Lights:** Verify headlights, taillights, and turn signals are working.
- **Mirrors:** Adjust mirrors for optimal rear visibility.

4.2 Starting the Engine

1. **Electric Start:** Insert the key into the ignition and turn it to the 'ON' position. Squeeze the brake lever (either front or rear) and press the electric start button.
2. **Kick Start (Backup):** If the electric start fails, turn the key to 'ON'. Extend the kick-start lever and push down firmly and smoothly until the engine starts.

4.3 Riding the Moped

The X-PRO Bali 50cc features a CVT automatic transmission, making it easy to ride.

- **Acceleration:** Gently twist the throttle grip towards you to accelerate. The CVT system will automatically adjust the gear ratio for smooth acceleration.
- **Braking:** To slow down or stop, gradually apply both the front (right lever) and rear (left lever) brakes simultaneously. Avoid sudden, hard braking, especially at high speeds.
- **Turning:** Lean into turns and use counter-steering techniques for stability.

CVT AUTOMATIC TRANSMISSION

Smooth, No-Shift Riding

01 **Twist-and-Go Simplicity**

 No clutch, no shift lever. Starting, acceleration, and deceleration happen automatically. Easy for beginners and stress-free in traffic.

02 **Smooth & Quiet Ride**

 Seamless acceleration with no gear-shift jerkiness. Belt-driven CVT helps reduce noise and vibration for a more comfortable daily ride.

03 **Fuel-Saving & Low Maintenance**

 Keeps the engine in an efficient RPM range for economical commuting. Low-maintenance belt drive means less routine upkeep.



BELT-DRIVEN PERFORMANCE



EFFORTLESS ACCELERATION



RELIABLE & DURABLE

Figure 4.1: Explanation of the CVT Automatic Transmission, emphasizing its ease of use for beginners and smooth, quiet operation.

5. MAINTENANCE

Regular maintenance is essential to keep your X-PRO Bali 50cc Moped in optimal condition and ensure its longevity and safe operation.

5.1 Engine Maintenance

- **Oil Changes:** Perform the first oil change after the initial 300 miles (500 km) or 1 month of operation. Subsequent oil changes should be done every 1,000 miles (1,600 km) or 6 months, whichever comes first. Use recommended 4-stroke engine oil.
- **Air Filter:** Inspect and clean the air filter every 1,000 miles (1,600 km) or more frequently in dusty conditions. Replace if damaged.
- **Spark Plug:** Inspect the spark plug every 2,000 miles (3,200 km) and replace if necessary.

5.2 Brake System

- **Brake Pad Wear:** Regularly check the wear indicators on the front disc brake pads and rear drum brake shoes. Replace them before they reach their wear limits.
- **Brake Fluid:** For the front disc brake, check the brake fluid level periodically. Replace brake fluid according to the maintenance schedule in a more detailed service manual.
- **Brake Adjustment:** Ensure proper free play in the brake levers. Adjust if necessary.

5.3 Tires

- **Tire Pressure:** Maintain correct tire pressure as specified in the manual or on the tire sidewall. Incorrect pressure affects handling and tire life.
- **Tread Wear:** Inspect tire tread for wear and damage. Replace tires when the tread wear indicators are visible.

5.4 Storage

The under-seat storage compartment provides convenient space for small items. Ensure items are securely placed to prevent movement during operation.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your moped. For problems not listed here, consult a qualified technician.

Problem	Possible Cause	Solution
Engine does not start (Electric Start)	Low battery, loose battery connection, no fuel, kill switch engaged, brake lever not squeezed.	Check battery connections, charge battery, add fuel, disengage kill switch, ensure brake lever is squeezed. Try kick start.
Engine does not start (Kick Start)	No fuel, spark plug issue, engine flooded.	Add fuel, check spark plug, wait a few minutes and try again without throttle.
Poor acceleration/loss of power	Low fuel, clogged air filter, spark plug issue, CVT belt wear.	Check fuel, clean/replace air filter, inspect spark plug, consult technician for CVT belt.
Brakes feel spongy or ineffective	Worn brake pads/shoes, low brake fluid (front), air in brake line (front), improper adjustment.	Inspect and replace worn components, check/add brake fluid, bleed brake system (front), adjust brake cables.

7. SPECIFICATIONS

Detailed technical specifications for the X-PRO Bali 50cc Moped (Model MC-D001).

Feature	Specification
Engine Type	49.5cc Air-Cooled 4-Stroke
Transmission	CVT Automatic
Starting System	Electric Start with Kick Start Backup
Brake Style	Front Disc Brake, Rear Drum Brake
Wheel Size	10 Inches
Max Weight Limit	330 Pounds
Product Dimensions (L x W x H)	71.6" x 26" x 42" (181.9cm x 66cm x 106.7cm)
Item Weight	280 Pounds
Frame Material	Steel/Aluminum Alloy
Special Features	LED Lights, Street Legal



Figure 7.1: Detailed product dimensions of the X-PRO Bali 50cc Moped.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The X-PRO Bali 50cc Moped comes with a **90-day warranty against manufacturer defects**. This limited warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, parts inquiries, or warranty claims, please contact X-PRO customer support. Refer to the contact information provided with your purchase documentation or visit the official X-PRO website for support details.

