

[Manuals.plus](#) /

› [NEWBULIG](#) /

› NEWBULIG 4.7Qt Glass Air Fryer Instruction Manual (Model AH-KZG4510-45BK)

NEWBULIG AH-KZG4510-45BK

NEWBULIG 4.7Qt Glass Air Fryer Instruction Manual

Model: AH-KZG4510-45BK

1. INTRODUCTION

Thank you for choosing the NEWBULIG 4.7Qt Glass Air Fryer. This appliance is designed to provide a healthier and more efficient way to cook your favorite meals. With its transparent glass basket and versatile functions, you can enjoy delicious results with ease. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Image 1.1: The NEWBULIG 4.7Qt Glass Air Fryer, showcasing its compact design and transparent cooking basket.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.

- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the glass basket is properly seated before operation.
- Provide adequate ventilation around the air fryer during use.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your NEWBULIG Glass Air Fryer:

- **Main Unit:** Houses the heating element and control panel.
- **Glass Cooking Basket:** Transparent, non-toxic, and provides 360° visibility during cooking.
- **Crisper Plate:** Sits inside the glass basket to allow air circulation for even cooking.
- **Handle:** For safe removal and insertion of the glass basket.
- **Control Panel:** Touch-sensitive interface for setting time, temperature, and selecting presets.

Glass Cooking Basket

360° visibility, non-toxic, healthier



Image 3.1: Close-up view of the glass cooking basket and its crisper plate, highlighting the transparent design.

4. SETUP AND FIRST USE

4.1 Unpacking

- Remove all packaging materials, stickers, and labels from the appliance.
- Check that all components are present and undamaged.

4.2 Cleaning Before First Use

- Wash the glass cooking basket and crisper plate with hot water, dish soap, and a non-abrasive sponge.
- Rinse thoroughly and dry completely.
- Wipe the inside and outside of the main unit with a damp cloth.
- Ensure all parts are completely dry before use.

4.3 Placement

- Place the air fryer on a stable, heat-resistant, and level surface.

- Ensure there is at least 4 inches (10 cm) of free space on the back and sides of the appliance, and 4 inches (10 cm) above it, to allow for proper air circulation.
- Do not place the appliance against a wall or other appliances.

5. OPERATING INSTRUCTIONS

5.1 Powering On and Basic Operation

1. Plug the power cord into a grounded wall outlet. The appliance will beep, and the display will light up briefly.
2. Place the crisper plate inside the glass cooking basket.
3. Add your ingredients to the glass cooking basket. Do not overfill.
4. Slide the glass basket back into the main unit until it clicks into place.
5. Press the Power button to turn on the display.
6. To manually set cooking parameters:
 - Press the **Temp** button to adjust the temperature (105°F to 395°F). Use the '+' and '-' buttons to change the value.
 - Press the **Time** button to adjust the cooking time (1-60 minutes). Use the '+' and '-' buttons to change the value.
7. Press the Power button again to start cooking.
8. To pause cooking, pull out the glass basket or press the Power button once. To resume, reinsert the basket or press the Power button again.
9. When cooking is complete, the air fryer will beep, and the display will show 'OFF'. Carefully remove the basket using the handle.

5.2 Using Preset Functions

The air fryer features 10 one-touch presets for common foods:



Image 5.1: The touch control panel displaying various preset icons for different food types.

1. After powering on, press the **Menu** button repeatedly to cycle through the preset icons (Wings, Fish, Bacon, Shrimp, Steak, Fries, Nuts, Cake, Vegetable, Defrost).
2. Once the desired preset is selected, the air fryer will automatically set the optimal temperature and time.
3. You can adjust the preset temperature and time manually after selection if needed.
4. Press the Power button to start cooking.

Your browser does not support the video tag.

Video 5.1: An official product video demonstrating the NEWBULIG 4.7Qt Glass Air Fryer in operation, showcasing its features and ease of use.

6. COOKING GUIDE AND TIPS

The NEWBULIG Glass Air Fryer is capable of various cooking methods including roasting, baking, dehydrating, and reheating. Here are some general tips:

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes at the desired temperature before adding

food.

- **Oil Usage:** Most foods require little to no oil. For a crispier result, lightly toss food with 1 tablespoon of oil.
- **Shaking/Tossing:** For even cooking, especially with smaller items like fries or nuggets, shake or toss the basket halfway through the cooking time. The transparent glass allows you to monitor progress without opening.
- **Batch Cooking:** Avoid overcrowding the basket. Cook in smaller batches if necessary to ensure even air circulation and crispiness.
- **Food Examples:** The air fryer is suitable for items such as roasted potatoes, grilled salmon, asparagus, corn, mushroom skewers, garlic bread, and grilled fish.



Image 6.1: A display of various healthy and delicious meals prepared using the air fryer, including roasted potatoes, grilled salmon, and mushroom skewers.

7. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your air fryer.

7.1 Daily Cleaning

1. Unplug the air fryer and allow it to cool completely before cleaning.
2. Remove the glass cooking basket and crisper plate.
3. The glass cooking basket and crisper plate are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge.
4. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. Clean the interior of the main unit with a damp cloth and mild detergent if necessary.
6. Ensure all parts are completely dry before storage or next use.

Accessories Dishwasher Safe

Glass Basket and Crisper Plate



Image 7.1: The glass cooking basket and crisper plate being placed into a dishwasher, demonstrating their dishwasher-safe feature.

7.2 Storage

Store the appliance in a cool, dry place when not in use. Ensure all components are clean and dry before storing.

8. TROUBLESHOOTING

If you encounter any issues with your air fryer, please refer to the following table:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
	Power outlet is not working.	Try plugging another appliance into the same outlet to check if it's working.
Food is not cooked evenly.	Basket is overcrowded.	Cook food in smaller batches.
	Food was not shaken/tossed.	Shake or toss the food halfway through cooking.
White smoke comes from the appliance.	Grease residue from previous use.	Clean the glass basket and crisper plate thoroughly after each use.
	Cooking fatty ingredients.	This is normal for fatty foods. Ensure the crisper plate is in place to drain excess fat.

9. SPECIFICATIONS

Feature	Detail
Model Name	AH-KZG4510-45BK
Brand	NEWBULIG
Capacity	4.7 Quarts
Output Wattage	1300 Watts
Temperature Range	105°F to 395°F
Control Method	Touch
Material	Glass
Product Dimensions (D x W x H)	8.43"D x 10.79"W x 12.91"H
Item Weight	10.8 Pounds
Special Features	Programmable, Temperature Control, Timer, Glass Basket
Dishwasher Safe Parts	Glass Basket, Crisper Plate

NEWBULIG 4.7Qt Glass Air Fryer



Image 9.1: The NEWBULIG 4.7Qt Glass Air Fryer with its key dimensions (depth, width, height) clearly indicated.

10. WARRANTY AND SUPPORT

NEWBULIG products are manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official NEWBULIG website. If you have any questions, require technical assistance, or need to report an issue, please contact NEWBULIG customer support.

Customer Support: Please refer to the contact information provided in your product packaging or on the official NEWBULIG website.