

Superun walking pad

Superun Walking Pad with 6% Incline Treadmill User Manual

Model: Walking Pad

INTRODUCTION

Thank you for choosing the Superun Walking Pad with 6% Incline. This manual provides essential information for the safe and effective use of your new walking pad. Please read it thoroughly before operation and retain it for future reference. This walking pad is designed for walking and light jogging, offering a compact and quiet fitness solution for home or office use.

SAFETY INFORMATION

The Superun Walking Pad is equipped with full-length side rails, providing support from front to back. This design ensures that stability is always within reach during your workout. Always maintain a secure grip on the side rails, especially when starting or stopping the machine, or adjusting speed. Ensure the walking pad is placed on a flat, stable surface before use. Keep children and pets away from the equipment during operation.



Image: The Superun Walking Pad features full-length side rails for continuous support, unlike other models that may offer only a front bar.

WHAT'S IN THE BOX

Upon unboxing, please verify that all components are present:

- Superun Walking Pad

- Remote Control
- Tool Kit
- User Manual (this document)
- Lubricant

SETUP

The Superun Walking Pad requires zero assembly and is ready for use right out of the box. Simply remove it from its packaging and place it on a level surface. The unit is lightweight (approximately 41.2 lbs) and features built-in wheels for easy maneuverability. Its slim 3.94-inch profile allows for convenient storage under furniture.

Initial Placement and Storage

1. Unpack the walking pad from its box.
2. Place the walking pad on a firm, level surface, ensuring adequate space around the unit for safe operation.
3. To store, utilize the built-in wheels to slide the unit under a sofa, bed, or desk. The handle can be folded down for compact storage.



Image: The walking pad's compact design and integrated wheels facilitate easy movement and storage, allowing it to be slid under furniture or stored upright.

OPERATING INSTRUCTIONS

The Superun Walking Pad offers a speed range of 0.6 to 3.8 MPH, suitable for walking and light jogging. It features a 6% manual incline for increased calorie burn and a quiet 2.5HP motor.

Power On/Off and Speed Adjustment

1. Plug the power cord into a grounded electrical outlet.
2. Use the included remote control to power on the walking pad.
3. Adjust the speed using the '+' and '-' buttons on the remote control. The LED display will show the current speed, time, distance, and calories burned.
4. To stop, press the 'Stop' button on the remote. The machine will gradually slow down.

Incline Feature

The walking pad includes a fixed 6% manual incline. This incline is designed to simulate uphill walking, enhancing calorie expenditure compared to a flat surface.




Image: The 6% incline feature of the Superun Walking Pad helps maximize workout efficiency and calorie burn.

Smart Tracking and App Connectivity

Connect your walking pad to the PitPat App via Bluetooth for advanced tracking and interactive features. The app allows you to visualize workout data, set fitness goals, and participate in virtual races and challenges.



Image: The PitPat App provides smart tracking, goal setting, and community engagement for an enhanced fitness experience.

Operating Modes

The walking pad supports various activity levels:

- **Focus Work:** 0.6-1.6 MPH (Ideal for use under a standing desk)
- **Casual Walking:** 1.7-2.6 MPH
- **Light Jogging:** 2.7-3.8 MPH

Focus Work (0.6-1.6 MPH)



Casual Walking (1.7-2.6 MPH)



Over Jogging (2.7-3.8 MPH)



Image: The walking pad supports various speeds for different activities, from focused work to light jogging.

Official Product Videos

Superun Walking Pad with 6% Incline Overview

Your browser does not support the video tag.

Video: This video provides an overview of the Superun Walking Pad, highlighting its features and benefits, including the 6% incline.

Superun Walking Pad Home Fitness

Your browser does not support the video tag.

Video: This video demonstrates the Superun Walking Pad in a home fitness setting, showcasing its practical use.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Superun Walking Pad.

Lubrication

The walking belt requires periodic lubrication to reduce friction and wear. Use the provided lubricant as instructed. A common indicator for lubrication is a slight dust accumulation behind the unit or increased noise during operation.

1. Turn off and unplug the walking pad.
2. Lift the edge of the walking belt.
3. Apply a small amount of lubricant evenly under the belt, towards the center.
4. Plug in the walking pad and run it at a low speed (e.g., 1 MPH) for a few minutes to distribute the lubricant.

Cleaning

Wipe down the walking pad with a damp cloth after each use to remove sweat and dust. Avoid using abrasive cleaners or solvents.

TROUBLESHOOTING

If you encounter issues with your Superun Walking Pad, refer to the following common solutions:

- **Treadmill not starting:** Ensure the power cord is securely plugged in and the main power switch (if present) is on. Some models may require initial activation via the companion app before remote control functionality is fully enabled.
- **Burning smell during use:** A burning smell after extended use (e.g., 40 minutes) may indicate overheating or a need for

belt lubrication. Stop the machine immediately, unplug it, and allow it to cool down. Apply lubricant as per maintenance instructions. If the issue persists, contact customer support.

- **Loud beeping:** The treadmill emits a beep sound each time a button is pressed on the remote or when starting/stopping. This is normal operational feedback.
- **Belt slippage or uneven movement:** Check for proper belt tension and lubrication. Refer to the maintenance section for lubrication instructions. If the belt is misaligned, consult the full user manual for belt adjustment procedures.
- **App connectivity issues:** Ensure Bluetooth is enabled on your device and the walking pad is powered on. Try restarting both the app and the walking pad.

SPECIFICATIONS

Feature	Detail
Brand	Superun
Model Name	walking pad
Color	Glossy Black
Product Dimensions (D x W x H)	42.52"D x 24.49"W x 41.26"H
Item Weight	41.2 pounds
Material	Alloy Steel
Maximum Speed	3.8 miles per hour
Special Features	Lightweight, Manual Incline, Portable, Shock Absorbent, Wheeled
Maximum Horsepower	3.8 hp
Maximum Incline Percentage	6%
Display Type	LED
Power Source	Corded Electric
Connectivity Technology	Bluetooth
Metrics Measured	Calories Burned, Distance, Speed, Time
Maximum Weight Recommendation	300 pounds
Deck Length	35.43 inches
Deck Width	14.96 inches
UPC	884400221391

WARRANTY AND SUPPORT

Warranty Information

The Superun Walking Pad comes with a **1-year warranty**. This warranty covers manufacturing defects and ensures the product meets its specified performance standards under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Superun customer support. Refer to the contact information provided on the product packaging or the official Superun website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question