



AstroAI ASIMT33D Digital Multimeter User Manual

[Home](#) » [AstroAI](#) » AstroAI ASIMT33D Digital Multimeter User Manual 

AstroAI ASIMT33D Digital Multimeter User Manual



Thank you for purchasing the Digital Multimeter from AstroAI. The AstroAI Digital Multimeter is designed to be safely and accurately used in schools, laboratories, factories and other social/industrial fields. This user manual provides all the safety information, operation instruction, specifications, and maintenance for the meter. This instrument performs AC/DC Voltage, DC Current, Resistance, Diode Testing and Continuity Testing. Thank you again for choosing AstroAI, if you have any questions or concerns regarding your product, please contact us at support@AstroAI.com.

NOTE:

Fully read and comprehend this manual before using this Digital Multimeter.

WARNING












To avoid possible electric shocks, personal injury and to avoid possible damage to the Meter or to the equipment being tested, adhere to the following rules:

- Use the Meter strictly in accordance with this manual, otherwise the protection function provided by the Meter may be damaged or weakened.
- Please be especially careful when measuring over 60V DC, 30V AC RMS or 42V peak value, there is a danger of electric shocks.
- Do not apply more than the rated voltage marked on the Meter, between the terminals or between any terminal and grounding.
- Check whether the Meter is working normally by measuring the known voltage, do not use it if the readings are incorrect or the Meter is damaged.
- Before using the meter, please check whether there are cracks or damage to the plastic parts of the meter casing. Do not use the Meter if all or part of the exterior casing is damaged.
- Before using the Meter, please check whether the test leads are cracked or damaged. Please replace the test leads with those of the same model and same electrical specifications if the leads are damaged.
- Use the Meter according to the measurement category, voltage or current rating specified on the meter or manual.
- Comply with local and national safety regulations. Wear personal protective equipment (such as approved rubber gloves, masks, and flame-retardant clothing, etc.) to prevent injury from electric shocks and arcs when hazardous live conductors are exposed.
- Replace the battery as soon as the low-battery indicator appears to avoid measurement errors.
- Do not use the Meter around explosive gas, steam or humid environment.
- When using the test leads, keep your fingers behind the finger guards.
- When measuring, connect the neutral wire or ground wire first, then connect the live wire; when disconnecting, disconnect the live wire first, and then disconnect the neutral and ground wires.
- Before opening the case or battery cover, remove the test leads from the Meter first. Do not use the Meter when it is disassembled or when the battery cover is opened.
- The Meter can only be used with the equipped test leads to meet the requirements of safety standards. If the test leads are damaged and need to be replaced, replace only with the same model and the same electrical specifications.



Contents

- 1 ELECTRICAL SYBOLS
- 2 DIAGRAM
- 3 GETTING TO KNOW YOUR DEVICE
- 4 REPLACING THE BATTERY AND FUSE
- 5 THE SPECIFICATIONS OF FUSES
- 6 OPERATION INSTRUCTIONS
- 7 MEASURING AC/DC VOLTAGE
- 8 AUTOMOTIVE PARASITIC BATTERY DRAIN
- 9 MAINTENANCE
- 10 SPECIFICATIONS
- 11 DETAILED SPECIFICATIONS
- 12 INCLUDED IN BOX
- 13 1 YEAR LIMITED WARRANTY FROM ASTROAI
- 14 Documents / Resources
- 15 Related Posts


ELECTICAL SYBOLS

	AC (Alternating Current)		Low Battery Symbol
	DC (Direct Current)		Audible Continuity Test
V	Voltage		Diode Test
A	Current		Resistance Test
	Square Wave		Earth Ground
	Double Insulation		Warning
	Compliant with EU Standards		

SIZE



DIAGRAM





1. LCD Screen
2. Hold Button
3. Backlight Button
4. Rotary Switch
5. OFF
6. DC Voltage Test
7. Resistance
8. AC Voltage Test
9. DC Current Test
10. Square Wave Output
11. Continuity Test/Diode Test

12. 10A Terminal
13. vnm Terminal
14. Com Terminal
15. Test Leads

GETTING TO KNOW YOUR DEVICE


BUTTON FUNCTIONS

	
BUTTONS	FUNCTIONS
	<ul style="list-style-type: none"> • Press the HOLD button to hold or cancel the data. • Press this button while performing a test to hold (freeze) the reading for recording, then the screen will keep the reading when the hold function is activated. Press the HOLD button again to turn off this function. • NOTE : The screen will display "Ou "when the data hold function is activated.
	<ul style="list-style-type: none"> • Press the Backlight button to turn on the screen's backlight. The backlight allows you to get a clear reading in a dim environment. When the backlight is turned on, it will turn dark slowly until it is completely off. When the light turns dark, press the button again and it will turn bright again. If you need to turn off the backlight quickly, move the rotary switch to the off position.

	
	<ul style="list-style-type: none"> • Plug the red test lead into 10A terminal when using the 10A setting of DC current test.
	<ul style="list-style-type: none"> • Plug the red test lead into “2” terminal when you need to use functions other than 10A.
3	<ul style="list-style-type: none"> • Plug the black test lead into the COM terminal.

REPLACING THE BATTERY AND FUSE

- Turn off the Meter and remove the test leads.
- Unscrew the screws (that fix the battery cover) with a screwdriver, and remove the battery cover.



- Remove the old battery and replace it with a new battery of the same specification.
- Put the battery cover back to its original position and fix the battery cover with the removed screws.


Battery Type: 1 x 9V Battery NEDA 1604/6F22/006P



REPLACING FUSE

- Turn off the Meter and remove the test leads.
- Unscrew the screws fixing the battery cover with a screwdriver, and remove the battery cover and the battery




-





- Remove the blown fuses and replace them with new fuses of the same specification, make sure that the fuses are loaded into the fuse clip and clamped tightly.



F500mA/600V

F10A/600V

- Put the insulation cover, the battery and the battery cover back, and lock the cover with screws.

THE SPECIFICATIONS OF FUSES

- Fuse 1: F500mA/600V fuse; Size:p5*20mm
- Fuse 2: F10A/600V fuse; Size:p5“20mm


OPERATION INSTRUCTIONS

- To avoid damage to the Meter, do not measure voltages exceeding SOOV.
- This Meter is a manual range Multimeter. Please be sure to choose the correct measuring range to prevent damage.
- Pay special attention to safety when measuring high voltages to avoid electric shock or personal injury.
- Before using the Meter to test a known voltage or current, confirm that the Meter functions work properly.


MEASURING AC/DC VOLTAGE

MEASURING DC VOLTAGE

- Insert the red test lead into the “ vnmAm “terminal and the black test lead into the “COM” terminal.
- Turn the rotary dial to the continuity test, touch the red test lead and the black test I ead to check whether they are normal. The buzzer will beep if the test leads are normal.



- Turn the rotary dial to the “ V- ” area with a white font. The screen will display “000” indicating that the measurement function is DC voltage.



NOTE

- Of The test unit of “v=” area is “V ”; If the number on the white area is followed by “m”, then the test unit is “mV”.
- If the measurement range is the maximum, that is, 500 V setting, “HV” will be displayed on the screen.




- Connect the test leads to the circuit under test (connect the leads in parallel to the power supply or circuit under test) to measure.

NOTE


- @ If the reading is negative when measuring the DC voltage, it means that the positive and negative poles of the test leads are reversed, please change the test leads.
- After the reading stabilizes, record the reading from the LCD screen.
- Turn the rotary switch to the OFF position to turn off the Meter.

MEASURING AC VOLTAGE

- Insert the red test lead into the “VmA -” terminal and the black test lead into the “COM” terminal.
- Turn the rotary dial to the continuity test, touch the red test lead and the black test lead to check whether they are normal. The buzzer will beep if the test leads are normal.



- Turn the rotary dial to the “V” area with a white font. The screen will display “000” indicating that the measurement function is DC voltage.



NOTE

@ The test unit of “V” area is “V”. 2 If the measurement range at the maximum (SOOV setting) “HV” will be displayed on the screen.



- Connect the test leads to the circuit under test (connect the leads in parallel to the power supply or circuit under test) to measure.
- After the reading stabilizes, record the reading from the LCD screen.
- Turn the rotary switch to the OFF position to turn off the Meter.

VOLTAGE TIPS

HOW TO FIND A LIVE WIRE IN A SOCKET


- Switch to the voltage test setting.
- Connect the black test lead to the grounded wire or jack. Connect the red test lead to one of the jacks to be measured.
- Check both jacks. One should have a reading and the other should remain at or near zero. The live wire will have the reading.

VOLTAGE NOTES

- Choose the SOOV setting to measure the unknown voltage first, and then select the appropriate range according to the voltage.
- To avoid damage to the meter, do not measure voltage exceeding SOOV DC or SOOV AC CATII.
- If the AC setting is used to measure DC and vice versa, an overflow symbol will be displayed. Performing this action has the potential to damage the Meter or any components you are attempting to test.
- When measuring voltage, the result will fluctuate depending on the power supply. Generally, the result will fluctuate +10V, which is NOT an inaccurate result.

MEASURING DC CURRENT

- Disconnect the power supply of the circuit under test.
- Insert the red test lead into the “ ” terminal and the black test lead into the “COM” terminal.
- Turn the rotary dial to the continuity test, touch the red test lead and the black test lead to check whether they are normal. The buzzer will beep if the test leads are normal.




- Insert the black test lead into the “COM” terminal and red test lead into the 10A terminal.

NOTE

@ Please be sure to start the test from the 10A setting when measuring the unknown current.



- Turn the rotary dial to the 10A setting of “A=” area. The screen will display “000” indicating that the measurement function is a DC current from 200mA to 10A.



- Connect the Meter to the circuit under test in series, and then turn on the power supply of the circuit.
- After the reading stabilizes, record the reading from the LCD screen.
- Turn the rotary switch to the OFF position to turn off the Meter.

MEASURING DC A CURRENT

- Disconnect the power supply of the circuit under test.
- Insert the red test lead into the “VDMa-‘Tr” terminal and the black test lead into the “COM” terminal.
- Turn the rotary dial to the continuity test, touch the red and black test leads to check whether they are normal. The buzzer will beep if the test leads are normal.



- Turn the rotary dial to the “A=” area with yellow font. The screen will display “000” indicating that the measurement function is a DC A current from 200pA to 200mA.



NOTE

@ The test unit of “A=” area is “A”; If the number on the yellow area is followed by “mTM”, then the test unit is “mA”.

- Choose a larger setting to measure the unknown current first, and then select the appropriate range according to the current.
- Connect the Meter to the circuit under test in series, and then turn on the power supply of the circuit.
- After the reading stabilizes, record the reading from the LCD screen.
- Turn the rotary switch to the OFF position to turn off the Meter

AUTOMOTIVE PARASITIC BATTERY DRAIN

- Check if the battery voltage and power generation are within normal range. The battery voltage is generally around 12.7V and the power generation is around 14V.
- Turn off all electrical accessories inside and outside the car and close the doors.
- Remove the negative electrode of the battery. Set the Multimeter to the maximum current level and connect the Meter in series to the battery.

Connect the red test lead to the negative line and the black test lead to the battery terminal.


- Adjust the Meter, if necessary, to a lower range.
- Wait for about 30 minutes; after all the modules of the vehicle have entered the sleep state, read the accurate static discharge current. The discharge current is generally 0.02A (20mA), however, this can vary depending on the vehicle. Normally it will not exceed 50mA.
- If the drain is larger than 50mA, begin checking fuses individually for which circuit is carrying the excess load. If a removed fuse reduces the battery draw to below 50mA, it can be determined that the corresponding circuit is drawing the excess discharge.

CURRENT NOTES


- Choose the maximum setting to measure the unknown current first, and then select the appropriate range according to the current.
- If you insert the red test lead into the 10A jack, be sure to insert the test lead back into the “VnmAm” jack after the test to avoid forgetting to switch the jack for the next operation and thus burning the Multimeter.
- When testing a high current, for safety reasons, each measurement time should be less than 10 seconds, and the interval time between tests should be greater than 15 minutes.
- When testing the current, there must be a load in the circuit. Do not connect the multimeter in series with the circuit without a load to measure; doing so can potentially damage the Meter.
- Do not apply a current exceeding the Meter’s range to avoid damaging the Meter.

MEASURING RESISTANCE

- Insert the red test lead into the “VnmA-Ω” terminal and the black test lead into the “COM” terminal.
- Turn the rotary dial to the continuity test, touch the red and the black test leads to check whether they are normal. The buzzer will beep if the test leads are normal.



- Turn the rotary dial to the “CI” area with a yellow font. The screen will display “1” indicating that the measurement function is resistance.



NOTE


1. The test unit of “CI” area is “CI”; If the number on the yellow area is followed by a “M”, then the test unit is “MD”; If the number on the yellow area is followed by a “K”, then the test unit is “KPI”.
2. Choose a larger measurement range to measure the unknown resistance first, then select the appropriate range according to the resistance.
3. Connect the test leads to both ends of the circuit or resistor under test (connect the leads to the resistance under test in parallel).
4. After the reading stabilizes, record it from the LCD screen.
5. Turn the rotary switch to the OFF position to turn off the Meter.

RESISTANCE NOTES


- Do not change the resistance while taking a measurement.
Doing so may damage the Meter and affect the test results.
- Do not test parallel circuits. The accuracy of the measurement will be affected, and the results may not be accurate.
- Do not directly measure the internal resistance of micrometers, galvanometers, batteries, and other instruments.

CONTINUITY TEST

- Insert the red test lead into the “VnmAT” terminal and the black test lead into the “COM” terminal.
- Turn the rotary dial to the “++” setting. touch the red and the black test leads to check whether they are normal. The buzzer will beep if the test leads are normal.



- Connect the test leads to both ends of the circuit or resistor under test (parallel). If the resistance of the circuit or resistor under test is connected and less than SOA, the buzzer will emit a beep sound.
- If the circuit or resistor under test is disconnected, or the resistance value is greater than 500Ω, the LCD screen will display "1".



- Turn the rotary switch to the OFF position to turn off the Meter.

DIODE TEST

- Insert the red test lead into the "VΩmA" terminal and the black test lead into the "COM" terminal.
- Turn the rotary dial to the "++" setting. touch the red and the black test leads to check whether they are normal. The buzzer will beep if the test leads are normal.
- Connect the red test lead to the anode of the diode under test and the black test lead to the cathode of the diode.

NOTE

Usually the anode of the diode is the longer end.

- The LCD screen will display the approximate voltage drop reading of the diode. The test unit is "mV". If the test leads are connected in reverse, "1" will be displayed on the LCD screen.
Please replace the test leads to measure again.
- Turn the rotary switch to the OFF position to turn off the Meter.

DIODE TEST TIPS


- Is the diode functioning correctly: If the red test lead is connected to the positive pole of the diode and the black lead is connected to negative, then the diode should be in a forward conduction state, and the displayed value is the forward voltage drop.
- Normal diode forward pressure drop: the general silicon tube is 0.5- 0.7 V, germanium tube is 0.15-0.3V.
- You can also verify that the red test lead is connected to the negative pole of the tested diode and the black test rod is connected to the positive pole. The diode should display "1".

POLARITY JUDGMENT METHOD


- Switch the Multimeter to the Resistance setting.
- Connect the two test leads to the two electrodes of the diode.
- Measure one result, then swap the positions of the test leads and measure the second result.
- The larger result is the reverse resistance and the smaller result is the forward resistance. The smaller resistance is when the black test lead is connected to the positive end of the diode and the red lead is connected to the negative end.

SQUARE WAVE OUTPUT

- Insert the red test lead into the “VrznA-‘Tr” terminal and the black test lead into the “COM” terminal.
- Turn the rotary dial to the continuity test, touch the red test lead and the black test lead to check whether they are normal. The buzzer will beep if the test leads are normal.



- Turn the rotary dial to the “ ” setting. The screen will display “1” indicating that the measurement function is square wave output.



- Connect the test leads in parallel to both ends of the tested power supply or circuit.
- After the reading stabilizes, record the reading from the LCD screen.
- Turn the rotary switch to the OFF position to turn off the Meter.

MAINTENANCE

CLEANING THE METER

If there is dust or humidity in the terminals, it may produce erroneous measurements. Please clean the Meter as follows:

- Turn off the power to the Meter and remove the test leads.
- Turn the meter over and shake out the dust accumulated in the input jack, wipe the case with a damp cloth or

mild detergent. Wipe the contacts in each terminal with a clean cotton swab dampened in alcohol.

SPECIFICATIONS

Accuracy is guaranteed for 1 year, with storage conditions of 23°C+5°C, less than 80%RH

Digital Display	2000, 3 /
Sampling Speed	2 Times/Second
LCD Dimensions	49 x 17mm
Range Selection	Manual
Polarity Indication	“-” Automatically Displayed
Overload Indication	“1” Displayed
Low Battery Indication	“ ”displayed when battery voltage is lower than normal
Work Environment	32-104 °F; 0-40 °C, at <80%RH
Storage Temperature	14-122 °F; -10-50 °C, at <85%RH
Power	1 x 9V Battery NEDA 1604/6F22/006P
Weight	Approximately 145g
Dimensions	130 x 73 x 37mm

DETAILED SPECIFICATIONS

Accuracy is guaranteed for 1 year, with storage conditions of 23°C+5°C, less than 80%RH

1. DC VOLTAGE

Range	Resolution	Accuracy	Overload Protection
200mV	100pV	* (0.5%+3)	220V RMS AC
2000mV	1mV	1 (0.8%+2)	SOOV DC / SOOV RMS
20V	10mV		
200V	100mV		
SOOV	1V	* (0.8%*3)	

2. AC VOLTAGE

Range	Resolution	Accuracy	Overload Protection
200V	100mV	*(2.0%+10)	SOOV DC / SOOV RMS
SOOV	1V		

3. DC CURRENT

Range	Resolution	Accuracy	Overload Protection
2000pA	1pA	* (2.0%+5)	500mA, 600V fuse
20mA	10pA		
200mA	100pA		
10A	10mA	* (2.5%+5)	10A, 600V fuse


Measured Voltage Drop: 200mV

4. RESISTANCE

Range	Resolution	Accuracy	Overload Protection
200CI	0.1CI	(1.5%*5)	15 seconds maximum exposure to 220Vrms
2000CI	1CI	* (1.0%*4)	
20KCt	10CI		
200KCI	100D		
20MCI	10KCI	-L (1.0%+10)	
200MCI	100KCI	-L (1.0%+10)	

Maximum Open Circuit Voltage: 3V

5. CONTINUITY TEST

Range	Resolution	Overload Protection
	Built-in buzzer sounds if resistance is less than 301-20CI	15 second maximum exposure to 220V RMS

INCLUDED IN BOX

- 1 x User Manual
- 1 x Pair of Test Leads
- 1 x AstroAI Digital Multimeter

1 YEAR LIMITED WARRANTY FROM ASTROAI


Each AstroAI Digital Multimeter will be free from defects in material and workmanship. This warranty does not cover fuses, disposable batteries and damage from neglect, misuse, contamination, alteration, accident, or abnormal conditions of operation or handling, including over-voltage failures caused by use outside the Meter's specified rating, or normal wear and tear of mechanical components. This warranty covers the original purchaser only and is not transferable. If this product is defective, please contact AstroAI Customer Support at support@astroai.com.



Web: www.astroai.com

E-mail: support@astroi.com

Documents / Resources

 The image shows the front cover of a user manual. At the top left is the "AstroAI" logo. Below it, the text "Digital Multimeter" and "User Manual" is printed. The central part of the cover features a photograph of the ASIMT33D digital multimeter, which has a large LCD screen displaying "0.000" and various function buttons and ports at the bottom.	<p>AstroAI ASIMT33D Digital Multimeter [pdf] User Manual ASIMT33D, Digital Multimeter</p>
--	---