


# **ATOMRC Fixed Wing Flying Fish User Manual**

**Home** » **ATOMRC** » **ATOMRC** Fixed Wing Flying Fish User Manual



Fixed Wing Flying Fish User Manual



#### **Contents**

- 1 Introduction
- 2 Specifications
- **3 Version Description**
- 4 Installation
- 5 Tx500 VTX User
- manual
- 6 2 in 1 ESC Wiring
- 7 Tips
- 8 Documents /
- **Resources**
- 8.1 References
- **9 Related Posts**

### Introduction

The Flying Fish is a special design twin motor glider for close-range FPV, the 650mm wingspan made the glider easy to fly in a small room and also easy to launch. With 2 in 1 ESC, the wiring is clean and simple, with no modification. The twin motor design made the glider very efficient.

# **Specifications**

Wingspan	650mm
Length	570mm
WingArea	6.15d
Material	EPP
Motor	1105 5000KV*2
ESC	BLS 2 in 1 10A 2~4S
Propeller	T3018
Servo	4.3g Servo*4Pcs
Recommend Battery	3S 750mAh Lipo


# **Version Description**

Light-bit	State	Meaning			
Light output terminal Red light 1	Bright flame	Turn on the output			
	Often off	Turn off the output			
	Always put out a Br ight flame	Standby. screen off Turn on the output. state of the constant voltage CC			
	Always off	Turn off the output			
Blue lights 2	Bright flame Always put out	Turn on the output. constant current CV state Turn off the output			
Red light 2	Bright flame	Parameter lock			
	Always put out	Parameter not locked			
Greenlight 1	Bright flame	not disconnected			
	sparkle	Select the extension that has been disconnected			
	Turn off the flash	has been disconnected			
Up and down the re	sparkle	alarm			


# Installation




Install the tail, then install the elevator control surface.



Plug the ESC/Servo connector into the receiver.



Install the propeller, then install the wing to the fuselage.



Install the hatch.

# Tx500 VTX User manual

Band	Channel								
	1	2	3	4	5	6	7	8	
Band A	5865	5845	5825	5805	5785	5765	5745	5725	
Band B	5733	5752	5771	5790	5809	5828	5847	5866	
Band E	5705	5685	5665	5645	5885	5905	5925	5945	
Airwave/FS	5740	5760	5780	5800	5820	5840	5860	5880	
Race Band	5658	5695	5732	5769	5806	5843	5880	5917	
L Band	5362	5399	5436	5473	5510	5547	5584	5621	

# **VTX Specs**


Voltage input: 2~6S Lipo Frequency:5.3~5.9Ghz

Power: 100/200/500mw Switchable Power consumption: 9V 1.1A

### **VTX Setting**


- 1. Hold the button 3 seconds into setting mode. In setting mode. short press the button to change the band.
- 2. Then hold the button 3 seconds into CH setting mode, and short press the button to change CH.
- 3. Hold the button 3 seconds to get into Power setting mode, there is a short bar on the LED, short press to switch power, 1 bar means 100mW, 2 bar means 200mW, 3 bar means 500mW.

### 2 in 1 ESC Wiring



The throttle input is bridged on the cable, if the user wants differential throttle, please solder the input on the soldering pads.

### **VTX Wiring**




# **Tips**

This product is not a toy, adult supervision is required for those under 14 years old!





The CG is very important for Flying Fish CG is marked on the bottom of the wing. Check the CG carefully before flight.



Please download the latest user manual at



www.atomrc.com/pages/download

### **Documents / Resources**



ATOMRC Fixed Wing Flying Fish [pdf] User Manual Fixed Wing Flying Fish, Wing Flying Fish, Flying Fish, Fish

# References

• <u>O Download – ATOMRC</u>

Manuals+,