



audiolab Omnia Encompassing Audio Solution User Manual

[Home](#) » [audiolab](#) » audiolab Omnia Encompassing Audio Solution User Manual

Contents [[hide](#)]

- 1 audiolab Omnia Encompassing Audio Solution
- 2 Safety
- 3 Introduction
- 4 Installation recommendations
- 5 Installation
 - 5.1 Electrical installation
- 6 Technical data
- 7 Principal dimensions
- 8 Wiring diagrams
- 9 Battery capacity, battery cables
- 10 Documents / Resources
- 11 Related Posts

audiolab

audiolab Omnia Encompassing Audio Solution



Safety

Warning indications

The following warning indications are used in this manual in the context of safety:

- **Danger**

Indicates that great potential danger exists that can lead to serious injury or death.

- **Warning**

Indicates that a potential danger that can lead to injury exists.

- **Caution**

Indicates that the usage procedures, actions etc. concerned can result in serious damage to property. Some CAUTION indications also advise that a potential danger exists that can lead to serious injury or death.

- **Note**

Emphasises important procedures, circumstances etc.

Symbols



Indicates that the relevant procedure must be carried out.



Indicates that a particular action is forbidden.

Share these safety instructions with all users.

General rules and laws concerning safety and accident prevention must always be observed.

Introduction

This manual give guidelines for installing a VETUS bow and/or stern thruster from the BOW PRO series, model 'BOWA0651' and 'BOWA0764'.

The bow or stern thruster system consists of the following basic components:

- Side thruster

- Tunnel
- Energy storage
- Energy supply
- Operation

Note

If necessary, consult the installation manuals for all components before putting the complete system into operation.

For maintenance and warranty, please refer to the 'Maintenance and Warranty Manual'.

The quality of installation will determine how reliably the bow and/or stern thruster performs. Almost all faults can be traced back to errors or inaccuracies during installation. It is therefore imperative that the steps given in the installation instructions are followed in full during the installation process and checked afterward.

Alterations made to the bow thruster by the user will void any liability on the part of the manufacturer for any damages that may result.

The actual thrust generated by the bow and/or stern thruster will vary from vessel to vessel depending on the windage, the hull displacement, and the shape of the underwater section.

The nominal thrust quoted can only be achieved under normal conditions:

- During use ensure the correct battery voltage is available.
- The installation is carried out in compliance with the recommendations given in this installation instruction, in particular with regard to:
 - Sufficiently large diameter of the battery cables so that voltage drop is reduced to a minimum.
 - The manner in which the tunnel has been connected to the hull.
 - Use of bars in the tunnel openings.
These bars should only be used where this is strictly necessary
(if sailing regularly in severely polluted water.)
 - The bars must have been fitted correctly.

Note

The areas in which the electric motor(s) of the thruster(s) and batteries are positioned must be dry and well ventilated.

Note

Check for possible leaks immediately the boat is relaunched.


Note

The maximum continuous length of usage and the thrust as specified in the technical details are based on the recommended battery capacities and battery cables.


Installation recommendations

Positioning of the thruster tunnel


Several installation examples.




To achieve the optimum performance, position the thruster tunnel as far forward as possible.




If, in addition to controlling the movement of the bow, the stern of the vessel is required to move sideways, then a second thruster may be installed at the stern.



For a planing boat the tunnel should, if possible, be so situated so that when the vessel is planing it is above the water level thus causing no resistance.



Installation of two bow thrusters in tandem (for larger boats). In this case, depending on weather conditions, one or both bow thrusters may be used.




Tip:

We do not advise fitting 2 bow thrusters into one tunnel; this does not result in doubling the thrust!


When choosing the location for the thrust tunnel, take the following into account for optimum performance:

- The distance A shown in the drawing must be at least $0.5 \times D$ (where D is the tunnel diameter).
- The length of the tunnel (distance B) should be between $2 \times D$ and $4 \times D$.




Positioning of the bow thruster in the thrust-tunnel


When determining the exact position of the bow thruster in the thrust tunnel, the tailpiece **MUST NOT** protrude from the tunnel end.



The propeller should preferably be situated on the centreline of the vessel, but it must always be accessible from the outside.




- The electric motor can be installed in various positions.
- If the motor is set up horizontally or at an angle, support is absolutely essential.
- The electric motor must be positioned in such a way that it is always well clear from the maximum bilge water level.




Connection of thrust tunnel to ship's hull

Direct connection of the tunnel to the hull, without a fairing, produces reasonable results.



- **A** The connection to the hull can be abrupt.
- **B** It is better to make the connection rounded with radius 'R' of about $0.1 \times D$.
- **C** It is even better to use sloping sides 'C' with dimensions 0.1 to $0.15 \times D$.


Connection of the thrust tunnel to the ship's hull with a fairing results in lower hull-resistance during normal sailing.



- **A** The connection with a fairing can be abrupt.
- **B** It is better to make the connection with a fairing rounded with radius 'R' of about $0.1 \times D$.
- **C** The best connection is with a fairing using sloping side 'C' with dimensions 0.1 to $0.15 \times D$.

Tip:


The manner, in which the thrust tunnel is connected to the hull, has a great influence on the actual performance of the bow thruster and to the drag the hull experiences when underway.



- Length 'L' of the fairing should be between $1 \times D$ and $3 \times D$.
- This fairing should be embodied in the ship's hull in such a way that the centreline of the fairing will correspond with the anticipated shape of the bow-wave.

If the connection of the thrust tunnel and the boat's hull is to be made with a sloped side, it should be executed in accordance with the drawing.

Make the sloped side (C) with a length of 0.1 to $0.15 \times D$ and make sure that the angle between the tunnel and the sloped side will be identical to the angle between the sloped side and the ship's hull.





Grid bars in the tunnel openings


Although the thrust force will be adversely affected, grid bars may be placed into the tunnel openings, for protection of the thruster.


In order to limit the negative effect of this on the thrust and on hull resistance during normal operation as much as possible, the following must be taken into account:

- Do not fit more bars per opening than is indicated in the drawing.



- The bars must have a rectangular cross-section.
- Do not fit round bars.
- The bars must overlap a certain amount.







- The bars must be installed so they are perpendicular to the expected waveform.

Installation of the thrust tunnel

- Drill 2 holes in the hull, where the centreline of the thrust tunnel will be, in accordance with the diameter of the marking tool.




- Pass the marking tool (home-made) through both pre-drilled holes and mark the outside diameter of the thrust-tunnel on the hull.




D [mm] (inches)		
Steel	GRP	Aluminium
194 (7 41/64")	196 (7 23/32")	196 (7 23/32")

- Dependent on the vessel's construction material, cut out the holes by means of a jigsaw or an oxy-acetylene cutter.



- Install the thrust-tunnel.



Polyester thrust tunnel:

Resin: The resin used for the polyester thrust tunnel is Isophthalic polyester resin (Norpol PI 2857).

Pre-treatment: The outside of the tunnel must be roughened.


Remove all of the top surface down to the glass-fibre. Use a grinding disc for this.

Important: After the tunnel been sawn to length, treat the end of the tube with resin. This will prevent water seeping in.

Laminating: Apply a coat of resin as the first coat. Lay on a glassfibre mat and impregnate with resin. Repeat this procedure until you have built up a sufficient number of layers.

A polyester thrust tunnel should be finished as follows:


- Roughen the hardened resin/glass-fibre. Apply a top coat of resin.
- Treat the side of the tunnel which comes into contact with water with 'epoxy paint' or 2-component polyurethane paint.
- Then apply anti-fouling treatment if required.





Drilling the holes in the thrust-tunnel



- Mark the installation position of the bow thruster by means of the intermediate flange.
- Use the drill pattern supplied, to determine the correct position of the holes to be drilled.

Important: The pattern of the holes must be positioned precisely on the centreline of the tunnel.






Consult the template for the dimensions of the holes to be drilled. Drill the holes through the thrust tunnel and take care that the holes are free of burrs.




Protection of the bow thruster against corrosion

To prevent corrosion problems, do not use copper based antifouling. Cathodic protection is a 'must' for the protection of all metal parts under water and the bow thruster is supplied with a zinc anode for this purpose.



Corrosion of a steel or aluminium thrust tunnel can be reduced by ensuring that the tail piece is completely insulated from the thrust-tunnel.

NOTE: The gaskets supplied are already electrically insulated. However the bolts and the shaft need to be fitted with insulation material, for example nylon bushes.



Installation


Introduction

Note

The areas in which the electric motor(s) of the bow thruster(s) and the batteries are positioned must be dry and well ventilated.

For overall dimensions see drawing, page 95

The bow thruster is supplied in parts as shown.




Installation tailpiece and intermediate flange

- Ensure that the plastic shim plate (1) has been positioned on the tail piece.
- Place one packing (2) between the tail piece and the tunnel.
- Apply a sealant (e.g. polyurethane*) or silicone) between the tail piece and packing, and between the packing and the tunnel wall.
- Place the tail piece in the hole in the tunnel.

Any extra packings used should be ones capable of justifying the tail piece.


*) e.g. Sikaflex®-292.



- Grease the hole of the intermediate flange and position this flange.
- Grease the threads of the bolts with 'outboard gear grease' *) before inserting and tightening them.

Note


Check for any leaks immediately the vessel returns to the water.




- A suitable grease is VETUS 'Shipping Grease', Art. code: VSG.

Final assembly


- Grease the propeller shaft with 'outboard gear grease' *) and install the propeller.




The propeller should run a minimum of 1.5 mm (1/16") free of the thrust tube wall, around the complete circumference.



- Slide the flexible coupling onto the output spindle of the electric motor as far as necessary to allow the end of the output spindle (A) and the underside of the flange (B) to become aligned.



- Tighten the lock-screw (C) to the specified torque.
- Grease the input shaft with an installation compound, such as 'Molykote® G-n plus'.
- Grease the threads of the fastenings bolts with 'outboard gear grease' and install the electric motor to the intermediate flange.
- For a first check, turn the propeller by hand – it should turn easily, while connected to the output spindle of the electric motor.



- A suitable grease is VETUS 'Shipping Grease', Art. code: VSG.

Electrical installation

Choice of battery

The total battery capacity must be sufficient for the size of the bow thruster; see the table. See page 106 for the applicable battery capacity.

The minimum battery capacity is specified in the table; with a larger battery capacity, the bow thruster will perform even better!

We recommend VETUS maintenance free marine batteries; these can be supplied in the following sizes: 55 Ah, 70 Ah, 90 Ah, 108 Ah, 120 Ah, 143 Ah, 165 Ah, 200 Ah and 225 Ah.

We also recommend that each bow thruster is powered by its own separate battery or batteries. This allows the battery bank to be placed as close as possible to the bow thruster; the main power cables can then be short thus preventing voltage losses caused by long cables.

Always use batteries whose type and capacity are compatible for their use.

Note

Be sure to only use 'sealed' batteries if the batteries are located in the same compartment as the bow thruster. VETUS 'SMF' and 'AGM' maintenance-free batteries are ideal for this application. Batteries that are not 'sealed' may produce small amounts of explosive gas during the charging cycle.

Main power cables (battery cables)

The minimum diameter and battery capacity must be sufficient for the bow thruster's current draw in use. Consult the table on page 106 for the correct values.

Note

The maximum operating time and the thrust, as specified by the technical details in your bow thruster installation and operating manual, are based on the recommended battery capacities and battery connection cables.

Main switch

The main switch must be fitted to the 'positive cable'.

The VETUS battery switch type BATSW250 is a suitable switch, which is also available in a 2-pole version, VETUS part number BATSW250T.



Fuses

Main power fuse 1,

Choice of battery

A fuse must be included in the 'positive cable' for the main switch, as close to the battery as possible.

This fuse protects the on-board power cabling from short circuits.



For all fuses we can supply a fuse holder, VETUS part no.: ZEHC100. See page 106 for the size of the fuse to be used.

Connecting the main power cables and configuring the bow and/or stern thruster

Make sure that no other electrical parts come loose when connecting the electric cables.

Check all electrical connections after 14 days. Electrical parts (such as bolts and nuts) may come loose as a result of fluctuations in temperature.

- Take off the cover.
- Feed the battery cables through the input glands in the cover.
- Apply cable terminals to the battery cables and connect the cables to the motor controller.

Make sure that the cable terminal on the negative cable cannot cause a short circuit to the lowest of the three motor connections on the controller!


Note

The tightening torque of bolts in the motor regulator is a maximum of 10 Nm (7 ft-lbf).

The drawing shows how the cables must be laid in order for the cover to be replaced again.

Note

Make sure that the voltage stated on the motor type plate is identical to the boat's power supply voltage.



For connection diagrams

Note

To allow the bow thruster or stern thruster to be distinguished on the CAN bus, these must be configured appropriately.


Bow thruster

The configuration as supplied is for application as a bow thruster.

Stern thruster

Configure a stern thruster by cutting through the red wire as indicated in the drawing.


- Reinstall the cover and tighten the glands.



Main power fuse 2

In the connection unit, there is a main power fuse on the controller.

This fuse protects the controller and motor against short circuit/overloading and it must remain present under all circumstances.



Note

When replacing the fuse, the replacement must be of the same rating.

Connecting CAN bus (control current) cables

See diagrams from page 97 if multiple panels have to be connected.

Note

The CAN bus power supply must always be connected to 12 Volt (≥ 10 V, ≤ 16 V). Use the E-Drive MPE1KB key switch as power supply.

Caution

As required by international standards, all neutral (negative) conductors of the DC system must be connected to one central point. This prevents not only dangerous situations and corrosion problems, but also error messages in the CAN bus system.

Technical data

Type	:	BOWA0651	BOWA0764
Electromotor			
Type	:	EC Motor (8VAC-2.7kW)	EC Motor (15VAC-3.1kW)
For DC systems	:	12 V =	48 V =
Current (In)	:	237 A @ 12,0 V	82 A @ 48,0 V
		271 A @ 10,5 V	93 A @ 42,0 V
Power consumption	:	2,9 kW	3,9 kW
Rating	:	S2 - 10 min. [1]	
Protection	:	IP44	
Insulation class	:	F	
Motor controller			
MCV	:	MCV30024 + MCV0651S	MCV25048C + MCV0764S
Transmission			
Gears	:	Bevel gear helical teeth	
Gear ratio	:	1,7 : 1	
Lubrication	:	oilbath, outboard gear oil SAE80W or EP 90	
	:	ca. 0.06 litre (2.1 fl.oz.)	
Propeller			
No. of blades	:	6	
Profile	:	asymmetrical	
Material	:	polyacetal (Delrin ®)	
Rated thrust	:	650 N (65 kgf)	900 N (90 kgf)

Control circuit

Fuse : Blade type fuse 'ATO' 5 A

Control circuit wires : 2 x 2x 0,5 mm² (2 x 2 x AWG20) Twisted pair

Extension cable : 5, 10, 15, 20 or 25 m (16', 33', 49', 66, or 82')

Thrust-tunnel

Steel model

dimensions : O.D. outside 194 mm, wall thickness 5,6mm

treatment : blasted, coated with: SikaCor Steel Protect.
Suitable for all kinds of protection systems.

Plastic model

dimensions : I.D. inside 185 mm, wall thickness 5 mm

material : glass fibre reinforced polyester

Aluminium model

dimensions : I.D. inside 185 mm, wall thickness 5,5 mm

material : aluminium, 6060 or 6062 (AlMg1SiCu)



Weight

Excl. thrust-tunnel : 35 kg (77 lbs)

[1] S2 't' min. → Activation time 't' min. continuously or a max. of 't' min. per hour at maximum power.

Principal dimensions

BOWA0651
BOWA0764




BOWA0651
185 mm Tunnel
8VAC-2.7kW Motor

BOWA0764
185 mm Tunnel
15VAC-3.1kW Motor

1 : 10


Wiring diagrams



Note


The CAN bus is a chain to which the bow thruster and the panels are connected.

At one end of the chain, the power supply (3) must be connected and the terminator (7) must be connected at the other end!




One (1) thruster (bow or stern),
One (1) helm station

1. Connection box thruster (or stern thruster)
2. Hub
3. CAN-bus supply
4. Control voltage fuse
5. Control panel
6. Connection cable
7. Terminator




One (1) thruster (bow or stern),
Two (2) helm stations



Thrusters (bow AND stern), One (1) helm station

1. Connection box bow thruster
2. Hub
3. CAN-bus supply
4. Control voltage fuse
5. Control panel bow thruster
6. Connection cable
7. Terminator
8. Connection box stern thruster
9. Control panel stern thruster





Thrusters (bow AND stern).

Two (2) helm stations. The diagram can be extended to up to four (4) helm stations.



1. Connection box bow thruster
2. Hub

3. CAN-bus supply
4. Control voltage fuse
5. Control panel bow thruster
6. Connection cable
7. Terminator
8. Connection box stern thruster
9. Control panel stern thruster



Connection of battery for a 12 volt bow or stern thruster

1. Connection box thruster (or stern thruster)
2. Battery
3. Main fuse
4. Main switch
5. Alternator
6. Starter motor
7. Battery isolator



Connection of batteries for a 48 volt bow or stern thruster

Battery capacity, battery cables


Bow thruster	Battery capacity required	Total length of plus- and minus cable	Cable cross-section	Main power fuse, see 5.4	
	Minimum			'slow blow'	VETUS art. code

BOWA065 1 65 kgf – 1 2 V	1 x 170 Ah – 12 V	0 – 6,3 m	0 – 20.7 ft	50 mm2	AWG 0	355 A	ZE355
		6,3 – 8,9 m	20.7 – 29.2 ft	70 mm2	AWG 00		
		8,9 – 11,9 m	29.2 – 39 ft	95 mm2	AWG 000		
		11,9 – 15,1 m	39 – 49.5 ft	120 mm2	AWG 0000		
		15,1 – 17,6 m	49.5 – 57.7 ft	2 x 70 mm2	2 x AWG 00		
		17,6 – 18,9 m	57.7 – 62 ft	150 mm2	AWG 300 MCM		
		18,9 – 23,9 m	62 – 78.4 ft	2 x 95 mm2	2 x AWG 000		
		23,9 – 30 m	78.4 – 98.4 ft	2 x 120 mm2	2 x AWG 0000		
		30 – 37,9 m	98.4 – 124.3 ft	2 x 150 mm2	2 x AWG 300 MCM		

BOWA076 4 76 kgf – 4 8 V	4 x 60 Ah – 12 V	0 – 37,7 m	0 – 123.7 ft	25 mm2	AWG 4	125 A	ZE125
		37,7 – 53,1 m	123.7 – 174.2 ft	35 mm2	AWG 2		
		53,1 – 76 m	174.2 – 249.3 ft	50 mm2	AWG 0		
		76 – 106,3 m	249.3 – 348.8 ft	70 mm2	AWG 00		
		106,3 – 144,4 m	348.8 – 473.8 ft	95 mm2	AWG 000		
		144,4 – 182,5 m	473.8 – 598.8 ft	120 mm2	AWG 0000		
		182,5 – 213 m	598.8 – 698.8 ft	2 x 70 mm2	2 x AWG 00		

FOKKERSTRAAT 571 – 3125 BD SCHIEDAM – HOLLAND
TEL.: +31 (0)88 4884700 – sales@vetus.nl – www.vetus.com

Documents / Resources

	audiolab Omnia Encompassing Audio Solution [pdf] User Manual Omnia Encompassing Audio Solution, Omnia, Encompassing Audio Solution, Audio Solution
---	---