



AUTEL ROBOTICS EVO II RTK V3 Series Rugged Bundle Camera Drone User Guide

[Home](#) » [AUTEL ROBOTICS](#) » AUTEL ROBOTICS EVO II RTK V3 Series Rugged Bundle Camera Drone User Guide 

AUTEL ROBOTICS EVO II RTK V3 Series Rugged Bundle Camera Drone User Guide




Contents

- 1 OVERVIEW
- 2 AIRCRAFT
- 3 FLIGHT LED INDICATIONS
- 4 REMOTE CONTROLLER
- 5 CHARGING
- 6 AUTEL EXPLORER APP
- 7 PREPARING THE AIRCRAFT
- 8 PROPELLERS
- 9 PREPARING THE CONTROLLER
- 10 POWERING UP
- 11 TAKE OFF
- 12 COMMAND STICK CONTROLS(MODE 2)
- 13 SPECIFICATIONS
- 14 FCC and ISCED Canada Compliance
- 15 Documents / Resources
 - 15.1 References
- 16 Related Posts

OVERVIEW


The EVO II RTK Series V3 brings excellent flight performance, achieving a top speed of 20m/s (45mph), 36-minute flight time, and an operating distance at 15km (9.32miles, FCC). The aircraft comes with a 7.9 inch touch-screen controller, boasts a 2048×1536 pixel resolution.




NOTE:

Please read all documentation before your first flight. Failure to operate the aircraft responsibly could lead to injury or damages, and may void any applicable warranty coverage.


AIRCRAFT




1. Propellers
2. Motors
3. Front LED Indicators
4. Landing Gear
5. Front Vision System
6. Gimbal Camera
7. RTK Module




- 8. Power Butto
- 9. Rear Vision System
- 10. Rear LED Indicators




- 11. Left Vision System
- 12. SD Card Slot



- 13. Right Vision System
- 14. Aircraft Battery
- 15. Air Vent
- 16. USB Port
- 17. Pairing Button / Pairing Indicator



18. Upward Vision System



19. Ultrasonic Sensor

20. Downward Vision Lighting LED

21. Downward Vision System

FLIGHT LED INDICATIONS

A LED indicator is located on the end of each aircraft arm. The front LEDs will light up solid red to help you identify the direction of the aircraft's nose. The rear LEDs will display the current flight status of the aircraft. The chart below shows the meaning of each status indicator.

Indicator Key: Color Key


Slow Flashing: Flashes once every 2s **R** – Red Color

Fast Flashing: Flashes twice per second **G** – Yellow Color

Alternate Flashing: Alternates among different colors **Y** – Green Color


Definitions of Indicator Status	
Normal	
RGY – Alternate Flashing	System self-test is activated
YG – Alternate Flashing	The aircraft is warming up
G – Slow Flashing	The aircraft is in GPS mode
Warning	
Y – Slow Flashing	The aircraft is in ATTI mode
Y – Fast Flashing	No connection between the aircraft and smart controller
R – Slow Flashing	Low Battery Warning
R – Fast Flashing	Critically Low Battery Warning
R – Solid Light	Critical problems, IMU error
RY – Alternate Flashing	Abnormal compass, calibration is required / Magnetometer interference
Compass Calibration	
Y – Fast Flashing	Be ready to calibrate the compass/ The aircraft is calibrating
G – Solid Light	Calibration is successful
R – Solid Light	Calibration is failed

REMOTE CONTROLLER




1. Left Command Stick
2. Gimbal Pitch Angle Wheel
3. Video Recording Button
4. Customizable Button C1

- 5. Air Outlet
- 6. HDMI Port
- 7. USB-C Port
- 8. USB-A Port
- 9. Power Button
- 10. Customizable Button C2
- 11. Photo Shutter Button
- 12. *Zoom Control Wheel
- 13. Right Command Stick




- 14. Battery Indicator
- 15. Antenna
- 16. Touch Screen
- 17. Pause Button
- 18. Auto-takeoff/ RTH Button
- 19. Microphone



- 20. Speaker Hole
- 21. Tripod Mount Hole
- 22. Air Vent
- 23. Bottom Hook
- 24. Grips

CHARGING

Aircraft Battery: Plug the charging connector into the battery's charge port, and connect the other end to power adapter. Plug the power adapter into a power outlet (100-240V AC).



Controller: Connect the charging cable to the USB port at the top of the controller, and the other end to power adapter. Plug the power adapter into a power outlet (100-240V AC).

NOTE:


- Always fully charge the aircraft and smart controller battery before flying.
- It takes approximately 90 minutes to fully charge the aircraft battery, and 120 minutes to charge the controller.

AUTEL EXPLORER APP


Search for 'Autel Explorer' from Google Play and install the app on your controller.

PREPARING THE AIRCRAFT

Before powering on the aircraft, please remove the gimbal guard.



Unfold the arms and propellers



NOTE:


Power off the aircraft before folding the arms. Fold in the rear arms and propellers first, and then the front ones.

PROPELLERS

Because the propellers come attached to the aircraft, the following instructions apply if you need to reinstall propellers.

Attaching the Propellers

1. Power off the aircraft.
2. Pair the propellers and corresponding motors according to the white mark .
3. Press each propeller down firmly and rotate in the lock direction to securely attach the propeller.



Detaching the Propellers

1. Power off the aircraft.
2. Press each propeller down firmly and rotate in the unlock direction to detach the propeller.

LEGEND



Lock Direction: Fasten the propeller by rotating it as indicated.




Unlock Direction: Unfasten the propeller by rotating is as indicated.


NOTE:

- Power off the aircraft before attaching or detaching propellers.
- Propellers must be undamaged and firmly attached.


PREPARING THE CONTROLLER




1. Unfold the antenna, detach the stick heads on the back of the controller handle, and screw them into the corresponding screw holes on both sides of the screen.
2. Adjust the antenna angle, and when the antenna and the back of the controller are at the angle of 180 or 260, and the antenna surface is facing the aircraft, the signal quality of the aircraft and controller will reach the optimal condition.



POWERING UP




Press and hold the power button for 2 seconds to turn on the controller.




Press and hold the power button 3 seconds to turn on the aircraft. The current battery level will be clearly displayed.

TAKE OFF

Start the motors by holding both command sticks for two seconds as shown below.



Push the left command stick slowly upward.



NOTE:


The default control stick mode is mode 2. The left stick controls the altitude and heading of the aircraft, while the right stick controls the forward, backward and sideward movements.

Before takeoff, place aircraft on a level surface, stand well clear of the rear of the aircraft.


COMMAND STICK CONTROLS(MODE 2)

Left Command Stick


Left Side View




Left Side View



Top View




Top View




Right Command Stick


Left Side View




Left Side View



Rear View



Rear View



SPECIFICATIONS

Aircraft	
Operating Frequency	902~928MHz (FCC);2.4~2.4835GHz;5.725~5.850GHz (Non-Japan);5.650-5.755GHz (Japan)
Transmission Power (EIRP)	900MHz: FCC/ISED<=31dBm 2.4GHz: FCC/ISED<=32dBm;CE/MIC/RRRC/RCM<=20dBm 5.8GHz/5.7GHz: FCC/ISED/RRRC/MIC<=33dBm; CE/RCM<=14dBm
Remote Controller	
Operating Frequency	902~928MHz (FCC);2.4~2.4835GHz;5.725~5.850GHz (Non-Japan);5.650-5.755GHz (Japan)
Transmission Power (EIRP)	FCC: ≤33dBmCE: ≤20dBm@2.4G , ≤14dBm@5.8G/5.7G RRRC: ≤20dBm@2.4G , ≤33dBm@5.8G/5.7G

FCC and ISED Canada Compliance

This device complies with part 15 of the FCC Rules and ISED Canada licence-exempt RSS standards. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

18th Floor, Block C1, Nanshan iPark, No. 1001 Xueyuan Avenue,
Nanshan District, Shenzhen, Guangdong, 518055, China
22522 29th Dr SE, Ste 101 Bothell, WA 98021 United States
Toll-free: (844) MY AUTEL or (844) 692-8835

www.autelrobotics.com

©2022 Autel Robotics Co., Ltd. All Rights Reserved

Documents / Resources



[AUTEL ROBOTICS EVO II RTK V3 Series Rugged Bundle Camera Drone](#) [pdf] User Guide
EVO II RTK V3 Series Rugged Bundle Camera Drone, Rugged Bundle Camera Drone, Camera Drone

References

- [Autel Robotics Enterprise Drone, Quadcopter & UAV for Sale | Leader in Drones](#)