



AVCOMM 620GX4 Ethernet Switch Installation Guide

[Home](#) » [AVCOMM](#) » AVCOMM 620GX4 Ethernet Switch Installation Guide 



Contents

- 1 AVCOMM 620GX4 Ethernet Switch Installation Guide
- 2 Overview
- 3 Package Checklist
- 4 Installation
- 5 Appearance
- 6 Indicator
- 7 Safety Precautions
- 8 Management
- 9 Support
- 10 Warranty
- 11 Disclaimer
- 12 Documents / Resources
 - 12.1 References

AVCOMM 620GX4 Ethernet Switch Installation Guide



620GX4
16+4G1000M Managed
Ethernet Switch

www.avcomm.cn

Overview

620GX4 is 16-port 10/100Base-TX RJ-45 and 4-port 10/100 Base-FX managed Ethernet switch with reverse polarity protection of DC input. It has ingenious appearance design and supports DIN Rail-mounted to facilitate in

various industrial network applications.

Package Checklist

- 1 x Product Unit
- 1 x Quick Installation Guide


Installation

For avoiding system damage by noise or electric shock, establish a direct connection between the grounding screw and the grounding surface prior to connecting devices.

DIN Rail-mounted


To mount the switch on the DIN Rail track, insert the upper end of the DIN-Rail clip into the back of the DIN-Rail track from its upper side and lightly push the bottom of the DIN-Rail clip into the track. The DIN Rail should comply with DIN EN50022 standard.

Using wrong DIN rail may cause unsafe installation.




Wiring the Power Input

1. Insert the positive and negative wires into the V+ and V- contact on the terminal block connector.
2. Tighten screws when the wire is connected.
3. Connect the power wires to suitable DC Switching type power supply.



Appearance



1. DIN-Rail clip
2. Grounding screw
3. Power & relay alarm input terminal
4. Relay alarm indicator
5. Power indicator P1 P2
6. Reset

7. Run indicator
8. Console port
9. 1000Base-X port
10. Company logo
11. 10/100Base-TX port
12. 10/100Base-TX port indicator

Indicator

LED	Status	Description
P1 P2	Green On	Power is in normal condition
	Green Off	Power is abnormal or power failure
FAIL	Red On	With alarm output
	Red Off	Without alarm output
RUN	Green Blinking	Normal running
	Green On/Off	Abnormal running
Fiber port	Green On	Normal running
	Green Blinking	Network is established
	Green Off	Link is not ready or link failure

RJ45	Green On Amber On	100Base network is ready
	Green On Amber Blinking	100Base network is established
	Amber On Green Off	10/100Base network is ready or link failure
	Amber Blinking	10/100Base network is established
	Amber Off	Link is not ready or link failure

Safety Precautions

- Keep DC power off before connecting to the terminal block connectors and ensure all connections are secure established.
- Do make sure that models connect to the corresponding supply voltage. The device is to be supplied by Limited Power Supply. The relay contact supports 0.5 A current, DC 24V Do not touch the surface of the switch while it is in operation!

Management

This device supports both in-band and out-of-band network management. The user can either configure the device through the user-friendly Web/HTTPS management or remotely manage the device through the network by console management or Telnet/SSH.

1. Web management. Before start, confirm that device is properly connected in the network and that each PC in

this network can access the router through the web browser (Google Chrome, Internet Explorer, Mozilla Firefox).

- Type http://IP address in the address bar (Default IP address is http://192.168.1.254/)
- Enter the username and password in Login screen and click Login.
- The default username and password are admin.
- You are required to change your password at first login. the welcome page of the web-based management interface will pop up when password is changed.
- On the left side you can see the list of software features, on the right side — available settings.

Make sure that the IP Address of the PC is accessed in the same subnet(192.168.1 .x).

2. Console management (using RS232 Port):

- Connect console cable between your PC and the device.
- Start Program SecureCRT-» Rapid connection.
- Give a name to a new console connection.
- Choose the COM name(COM6) and select correct serial settings:
- Baud Rate: 115200 1 Parity: None / Data Bit: 8 1 Stop Bit: 1/control of flow: None
- Enter the username and password to login after connected (for default system administrator, both username and password are admin. For general user, both username and password are guest).
- Follow the User Manual to configure the software features.

3. Telnet management. The router can be connected by Telnet and the command-lines. Steps to open Telnet connection to the router are as follow:

- Start Open Command prompt •Enter
- Type the username and password of Telnet, the default value are admin.
- Type the managed IP address of the Ethernet port that connected with the PC and press Enter until "Username" appears to be entered.

SSH (Secure Shell)

The device also supports SSH console. You can remotely connect to the switch to access command line interface. The SSH connection can secure all the configuration commands you sent to the switch.

SSH is a client/server architecture while the Switch is the SSH server.

When you want to make SSH connection with the switch, you should download the SSH client tool first.

SSH Client

There are many free, sharewares, trials or charged SSH clients you can find on the internet.

- For further feature configurations, please refer to User Manual.

Support

At AVCOMM, you can use the online service forms to request the support. The submitted forms are stored in server for AVCOMM team member to assign tasks and monitor the status of your service. Please feel free to write to sales@avcomm.cn if you encounter any problems.

Warranty

5-year Global warranty are available for AVCOMM products assuring our customers that the products shall remain free from defects in workmanship or materials and conform in all material respects to AVCOMM specifications, or purchasers supplied and accepted specifications. The warranty is limited to the repair and/or replacement, at AVCOMM sole discretion, of the defective product during its warranty period. The customer must obtain a Return Merchandise Authorization (RMA) approval code prior to returning the defective Product to

AVCOMM for service. The customer agrees to prepay shipping charges, to use the original shipping package or equivalent, and to ensure the product or assume the risk of loss or damage in transit. repaired or replaced products are warranted for ninety (90) days from the date of repair or replacement, or for the remainder of the original product's warranty period, whichever is longer.

Disclaimer


AVCOMM reserves the right to make changes to this QIG or to the product hardware at any time without notice. It is the user's responsibility to determine whether there have been any such updates or amendments herein.

Defects, malfunctions, or failures of the warranted Product(s) caused by damage resulting from unforeseeable incidents (such as lightings, floods, fire, etc.), environmental and atmospheric disturbances, other external forces such as power line disturbances and surge, host computer malfunction and virus, incorrect power input, or incorrect cabling, incorrect grounding and damages caused by misuse, abuse and unauthorized alteration or repair are not warranted.

www.avcomm.cn

Read More About This Manual & Download PDF:

Documents / Resources

	AVCOMM 620GX4 Ethernet Switch [pdf] Installation Guide 620GX4 Ethernet Switch, 620GX4, Ethernet Switch, Switch
---	---

References

- ▶ [é!-é!µ | á@%.é€\\$æ©á^ä¿;æ~æ\\$€æœï¼^â€—äº-ï¼%.æœ%.é™á...¬â](#)