

AzureWave
AW-BTA03 Bluetooth
5.2 Module



AzureWave AW-BTA03 Bluetooth 5.2 Module User Guide

[Home](#) » [AzureWave](#) » AzureWave AW-BTA03 Bluetooth 5.2 Module User Guide 

Contents

- 1 AzureWave AW-BTA03 Bluetooth 5.2 Module
- 2 Reference Schematic
- 3 Specifications
- 4 Product Usage Instructions
- 5 Reference Schematic
- 6 Frequently Asked Questions
- 7 Documents / Resources
 - 7.1 References

AzureWave

AzureWave AW-BTA03 Bluetooth 5.2 Module




Revision History


Version	Revision Date	Description	Initials	Approved
A	2024/08/21	I Initial Version	YuFu Chen	NC Chen

Reference Schematic


- The VBAT pin must have capacitor C1 (0.1uF) placed as close as possible to the pin 36, 37.



- The VDDIO pin must have capacitor C2 (0.1uF) placed as close as possible to pin 39.



- Reference Schematic



Specifications

- **Model:** AW-BTA03
- **Bluetooth Version:** 5.2
- **Application:** Automotive

Product Usage Instructions

Design Guide

The AW-BTA03 is a Bluetooth 5.2 module designed specifically for automotive applications. To ensure proper functionality and performance, please follow the design guide provided below.

Reference Schematic

- **VBAT Pin:** Capacitor C1 (0.1uF) must be placed as close as possible to pin 36, 37.
- **VDDIO Pin:** Capacitor C2 (0.1uF) must be placed as close as possible to pin 39.

Frequently Asked Questions



Q: Can the AW-BTA03 module be used in non-automotive applications?

A: The AW-BTA03 module is specifically designed for automotive applications and may not be suitable for other use cases.

Q: Is it necessary to follow the reference schematic for proper module functionality?

A: Yes, following the reference schematic provided is crucial to ensure optimal performance and reliability of the AW-BTA03 module.

Documents / Resources

	AzureWave AW-BTA03 Bluetooth 5.2 Module [pdf] User Guide AW-BTA03 Bluetooth 5.2 Module, AW-BTA03, Bluetooth 5.2 Module, 5.2 Module
	AzureWave AW-BTA03 Bluetooth 5.2 Module [pdf] User Guide AW-BTA03 Bluetooth 5.2 Module, AW-BTA03, Bluetooth 5.2 Module, 5.2 Module

References

- [User Manual](#)