

BANNER K50Z Multipoint Sensor



BANNER K50Z Multipoint Sensor Instruction Manual

[Home](#) » [BANNER](#) » BANNER K50Z Multipoint Sensor Instruction Manual 

Contents

- 1 [BANNER K50Z Multipoint Sensor](#)
- 2 [Product Description](#)
- 3 [Features and Indicators](#)
- 4 [Installation Instructions](#)
- 5 [Getting Started](#)
- 6 [Software Overview](#)
- 7 [Banner Measurement Sensor Workspace](#)
- 8 [Configuring a Sensor](#)
- 9 [Factory Default Settings](#)
- 10 [Specifications](#)
- 11 [Update the Software](#)
- 12 [Accessories](#)
- 13 [Product Support](#)
- 14 [Documents / Resources](#)
 - 14.1 [References](#)
- 15 [Related Posts](#)



BANNER K50Z Multipoint Sensor



Product Description

Wide area height and presence measurement sensor. Patent pending.

- 3D Time of Flight technology to measure nearest distance and average distance of a target area.
- Configurable sensing range up to 2-meter range with a wide, 45 × 45 degree field of view.
- Sensor monitors entire sensing region of interest, not a single point like an ultrasonic or laser sensor.
- Completely self-contained: no external lighting, controller, or PC required.
- Compact IP67 housing designed for industrial environments.
- Available with dual discrete outputs and IO-Link for advanced configuration and diagnostics.

WARNING:

- Do not use this device for personnel protection
- Using this device for personnel protection could result in serious injury or death.
- This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A device failure or malfunction can cause either an energized (on) or de-energized (off) output condition.

Models


Models	Detection Range	Supply Voltage	Output	Resolution	Field of View
K50Z-FA2000KD-Q8	20 mm to 2 m	10 V DC to 30 V DC	Dual Discrete (NPN/PP), Pulse Pro, IO link	8 × 8	45 × 45 degrees

Overview

The K50Z is an optical sensor that operates on the principals of time-of-flight technology to measure many points in the field of view. These points are used to calculate and track meaningful values such as nearest distance or average distance. The sensor uses infrared light that is reflected back to an imager with 64 measurement points to evaluate targets in a large area. The sensor can be configured by IO-link or in the Banner Measurement Sensor software. It has two outputs that can be set up independently of one another.

Features and Indicators

LED indicators provide ongoing indication of sensing status.


		LED	Color and Quantity	Description
	1	Power	One green	Power ON
	2	Output 1, on the left	Two amber	Discrete output 1 status
	3	Output 2, on the right	Two amber	Discrete output 2 status

Laser Description and Safety Information

CAUTION:

- Return defective units to the manufacturer.
- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- Do not attempt to disassemble this sensor for repair. A defective unit must be returned to the manufacturer.

Class 1 lasers are lasers that are safe under reasonably foreseeable conditions of operation, including the use of optical instruments for intra beam viewing.



Complies with 21 CFR 1040.10 and 1040.11, except for deviations pursuant to Laser Notic No. 56, dated May 8, 2019. Complies with IEC 60825-1:2014 and EN 60825-1:2014+A11:2021.

Banner Measurement Sensor Software



Use the Banner Measurement Sensor software to:

- Quickly configure the sensor
- Easily monitor device status via the software
- Visualize the application in real-time
- Make adjustments to sensor settings on the fly

Mount the Device

1. If a bracket is needed, mount the device onto the bracket. Mount the device (or the device and the bracket) to the machine or equipment at the desired location.
2. Do not tighten the mounting screws at this time.
3. Check the device alignment.
4. Tighten the mounting screws to secure the device (or the device and the bracket) in the aligned position.


Getting Started

Install the Software

IMPORTANT: Administrative rights are required to install the Banner Measurement Sensor software.

1. Download the latest version of the software from www.bannerengineering.com.
2. Navigate to and open the downloaded file.
3. Click Install to begin the installation process.
4. Depending on your system settings, a popup window may appear prompting to allow Banner Measurement Sensor to make changes to your computer. Click Yes.
5. Click Close to exit the installer.

Connect to the Sensor




- **A** = Pro Converter Cable (MQDC-506-USB)
- **B** = Splitter (CSB-M1251FM1251M)
- **C** = PC running Banner Measurement Sensor software
- **D** = K50Z
- **E** = Power Supply (PSW-24-1 or PSD-24-4)
- **F** = Optional 5-Pin to 5-Pin Double-Ended Cordset (ex. MQDEC3-515SS)

1. Connect the sensor to the Pro Cable. See “Configuration Tools” on page 23.
2. Connect the Pro Converter cable to the PC.
3. Open the Banner Measurement Sensor Software. Go to Sensor > Connect on the Navigation toolbar.
4. The Connection screen displays.
5. Select the correct Sensor Model and Com Port for the sensor. Click Connect. The Connection screen closes and the sensor data displays.

Software Overview

Easy setup and configuration of range, sensitivity, and output using the Banner Measurement Sensor software and Pro Converter Cable.



1. **Navigation toolbar**—Use this toolbar to connect to the sensor, to save or load a configuration, or to reset to factory defaults
2. **Observation Space**—Shows the entire sensor field of view and displays different items as they are selected from the legend
3. **Observation Legend**—Select what is viewable on the 3D View tab, such as the switch point planes and regions of interest
4. **Summary Pane**—Displays the live outputs numerically and shows information about each discrete configuration
5. **Sensor Settings pane**—Set the sensor parameters in this pane
6. **Status bar**—Shows whether the sensor is connected and if a software update is available
7. **Live Sensor Data controls**—Use these controls to record, pause, and play real-time sensor data, and to refresh the sensor connection.

Banner Measurement Sensor Workspace

Navigation Toolbar

Use this toolbar to connect to the sensor, to save or load a configuration, or to reset to factory defaults.

From the File menu, the following options are available:

- **Load Configuration**

Load a configuration to the connected sensor. Use this option to set up multiple sensors with the same parameters.

- **Save Configuration**

Save a configuration to a desired location for future use.

- **Reset Frequently Used Settings**

Resets the software settings without changing the configuration of the attached sensor.

- **Exit**

Exit the Banner Measurement Sensor software.

From the Sensor menu, the following options are available:

- **Connect**

Connect to the sensor.

- **Disconnect**

Disconnect from the sensor.

- **Factory Reset**

Select to perform a factory reset on the sensor. All custom parameters will be lost

From the Help menu, the following option is available:

- **About**

Select to view the software version number, the copyright notice, and the warranty.

Observation Space

The Observation Space displays the live data as the sensor sees it in real time. Up to sixty-four individual measurement points will be seen in the sensor's field of view, and by default the sensor is using all of the data when reporting a measurement. What is displayed may change based on user selections from the legend.

3D View Tab

Displays the 3D image of what the sensor sees. The entire sensor field of view can be seen, and the image changes when a target is presented. To manipulate the 3D image, click and hold the left mouse button to rotate the image. Click and hold the right mouse button to pan the image. Rotate the wheel button to zoom in and out of the image. The Visual controls can also be used to move the image. The two bar graphs represent Discrete 1 (red) and Discrete 2 (blue). The measurement displays on the graph as a moving bar. When the output is ON, the bar is green. When the output is OFF, the bar is grey. The solid red or blue lines represent switch points. The dashed lines represent the hysteresis values. By default, the sensing direction is from top to bottom on the screen. Double-click a bar graph to flip the sensing direction and present as bottom to top of screen.

2D View Tab

Displays a 2D representation of all the pixels in the field of view of the sensor. There are two numbers in each pixel. The top number is the distance from the sensor, in millimeters. The bottom number is the excess gain. Rotate the wheel button to zoom in and out of the image. Click on an individual pixel to display the coordinate data and the excess gain in the lower right corner.

Filter Pane

Use the Filter pane in the lower left corner to change how data is viewed on the 2D View and 3D View tabs.

- **Pixel Filter:** Select what pixel data to view in the Observation Space.
 - All = All data
 - Discrete1 = Only pixels in the active sensing zone of discrete 1
 - Discrete2 = Only pixels in the active sensing zone of discrete 2
 - D1 or D2 = Pixels in either the active sensing zone of discrete 1 or discrete 2
 - None = No pixel data is displayed

- **Colorization:** Select the variable to base the color of the pixel on. The options are:
 - Excess Gain
 - Distance
- **Palette:** Select the color scale to show in the Observation Space. The options are:
 - RGB
 - RB
 - Grayscale
- **Excess Gain:** Set a range from 1 to 50000. Available when Colorization is set to Excess Gain.
- **Distance (mm):** Set a range from 1 mm to 2000 mm. Available when Colorization is set to Distance.

Observation Legend

The Observation Legend controls what is displayed in the Observation Space of the 3D View tab. Red items relate to Discrete 1 and blue items relate to Discrete 2. Select or clear the checkboxes to show or hide the information.

- **Discrete Output**
Displays everything associated with the respective output.
- **Switch Point**
Displays a solid plane where the switch point is located, or 2 planes if in window mode.
- **Measured Value**
Displays a translucent plane that tracks with the current sensor measurement.
- **3D ROI**
Displays a customizable 3D box that represents the active sensing area for that output. The sensor will not account for pixels outside of this area for its measurement.
- **View X, Y, Z axis**
Displays the X, Y, and Z axes with the origin at the face of the sensor.
- **Sensor Field of View**
Displays a grey representation of the full viewing area of the sensor.
- **Visual controls**
The Visual controls are located in the upper left corner. Click the arrow if they are not visible. Click the buttons to move and rotate the image in the Observation Space. Click Reset View to reset the orientation of the image in the Observation Space.

Summary Pane

The Summary pane (blue shaded area) displays Discrete 1 State/Discrete 2 State and Discrete 1 Measurement/Discrete 2 Measurement, which is either Average Distance or Nearest Distance.

State

Displays whether the output is ON (green) or OFF (grey).

Measurement

Displays the distance to the target, depending on the Measurement Mode used (see “Discrete 1 Tab” on page 12 and “Discrete 2 Tab” on page 12).

- If Average Distance is used, the distance is the average of all pixels in that output’s active sensing area.
- If Nearest Distance is used, the distance is the closest measured point from the face of the sensor in the active sensing area.

Sensor Settings Pane

Set parameters for the sensor. Click Read to read the current parameters of the connected sensor. Click Write to write the parameters to the sensor. Yellow highlight on a parameter's value indicates changes that have not yet been written to the sensor.

General Tab

The following are the parameters on the General tab on the Sensor Settings pane.

Resolution

The sensor can operate at two resolutions:

- **Standard 8×8:** Best for utilizing as much of the available sensor information as possible.
- **Reduced 4×4:** Best for faster response time.

Response Speed

The available options depend on which resolution is selected.

- **Fast:** Operates as quickly as the sensor is able.
- **Medium:** Reduces outlier measurements.
- **Slow:** Longer shutter for improved repeatability and accuracy in low excess gain.

Resolution	Speed (ms)		
	Fast	Medium	Slow
Standard 8×8	140	270	500
Reduced 4×4	35	75	140

Sensor Polarity

Define the output and remote input signal type.

Sensor Lockout

Enable or disable the remote input wire.

Mounting Correction

Use the Pitch, Yaw, Roll sliders to apply a transform to the point cloud data to account for non-perpendicular mounting angles.

Discrete 1 Tab

The following are the parameters on the Discrete 1 tab on the Sensor Settings pane.

Measurement Mode

- **Nearest distance:** The sensor responds to the closest target in the field of view.
- **Average distance:** The sensor responds to the average pixel measurement over the entire active sensing area.

Output Mode

- **Switch Point** – Object Ref: Creates a single switch point with the hysteresis set farther away from the sensor. The output turns ON at the switch point, and OFF at the hysteresis.
- **Switch Point** – Background Ref: Creates a single switch point with the hysteresis set closer to the sensor. The output turns ON at the hysteresis and OFF at the switch point.
- **Window**: Creates two switch points forming window limits with the hysteresis on the outside of the window.

Distance Settings

- Define the switch point(s) and the hysteresis. Use either the sliders to manually define the switch point or the Teach button to automatically define the switch point.
- **Hysteresis Mode**: Select User Defined or Dynamic. Selecting Dynamic automatically sets the hysteresis depending on the target measurement.

Active Sensing Area

2D ROI

- **Full Field**: Uses the entire 8×8 (or 4×4) pixel area for measurement.
- **Custom**: Shows an ROI Map. Clicking individual pixels turns them on or off. Colored pixels are active, and white pixels are off. Drag to select a large number of pixels, then click the selection to turn the entire selection on or off.

3D ROI

- **Full Field**: Uses the entire 3D area for measurement.
- **Custom**: Defines three different dimensions in X, Y, and Z to create the active sensing area. This 3D area shows when the 3D ROI checkbox is selected in the Observation Legend. The sensor is located at point 0,0,0 and the dimensions are defined in relation to this origin.

Output Settings

- **NO/NC**: Select Normally Open or Normally Closed from the list.
- **On Delay**: Set an on delay in milliseconds. The maximum time is 60,000 ms.
- **Off Delay**: Set an off delay in milliseconds. The maximum time is 60,000 ms.

Response Time

Displays the response time set on the General tab under Response Speed.

Discrete 2 Tab

The following are the parameters on the Discrete 2 tab on the Sensor Settings pane. This tab is available for dual discrete models.

Measurement Mode

- **Nearest distance:** The sensor responds to the closest target in the active sensing area.
- **Average distance:** The sensor responds to the average measurement over the entire active sensing area.

Output Mode

- **Switch Point** – Object Ref: Creates a single switch point with the hysteresis set farther away from the sensor. The output turns ON at the switch point, and OFF at the hysteresis.
- **Switch Point** – Background Ref: Creates a single switch point with the hysteresis set closer to the sensor. The output turns ON at the hysteresis and OFF at the switch point.
- **Window:** Creates two switch points forming window limits with the hysteresis on the outside of the window.
- **Complementary:** Output 2 will be the opposite of Output 1.
- **Pulse Pro/PFM:** PulsePro/PFM output to interface with Banner lights or a PLC with Pulse Frequency Modulated (PFM) inputs.

Distance Settings

Define the switch point(s) and the hysteresis. Use either the sliders to manually define the switch point or the Teach button to automatically define the switch point.

Hysteresis Mode: Select User Defined or Dynamic. Selecting Dynamic automatically sets the hysteresis depending on the target measurement.

Pulse Pro/PFM Settings

Available when Output Mode is set to Pulse Pro/PFM. The K50Z can generate pulses whose frequency are proportional to the sensor's measured distance, thereby providing a method for representing an analog signal with only a discrete counter. The sensing range of the sensor is scaled from 100 Hz to 600 Hz. 100 Hz equals the near range limit of the sensor, and 600 Hz equals the far sensing range limit. An output of 50 Hz or 650 Hz (user defined in the software) represents a loss of signal condition where there is no target or the target is out of range. This output can be tied directly to a number of Banner lights for visual feedback without the need for a controller.

- **100 Hz:** Define the near sensing range limit of the Pulse Pro range.
- **600 Hz:** Define the far sensing range limit of the Pulse Pro range.
- **Loss-of-Signal:** Sets the value used by the sensor during a loss of signal. When a signal is restored, measurement resumes.
- **Hold last value**—The Discrete 2 Output holds the last value indefinitely during a loss of signal.
- **50 Hz**—The Discrete 2 Output switches to this value 2 seconds after a loss of signal.
- **650 Hz**—The Discrete 2 Output switches to this value 2 seconds after a loss of signal.

Active Sensing Area

2D ROI

- **Full Field:** Uses the entire 8×8 (or 4×4) pixel area for measurement.
- **Custom:** Shows an ROI Map. Clicking individual pixels turns them on or off. Colored pixels are active, and white pixels are off. Drag to select a large number of pixels, then click the selection to turn the entire selection on or off.

3D ROI

- **Full Field:** Uses the entire 3D area for measurement.
- **Custom:** Defines three different dimensions in X, Y, and Z to create the active sensing area. This 3D area shows when the 3D ROI checkbox is selected in the Observation Legend. The sensor is located at point 0,0,0 and the dimensions are defined in relation to this origin.

Output Settings

- **NO/NC:** Select Normally Open or Normally Closed from the list.
- **On Delay:** Set an on delay in milliseconds. The maximum time is 60,000 ms.
- **Off Delay:** Set an off delay in milliseconds. The maximum time is 60,000 ms.


Response Time


Displays the response time set on the General tab under Response Speed.

Live Sensor Data Controls

After connecting to the sensor, data sampling begins automatically (but not recording).

To stop data sampling, click  **Stop**.

To restart data sampling, click  **Play**. This only samples data from the sensor and displays it on the plot; it does not record the data to a log file.

To record data to a log file, click  **Record**. The log file selection prompt displays. Save the log file as desired. The log file format is .csv.

If communication to the sensor is lost, click  **Refresh Device Connection** to reconnect.

Configuring a Sensor


Banner Measurement Sensor Software

Use the Banner Measurement Sensor software and Pro Converter Cable to set up the sensor. For more information visit www.bannerengineering.com/us/en/products/sensors/software/banner-measurement-sensorsoftware.html.

Remote Input

The remote input provides limited programming options and is Active High. This can be configured for Active Low in the Banner Measurement Sensor software by changing the Sensor Polarity. For Active High, connect the gray input wire to V+ (10 V DC to 30 V DC), with a remote switch connected between the wire and V+. For Active Low, connect the gray input wire to ground (0 V DC) with a remote switch connected between the wire and ground.

The remote input wire is disabled by default. Pulse the remote input wire 10 times or use the Banner Measurement Sensor software to enable the feature. After enabling the remote input feature, pulse the remote input according to the diagram and the instructions provided in this manual. Remote teach can also be performed using the button on the Pro Converter Cable. The length of the individual programming pulses is equal to the value T: $0.04 \text{ seconds} \leq T \leq 0.8 \text{ seconds}$. Exit remote programming modes by setting the remote input Low for longer than 2 seconds or by waiting for 60 seconds.



Remote Setup

Use Remote Setup to set the Teach mode. Changing Teach mode does not immediately change the switch point location, but will affect the behavior of the next remote Teach.

Discrete 1 or Discrete 2 Teach

Use the following procedure to teach the first and second switch points when the sensor is in Two-Point Window mode.

1. Access Discrete 1 or Discrete 2 Teach selection.

Action	Result
Discrete 1: Single-pulse the remote input. Discrete 2: Double-pulse the remote input.	Discrete 1: Power and output 1 LED flash continuously Discrete 2: Power and output 2 LED flash continuously

2. Present the first point.
3. Teach the switch point.

Action	Result
Single-pulse the remote input.	<p>Teach Accepted</p> <p>The power LED and output LED 1 or LED 2 flash three times, then the sensor returns to run mode</p> <p>Teach Not Accepted</p> <p>The power LED and output LED 1 or LED 2 flash ten times,</p> <p>then the sensor returns to run mode</p> <p>Retry teaching the first point.</p>

4. Access Discrete 1 or Discrete 2 Teach selection.

Action	Result
<p>Discrete 1: Single-pulse the remote input. Discrete 2: Double-pulse the remote input.</p>	<p>Discrete 1: Power and output 1 LED flash continuously</p> <p>Discrete 2: Power and output 2 LED flash continuously</p>

5. Present the second point.

6. Teach the switch point.

Action	Result
Double-pulse the remote input.	<p>Teach Accepted</p> <p>The power LED and output LED 1 or LED 2 flash three times,</p> <p>then the sensor returns to run mode.</p> <p>Teach Not Accepted</p> <p>The power LED and output LED 1 or LED 2 flash ten times,</p> <p>then the sensor returns to run mode.</p> <p>Retry teaching the second point.</p>







Set the Response Speed and Resolution

Use Response Speed Selection to set the response of the sensor.

1. Access Response Speed Selection

Action	Result
Five-pulse the remote input.	The power LED and all output LEDs continuously flash five times, pause, flash five times, pause, and the sequence continues.

2. Select the desired response speed.

Action			Result
Pulses		TEACH Mode	
1		Resolution, Response Speed = Reduced 4 × 4, Fast	The power LED and all output LEDs flash equal to the number of times pulsed. For example, pulsing three times sets Slow response speed with 4 × 4 resolution, and is confirmed with three flashes.
2		Resolution, Response Speed = Reduced 4 × 4, Medium	
3		Resolution, Response Speed = Reduced 4 × 4, Slow	
4		Resolution, Response Speed = Standard 8 × 8, Fast	
5		Resolution, Response Speed = Standard 8 × 8, Medium	
6		Resolution, Response Speed = Standard 8 × 8, Slow	

IO-Link Interface

IO-Link is a point-to-point communication link between a master device and sensor. Use IO-Link to parameterize sensors and transmit process data automatically. For the latest IO-Link protocol and specifications, see www.io-link.com

- Each IO-Link device has an IODD (IO Device Description) file that contains information about the manufacturer, article number, functionality etc. This information can be easily read and processed by the user. Each device can be unambiguously identified via the IODD as well as via an internal device ID. Download the K50Z's IO-Link IODD package (p/n 238988) from
- Banner Engineering's website at www.bannerengineering.com.
- Banner has also developed Add On Instruction (AOI) files to simplify ease-of-use between the K50Z, multiple third-party vendors' IO-Link masters, and the Logix Designer software package for Rockwell Automation PLCs. Three types of AOI files for Rockwell Allen-Bradley PLCs are listed below. These files and more information can be found at www.bannerengineering.com.
- **Process Data AOIs**—These files can be used alone, without the need for any other IO-Link AOIs. The job of a Process Data AOI is to intelligently parse out the Process Data word(s) in separate pieces of information. All that is required to make use of this AOI is an EtherNet/IP connection to the IO-Link Master and knowledge of where the Process Data registers are located for each port.
- **Parameter Data AOIs**—These files require the use of an associated IO-Link Master AOI. The job of a Parameter Data AOI, when working in conjunction with the IO-Link Master AOI, is to provide quasi-realtime read/write access to all IO-Link parameter data in the sensor. Each Parameter Data AOI is specific to a given sensor or device.
- **IO-Link Master AOIs**—These files require the use of one or more associated Parameter Data AOIs. The job of an IO-Link Master AOI is to translate the desired IO-Link read/write requests, made by the Parameter Data AOI, into the format a specific IO-Link Master requires. Each IO-Link Master AOI is customized for a given brand of IO-Link Master. Add and configure the relevant Banner IO-Link Master AOI in your ladder logic program first; then add and configure Banner IO-Link Device AOIs as desired, linking them to the Master AOI as shown in the relevant AOI documentation.

Reset the Sensor to Factory Defaults

Reset the sensor to factory default settings using one of two methods.

NOTE: If a factory reset is performed through the Banner Measurement Sensor software, the remote input wire becomes disabled (factory default setting). If the sensor is returned to factory default settings by using the remote input wire, the input wire remains enabled and the rest of the settings are restored to factory defaults. To reset using the Banner Measurement Sensor software, go to Sensor › Factory Reset. The sensor indicators flash once, the sensor is reset back to the factory default settings, and a confirmation message displays. To reset using the remote input, eight-pulse the remote input to apply the factory default settings.

Factory Default Settings

General Tab Default Settings

Setting	Factory Default
Resolution	Standard 8×8
Response Speed	Fast (140 ms)
Sensor Polarity	PNP (Active High)
Sensor Lockout	Teach

Discrete 1 Tab Default Settings

Setting	Factory Default
Measurement Mode	Nearest Distance
Output Mode	Switch Point – Object Ref
Distance Settings	0.3 m
Hysteresis Mode	Dynamic
Active Sensing Area	Full Field
Output Settings	Normally Open

Discrete 2 Tab Default Settings

Setting	Factory Default
Measurement Mode	Nearest Distance
Output Mode	Switch Point – Object Ref
Distance Settings	2 m
Hysteresis Mode	Dynamic
Active Sensing Area	Full Field
Output Settings	Normally Open

Specifications

Resolution	Reduced 4×4		
Response Speed (ms)	Fast (35)	Medium (70)	Slow (140)
Repeatability, 10x Excess Gain (1 σ , mm) *	2.5	2.5	1.3
Linearity, 10x Excess Gain (\pm mm)*	10	10	10
Minimum Object Separation, 10x Excess Gain (mm)*	22.5	22.5	20

*4×4 specifications defined at 20 °C, 5 minutes after power on, excludes the corner pixels.

Resolution	Standard 8×8		
Response Speed (ms)	Fast (140)	Medium (270)	Slow (500)
Repeatability, 10x Excess Gain (1 σ , mm) *	5	5	2.5
Linearity, 10x Excess Gain (\pm mm)*	10	10	10
Minimum Object Separation, 10x Excess Gain (mm)*	45	45	22.5

*8×8 specifications defined at 20 °C, 5 minutes after power on, exclude the edge pixels.

- **Minimum Hysteresis**

20 mm

- **Range**

6% Black card: 1500 mm

90% White card: 2000 mm

- **Operating Principle**

3D Time of Flight

- **Supply Voltage (Vcc)**

10 V DC to 30 V DC

- **Recommended warm-up time**

5 minutes

- **Delay at Power-up**

2 seconds

- **Power and Current Consumption, exclusive of load**

Power consumption: < 1 W

- **Supply Protection Circuitry**

Protected against reverse polarity and transient overvoltages

- **Outputs**

PFM, Dual Discrete, IO-Link

- **Flatness (Pixel to Pixel Accuracy)**

20 mm

- **Communication Protocol**

IO-Link

- **Boresighting**

\pm 2 degrees

- **Light Source:**

Infrared, 940 nm

- **Field of View**

45 × 45 degrees

Symmetrical in X, Y direction, 5.625° per pixel

- **Field of View Size**

At 20 mm: 17 mm (X) by 17 mm (Y)

At 2000 mm: 1657 mm (X) by 1657 mm (Y)

- **Ambient Light Immunity**

10,000 lux

- **Output Protection**

Protected against reverse polarity and transient overvoltages

- **Remote Input**

Remote teach in, emitter enable/disable

- **Indicators**

Power LED: Green

Output LEDs: Amber, discrete output status

- **Construction**

Housing: Polycarbonate

Window: Polycarbonate

Lens Cover: Acrylic with optical coating

- **Connections**

Integral M12 quick disconnect

Models with a quick disconnect require a mating cordset

- **Vibration and Mechanical Shock**

All models meet MIL-STD-202F, Method 201A (Vibration: 10 Hz to 60 Hz maximum, 0.06 inch (1.52 mm) double amplitude, 10G acceleration) requirements. Method 213B conditions H&I. Shock: 75G with device operating; 100G for non-operation

Impact: EN 62262IK07

- **Operating Temperature**

–10 °C to +50 °C (+14 °F to +122 °F)

- **Temperature Effect**

0.25 mm/°C while in Standard 8×8, fast mode

- **Environmental Rating**

IP67

Output Rating

Black wire specifications per configuration		
IO-Link Push/Pull	Output High:	$\geq V_{\text{supply}} - 2.5 \text{ V}$
	Output Low:	$\leq 2.5 \text{ V}$
PNP	Output High:	$\geq V_{\text{supply}} - 2.5 \text{ V}$
	Output Low:	$\leq 1 \text{ V (loads } \leq 1 \text{ Meg}\Omega)$
NPN	Output High:	$\geq V_{\text{supply}} - 2.5 \text{ V (loads } \leq 50 \text{ k}\Omega)$
	Output Low:	$\leq 2.5 \text{ V}$

White wire specifications per configuration		
Push/Pull	Output High:	$\geq V_{\text{supply}} - 2.5 \text{ V}$
	Output Low:	$\leq 2.5 \text{ V}$
PNP	Output High:	$\geq V_{\text{supply}} - 2.5 \text{ V}$
	Output Low:	$\leq 2.5 \text{ V}$ (loads $\leq 70 \text{ k}\Omega$)
NPN	Output High:	$\geq V_{\text{supply}} - 2.5 \text{ V}$ (loads $\leq 70 \text{ k}\Omega$)
	Output Low:	$\leq 2.5 \text{ V}$

FCC Part 15 Class A for Unintentional Radiators

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. (Part 15.21) Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Industry Canada ICES-003(A)

This device complies with CAN ICES-3 (A)/NMB-3(A). Operation is subject to the following two conditions:

1. This device may not cause harmful interference; and
2. This device must accept any interference received, including interference that may cause undesired operation.

PC Requirements

- **Operating System**

Microsoft® Windows® operating system version 10 or 11(1)

- **Hard Drive Space**

500 MB

1. Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.

- **Third-Party Software**

.NET


- **Port**

Available USB port

IMPORTANT: Administrative rights are required to install the Banner Measurement Sensor software.

Dimensions

All measurements are listed in millimeters [inches], unless noted otherwise.




Field of View Charts

	Distance	X/Y Field of View (mm)	X/Y Pixel Length(m m)
<p>The diagram illustrates the sensor's field of view. A red arrow points from the sensor head down to a grid of pixels. The grid is labeled 'Z - Distance' and 'X/Y - Field of View'. The grid is divided into four quadrants by red arrows labeled '+X', '-X', '+Y', and '-Y'.</p>	20	17	2
	500	414	52
	1000	828	104
	1500	1242	155
	2000	1657	207

Update the Software


Use this procedure to update the Banner Measurement Sensor software. The Banner Measurement Sensor software automatically looks for updated software versions. The symbol in the lower right corner indicates that a software update is available.

Software Update Available

Connected(Q130RA-9076-AFQ) 

1. Click in the lower right corner of the software.

The Banner Measurement Sensor software update screen displays.



2. Click Upgrade to begin the process.

The Banner Measurement Sensor software closes and an installer (BannerMeasurementSensorSoftwareInstaller.exe) downloads to the desktop.


3. Navigate to and open the file BannerMeasurementSensorSoftwareInstaller.exe.
4. Depending on your system settings, a popup window may appear prompting to allow Banner Measurement Sensor software to make changes to your computer. Click Yes.
5. Click Close to exit the installer.

The software update is complete.

Accessories


Configuration Tools

MQDC-506-USB



- Pro Converter Cable
- 1.83 m (6 ft) length 5-pin M12 quick disconnect to Device and USB to PC
- Required for connection to the configuration software

PRO-KIT Includes:



- Pro Converter Cable (MQDC-506-USB)
- Splitter (CSB-M1251FM1251M)
- Power Supply (PSW-24-1)

Cordsets


5-pin M12 Cordsets - Female Single-Ended, Straight				
Model	Length	Dimensions (mm)	Pinout (Female)	
BC-M12F5-22-1	1 m (3.28 ft)			1 = Brown 2 = White 3 = Blue 4 = Black 5 = Gray
BC-M12F5-22-2	2 m (6.56 ft)			
BC-M12F5-22-5	5 m (16.4 ft)			
BC-M12F5-22-8	8 m (26.25 ft)			
BC-M12F5-22-10	10 m (30.81 ft)			
BC-M12F5-22-15	15 m (49.2 ft)			

5-pin M12 Cordsets - Female Single-Ended, Right-Angle				
Model	Length	Dimensions (mm)	Pinout (Female)	
BC-M12F5A-22-1	1 m (3.28 ft)			1 = Brown 2 = White 3 = Blue 4 = Black 5 = Gray
BC-M12F5A-22-2	2 m (6.56 ft)			
BC-M12F5A-22-5	5 m (16.4 ft)			
BC-M12F5A-22-8	8 m (26.25 ft)			
BC-M12F5A-22-10	10 m (30.81 ft)			
BC-M12F5A-22-15	15 m (49.2 ft)			

5-pin M12 Cordsets – Female Single-Ended, Right-Angle

Brackets


SMBK50RA



- Right-angle bracket

- 14-gauge 304 stainless steel

SMBAMSK50R



- Adjustable mounting bracket
- 14-gauge 304 stainless steel

Product Support

Clean with Compressed Air

Handle the sensor with care during installation and operation. Sensor windows soiled by fingerprints, dust, water, oil, etc. may create stray light that may degrade the peak performance of the sensor. Blow dust from the sensor using filtered, compressed air.

Repairs

Contact Banner Engineering for troubleshooting of this device. Do not attempt any repairs to this Banner device; it contains no field-replaceable parts or components. If the device, device part, or device component is determined to be defective by a Banner Applications Engineer, they will advise you of Banner's RMA (Return Merchandise Authorization) procedure.

IMPORTANT: If instructed to return the device, pack it with care. Damage that occurs in return shipping is not covered by warranty.

Contact Us

Banner Engineering Corp. headquarters is located at: 9714 Tenth Avenue North | Minneapolis, MN 55441, USA | Phone: + 1888 373 6767

For worldwide locations and local representatives, visit www.bannerengineering.com.

Banner Engineering Corp. Software Copyright Notice

© Banner Engineering Corp., All Rights Reserved.

<https://www.bannerengineering.com/us/en/company/terms-and-conditions.html>

Disclaimer of Warranties. This software is provided "AS-IS." To the maximum extent permitted by applicable law, Banner, its affiliates, and its channel partners disclaim all warranties, expressed or implied, including any warranty that the software is fit for a particular purpose, title, merchantability, data loss, noninterference with or non-infringement of any intellectual property rights, or the accuracy, reliability, quality or content in or linked to the services. Banner and its affiliates and channel partners do not warrant that the services are secure, free from bugs, viruses, interruption, errors, theft or destruction. If the exclusions for implied warranties do not apply to you, any implied warranties are limited to 60 days from the date of first use of this software. Limitation of Liability and Indemnity. Banner, its affiliates and channel partners are not liable for indirect, special, incidental, punitive or consequential damages, damages relating to corruption, security, loss or theft of data, viruses, spyware, loss of business, revenue, profits, or investment, or use of software or hardware that does not meet Banner minimum systems requirements. The above limitations apply even if Banner and its affiliates and channel partners have been advised of the possibility of such damages. This Agreement sets forth the entire liability of Banner, its affiliates and your exclusive remedy with respect to the software use.

Banner Engineering Corp Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE. This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.


Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com. For patent information, see

www.bannerengineering.com/patents.






© 2024. All rights reserved.

www.bannerengineering.com

Documents / Resources

	BANNER K50Z Multipoint Sensor [pdf] Instruction Manual K50Z Multipoint Sensor, K50Z, Multipoint Sensor, Sensor
---	--

References

-  [Patents](#)
-  [Sensor Software](#)
-  [IO-Link](#)
-  [Banner Engineering](#)
-  [Terms and Conditions of Sale](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.