

[Skip to content](#)

Manuals+

User Manuals Simplified.



BANNER ZMX Series 3D Time of Flight Sensor User Guide

[Home](#) » [BANNER](#) » BANNER ZMX Series 3D Time of Flight Sensor User Guide



more sensors, more solutions

User Guide

ZMX Series 3D Time of Flight Sensor

Contents [hide](#)

- [1 ZMX Series 3D Time of Flight Sensor](#)
- [2 Features and Indicators](#)
- [3 Laser Description and Safety Information](#)
- [4 Installation Instructions](#)
- [5 Install the Software](#)
- [6 Getting Started](#)
- [7 Specifications](#)
- [8 Warranty](#)
- [9 Documents / Resources](#)
- [9.1 References](#)
- [10 Related Posts](#)

ZMX Series 3D Time of Flight Sensor

Simple, reliable, volume and height monitoring with ZMX Series. Patent pending.

This guide is designed to help you set up and install the ZMX Series. For complete information on programming, performance, troubleshooting, dimensions, and accessories, please refer to the Instruction Manual at www.bannerengineering.com. Search for p/n 230551 to view the Instruction Manual. Use of this document assumes familiarity with pertinent industry standards and practices.

Features and Indicators

LED indicators provide ongoing indication of sensing status.




Figure 1. Features

1. Power and Fault LED (off, green, red, or flashing red)
2. Ready LED
3. Image Transmitted LED
4. Ethernet Activity LED
5. Ethernet connection
6. Power connection

Laser Description and Safety Information



CAUTION:

- Return defective units to the manufacturer.
- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- Do not attempt to disassemble this sensor for repair. A defective unit must be returned to the manufacturer.

Class 1 lasers are lasers that are safe under reasonably foreseeable conditions of operation, including the use of optical instruments for intrabeam viewing.

CLASS 1

LASER PRODUCT

Complies with 21 CFR 1040.10 and 1040.11, except for deviations pursuant to Laser Notice No. 56, dated May 8, 2019.

Complies with IEC 60825-1:2014 and EN 60825-1:2014+A11:2021.

Installation Instructions

Mount the Device

1. If a bracket is needed, mount the device onto the bracket.
2. Mount the device (or the device and the bracket) to the machine or equipment at the desired location. Do not tighten the mounting screws at this time.




CAUTION: This device accepts M4 screws. Engaging the screws more than 4 mm will damage the device.



CAUTION: 8 in-lbf (0.904 Nm) maximum torque

3. Check the device alignment.
4. Tighten the mounting screws to secure the device (or the device and the bracket) in the aligned position.

Figure 2. Mounting Holes



Note: Do not remove the housing screws.

Note: Provide adequate dissipation of heat. A good heat conductor, such as aluminum, may be required.

Mounting Surface Thickness

- ≤ 2 mm
- 2 mm to 4 mm
- 4 mm to 6 mm

Length of Mounting Screws

- 4 mm
- 6 mm
- 8 mm

Wiring

To maintain the ratings listed in the Specifications, use cables with shields.
Tighten the cables finger tight only.





Figure 3. Channel 1 as PNP Output, Channel 2 as Trigger Input

Figure 4. Channel 1 as NPN Output,



Channel 2 as Trigger Input
Power and I/O Pinouts




Figure 5. M8 Male Connector

Table 1:

Pin	Wire Color	Description
1	Brown	12 V DC to 30 V DC
2	White	Trigger Input or Output (selectable PNP, NPN, or push-pull)
3	Blue	Common
4	Black	Output (selectable PNP, NPN, or push-pull)

Install the Software

Use the following instructions to install the Banner 3D Configuration software on your computer.

PC Requirements

Operating System

Microsoft® Windows® operating system version 8, 10, or 11¹

Hard Drive Space

100 MB

Screen Resolution

1024 × 768 pixels

Memory (RAM)

500 MB

Ports Needed

TCP/IP port 32000

TCP/IP port 32200

UP/IP Port 19995

★ **Important:** Administrative rights may be required to install the Banner 3D Configuration software.

1. Download the latest version of the software from www.bannerengineering.com.
2. Navigate to and open the downloaded file.
3. Run the downloaded installer.


4. Check the agreement for license terms and conditions.
5. Click Install to install the software.
A Windows security message displays. This indicates that the installer is signed and is from Banner.
6. Click Yes.
7. Click Close to exit the installer when the installation is complete.
8. Locate the program icon on the desktop or in the **Start** menu and open the Banner 3D Configuration software.

¹Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Getting Started

Connect to the Sensor


These instructions use Windows® operating system version 8, 10, or 11.²

1. Confirm the network connections.
 - a) Click the Start button, then on the Start menu, click Control Panel.
 - b) In Control Panel, click Network and Internet, then click Network and Sharing Center, and then click Change adapter settings.
 - c) Right-click on the connection that you want to change, then click Properties.
 If you are prompted for an administrator password or confirmation, enter the password or provide confirmation.
 - d) In the connection properties, click Internet Protocol Version 4 (TCP/IPv4), and then click Properties.
 - e) In the Internet Protocol (TCP/IPv4) Properties, select Use the following IP address.
 - f) Make sure that the IP address is **192.168.0.2** (or an unused IP address within the **192.168.0.x** subnet), and the subnet mask is **255.255.255.0**.
2. Open the Banner 3D Configuration software from the desktop or the Start menu.
3. Connect to the ZMX sensor using one of the following options:
 - From the Connection pane, enter the IP address of the desired ZMX sensor into the Sensor IP Address field, then click Connect.
 - From the Connection pane, locate the IP address of the desired sensor in the list of discovered sensors, then click  next to IP Address.
 The default IP address for the sensor is **192.168.0.10**.

Banner 3D Configuration Workspace

The Banner 3D Configuration software displays the information needed to modify sensor parameters.

Figure 6. Banner 3D Configuration Software



The workspace is divided into several panes.

1. Image Pane Parameters—Includes zoom; x, y, z coordinates; image color; view selection (Amplitude, Z(mm), Points, Surface). The options vary depending on the selected view.
2. Image pane—Displays the current image captured by the sensor and includes the buttons:
 - Load Image—Loads a previously saved file for viewing while disconnected from the sensor
 - Save Image—Save file as a .t3f
 - Trigger—Manually triggers the sensor when Trigger mode is set to External or Software
3. Connection pane—Enables connection to a sensor and includes settings and information related to the sensor's IP address.
4. Sensor Controls pane—Controls the trigger mode and illumination output.
5. Fill Level pane—Includes options for the region of interest and sensor controls, as well as live fill and peak height data.
6. Communications pane—Sets the communication protocol and DHCP option for the sensor.
7. Sensor Maintenance pane—Includes sensor information and options to update the firmware, restore the sensor to the default settings, to backup the current sensor settings, or restore the sensor to previously saved settings.

Specifications

Sensing Range

200 mm to 2500 mm (7.9 in to 8.2 ft) on a 90% reflectance white target
 200 mm to 2500 mm (7.9 in to 8.2 ft) on a 20% reflectance gray target
 200 mm to 1700 mm (7.9 in to 5.6 ft) on a 6% reflectance black target

Supply Voltage

12 V DC to 30 V DC

Current: 200 mA average, 2.5 A peak (exclusive of load and lights)

Use only with a suitable Class 2 power supply, or current-limiting power supply rated

12 V DC to 30V DC, 2.5 A

Discrete I/O Configuration

Channel 1: Push-pull, PNP or NPN discrete output, or Pulse Pro/Pulse Frequency Modulation (PFM) output

Channel 2: PNP or NPN discrete output, or Pulse Pro/Pulse Frequency Modulation (PFM) output, or remote trigger

Flatness (Pixel-to-Pixel Accuracy)

±20 mm for > 10x excess gain
 ±60 mm for 2x to 10x excess gain

Response Time

150 ms in Free Run mode

Accuracy

±30 mm for > 10x excess gain³

Repeatability (1-sigma)

Peak excess gain: 2 mm
 >10x excess gain, 10 mm
 >2x excess gain, 40 mm

Communication Interface

Ethernet; 100 Mbps


Communication Protocol⁴

Modbus® TCP/IP
EtherNet/IP™
Boresighting
±20 mm at 1 m range
Delay at Power Up
< 10s
Recommended Warm Up Time
15 minutes
Output Rating
Current rating: 50 mA maximum
Light Source
Infrared, 850 nm
Temperature Effect
< 0.5 mm/°C
Resolution
272 horizontal × 208 vertical pixels
Field of View
60 horizontal × 45 vertical degrees
Reading Rate, Full Resolution
Up to 6 frames per second in Free Run mode
Ambient Light Immunity
10,000 lux
Torque—Tapped Holes for Mounting Screws
8 in-lbf (0.904 Nm) maximum torque
Torque—Cables
Finger tighten only
Construction
Housing: Aluminum
Lens Cover: Acrylic with optical coating
Light Pipe: Polycarbonate
Connections
4-pin M8 male for power and discrete I/O
4-pin M8 female for Ethernet
Storage Conditions
–30 °C to +65 °C (–22 °F to +149 °F)
Operating Conditions
–10 °C to +40 °C (+14 °F to +104 °F), assuming adequate mounting and ventilation
Environmental Rating
IP65 per IEC60529
Vibration
MIL-STD-202G, Method 201A (Vibration: 10 Hz to 55 Hz, 0.06 inch (1.52 mm) double amplitude, 2 hours each along X, Y and Z axes), with device operating
Shock
MIL-STD-202G, Method 213B, Condition I (100G 6x along X, Y, and Z axes, 18 shocks), with device operating
Weight
205 g

White wire specifications per configuration

PNP	Output High	≥ Vsupply – 2.5 V
	Output Low	≤ 2.5 V (loads ≤ 70 kΩ)
NPN	Output High	≥ Vsupply – 2.5 V
	Output Low	≤ 2.5 V

Required Overcurrent Protection

 **WARNING:** Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations. Overcurrent protection is required to be provided by end product application per the supplied table. Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply. Supply wiring leads < 24 AWG shall not be spliced. For additional product support, go to www.bannerengineering.com.


Supply Wiring (AWG)	Required Overcurrent Protection (Amps)
20	5.0
22	3.0
24	2.0
26	1.0
28	0.8
30	0.5

Certifications



EtherNet/IP®

 Banner Engineering BV Park Lane, Culliganlaan 2F bus 3, 1831 Diegem, BELGIUM

 Turck Banner LTD Blenheim House, Blenheim Court, Wickford, Essex SS11 8YT, Great Britain

Advanced Capabilities



- For 6% to 90% diffuse targets in the center 25% of the field of view.
- ± 60 mm accuracy for 2x to 10x excess gain.

4. Modbus® is a registered trademark of Schneider Electric USA, Inc. EtherNet/IP™ is a trademark of ODVA, Inc. Refer to the Instruction Manual, p/n 230551, for FCC and Industry Canada notification statements.

Warranty

Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to:

www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.

Banner Engineering Corp. Software Copyright Notice

© Banner Engineering Corp., All Rights Reserved.

<https://www.bannerengineering.com/us/en/company/terms-and-conditions.html>

Disclaimer of Warranties. This software is provided "AS-IS." To the maximum extent permitted by applicable law, Banner, its affiliates, and its channel partners disclaim all warranties, expressed or implied, including any warranty that the software is fit for a particular purpose, title, merchantability, data loss, non-interference with or non-infringement of any intellectual property rights, or the accuracy, reliability, quality or content in or linked to the services. Banner and its affiliates and channel partners do not warrant that the services are secure, free from bugs, viruses, interruption, errors, theft or destruction. If the exclusions for implied warranties do not apply to you, any implied warranties are limited to 60 days from the date of first use of this software.

Limitation of Liability and Indemnity. Banner, its affiliates and channel partners are not liable for indirect, special, incidental, punitive or consequential damages, damages relating to corruption, security, loss or theft of data, viruses, spyware, loss of business, revenue, profits, or investment, or use of software or hardware that does not meet Banner minimum systems requirements. The above limitations apply even if Banner and its affiliates and channel partners have been advised of the possibility of such damages. This Agreement sets forth the entire liability of Banner, its affiliates and your exclusive remedy with respect to the software use.



more sensors, more solutions

© Banner Engineering Corp. All rights reserved

Documents / Resources



[BANNER ZMX Series 3D Time of Flight Sensor](#) [pdf] User Guide

ZMX Series, 3D Time of Flight Sensor, ZMX Series 3D Time of Flight Sensor, Flight Sensor, Sensor

References

- [Banner Engineering](#)
- [Patents](#)
- [Terms and Conditions of Sale](#)

Manuals+

- [home](#)
- [privacy](#)