



## BEKA Advisor A90 Modbus Interface User Guide

[Home](#) » [BEKA](#) » BEKA Advisor A90 Modbus Interface User Guide 

BEKA Advisor A90 Modbus Interface



## Contents

- [1 Introduction](#)
- [2 Product Overview](#)
- [3 Modbus Implementation](#)
- [4 Modbus Register Address Map](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)
- [6 Related Posts](#)

## Introduction

This guide gives all the necessary information to use our Advisor A90 process meter in a Modbus installation. For hardware installation information, please refer to the separate instruction manuals available for each model.

### **What's in this Modbus Interface Guide**

- An overview of each instrument
- A description of the parameters that are applicable to each instrument
- Instructions on how to use the instrument in its standard mode

### **What's in the Instruction Manuals**

- An overview of the instrument
- System Design and Installation
- Configuration
- Maintenance

### **Other sources of information**

Our website at [www.beka.co.uk](http://www.beka.co.uk) is kept up to date with the latest literature and information. After reading through this guide, if you still have a problem getting the results you need then email us at [support@beka.co.uk](mailto:support@beka.co.uk) and we will do our best to help.

## Product Overview

A detailed overview of the instrument is given in the instruction manual for each product. This should be read before implementing any system using these instruments, however a summary of the main features is listed below:

### **Function**

The Advisor A90 Universal Panel Meter is a multicolour five digit display instrument, primarily intended for displaying a current, voltage or resistance analogue process signal in engineering units. The instrument can also display temperature directly from a resistance thermometer. The A90 is configurable on-site using the four front panel push buttons and an intuitive menu that can be protected by a security code to prevent accidental adjustment.

### **Display**

The Advisor A90 Process Panel Meter employs a novel technique that enables the display to be in any colour on a black background, readable in all conditions from total darkness to bright sunlight. The display intensity is fully adjustable to match other instruments and preserve operator's night time vision.

When fitted with optional alarms the display colour can be linked to the alarm status. For example, a green display could indicate normal operation, the display colour changing to red when a high alarm occurs and to blue when a low alarm occurs.

### **Analogue Input**

The instrument input type and range are selectable on-site and the meter display can be calibrated to show the engineering variable represented by the analogue input. The engineering units of measurement such as kg, gallons/hour or °C, can be printed on the slide-in scalecard.

One of the following input ranges may be selected:

#### **Voltage input**

0 to 100mV

0 to 1V

0 to 10V

#### **Current input**

4 to 20mA

0 to 50mA

#### **Resistance thermometer input**

2 or 3 wire connected PT100 resistance thermometer, or differential output from two PT100 resistance thermometers. -200 to 850°C

Changing the input type will reset the Panel Meter to its default settings for that input.

### **Optional Alarm Outputs**

There are two relay changeover outputs available. These are totally isolated and are energised or de-energised independently according to the status of the Alarm set-points. These can NOT be overridden by issuing any Modbus commands.

### **Optional Analogue Output**

A totally isolated analogue output is available which is configured as a current sink. This output can be configured to respond to the analogue input, and can NOT be overridden by issuing any Modbus commands. This option also comes with an isolated 24V DC power supply output which can be used to supply a 4-20 mA current loop.

## **Modbus Implementation**

The Modbus implementation on the Advisor has several objectives. It offers the following services to the Modbus Master (PLC, PC or similar):

- Monitor the process variable measured by the instrument
- Identify the status of the instrument (Alarms status, Tare Activation status,...)
- Configure the instrument remotely

The Modbus interface is available as an optional module on the Advisor A90. The supported protocol is Modbus RTU (Modbus over RS485). Note that the ASCII version of the protocol has not been implemented.

The A90 operates only as a slave on the network, processing requests from a remote Master. Multidrop mode is

supported in that there can be more than one device (A90 or others) on the bus.

### **Exclusions**

It is not possible to configure the product locally and remotely at the same time. If a user is navigating through the menus, a Modbus Busy exception will be raised to the Master.

The Master cannot be used to override the internal logic of the instrument. For example, it is not possible to directly control the Alarm Outputs, read the keypad buttons or take control of the displayed value via Modbus.

The Master cannot override operations which are intended to take place locally. For example actions such as Silencing Alarms, Input Calibration, Temperature Trimming, Input Taring are not available via Modbus.

The Input type is not writeable by the Master as changing the input type has the effect of resetting the product back to defaults, causing significant problems.

### **Hardware**

The physical hardware layer is a 2 wire RS485 interface. The A90 will see the all requests from the master and every reply from any other devices on the bus. These are ignored unless the request is specifically addressed to the unit.

The RS485 communication settings can be amended locally on the instrument by going into the “Ser” submenu or via the dedicated holding registers. The following settings can be changed :

- Baud Rate in kbaud : can be 9.6, 19.2, 38.4, 57.6, 115.2
- Parity: Even, None or Odd
- Number of Stop Bits: 1 or 2

The default values are 19.2kbaud, Even Parity, 1 Stop bit The default values are 19.2kbaud, Even Parity, 1 Stop bit

### **Setting the Address**

The Modbus Slave Address can only be amended locally on the instrument via the “5Er” submenu. The slave address can range from 1 to 247. The default value is 001.

Note: Address 0 is reserved for broadcast messages. The A90 accepts the broadcast for writing functions, however no response is returned to the master.

### **Reset to Defaults**

Changing the instrument input type (locally via the keypad) or resetting the configuration to defaults will have the effect of reverting the Modbus communication settings and slave address to their default values.

### **Supported Modbus Functions**

The Modbus functions that are supported by the A90 are as follows:

Decimal	Hex	Description
01	0x01	Read Coils
02	0x02	Read Discrete Inputs
03	0x03	Read Holding Registers
04	0x04	Read Input Registers
05	0x05	Write Single Coil
06	0x06	Write Single Register
08	0x08	Diagnostics <b>(Partly Supported)</b>
15	0x0F	Write Multiple Coils
16	0x10	Write Multiple Registers
43	0x2B	Read Device Identification <b>(Partly Supported)</b>

All of the following diagnostic sub-functions are supported except sub-function 0x03 (This is only required for ASCII protocol. A request on this subfunction generates an ILLEGAL DATA VALUE exception.)

Sub-Function Code		Description
Decimal	Hex	
00	0x00	Return Query Data
01	0x01	Restart Communications Option
02	0x02	Return Diagnostic Registers
03	0x03	Change ASCII Input Delimiter <b>(Unsupported)</b>
04	0x04	Force Listen Only Mode
05...09	0x05...0x09	<b>Reserved</b>
10	0x0A	Clear Counters and Diagnostic Register
11	0x0B	Return Bus Message Count
12	0x0C	Return Bus Communication Error Count
13	0x0D	Return Bus Exception Error Count
14	0x0E	Return Server Message Count
15	0x0F	Return Server No Response Count
16	0x10	Return Server NAK Count
17	0x11	Return Server Busy Count
18	0x12	Return Bus Character Overrun Count
19	0x13	<b>Reserved</b>
20	0x14	Clear Overrun Counter and Flag
21...65535	0xnn	<b>Reserved</b>

### **Read Device Identification (Function Code 0x2B)**

Only the MEI type 14 is supported in this function, and all other types are rejected. This function code allows reading the identification and additional information from a remote device.

There are 3 categories of objects defined in the following table. The table also specifies the value and message length from the instrument for each object ID.

MEI Type	Object ID	Object Name / Description	Type	Category	Returned Value	Value Length	
14	0x00	Vend or Name	ASCII String	Basic	"BEKA Associates Ltd."	20	
	0x01	Product Code	ASCII String		"A90"	3	
	0x02	Major Minor Revision	ASCII String		"A90.1.FX.XX" where X.XX is the firmware version	11	
	0x03	Vendor URL	ASCII String	Regular	<a href="http://www.beka.co.uk">www.beka.co.uk</a>	14	
	0x04	Product Name	ASCII String		"Advisor"	7	
	0x05	Model Name	ASCII String		"A90"	3	
	0x06	User Application Name	ASCII String		<b>Unused</b>		
	0x07...0x7F	<i>Reserved</i>			<b>Unused</b>		
	0x80...0xFF				Extended	<b>Not Supported</b>	

The request from the Master for this function must include a Read Device ID Code which defines whether the

request is only for a single object or stream of objects:

ID 01 : request to get the basic device identification (stream access)

ID 02: request to get the regular device identification (stream access)

ID 03: request to get the extended device identification (stream access) – Not Supported

ID 04: request to get one specific identification object (individual access)

- For Extended access (ID 03) an Exception Code 03 (ILLEGAL DATA VALUE) is returned
- For a single object request (ID 04), if the object ID requested corresponds to an unused or unsupported object ID (address  $\geq 0x07$ ), an Exception Code 02 (ILLEGAL DATA ADDRESS) is returned
- For a stream access (ID 02), the response will only include the used objects (address  $< 0x07$ ) and the next object ID will be set to 0x00 (restart at the beginning)

## Modbus Register Address Map

### Notes:

In the tables below (IEEE) indicates that data is represented by a 4 byte IEEE floating point format For 32 bits registers (integers or floats), the Most Significant 16 bits word is the one with the highest Modbus address

Coils	Read / Write		
Address	Bits	Description	Functions Supported
1	1	Alarm1 Enable	1, 5, 15
2	1	Alarm2 Enable	1, 5, 15
3	1	4/20 O/P Enable	1, 5, 15
4	1	Save Configuration	1, 5, 15

### Notes:

**Enable:** 0 = Disable 1= Enable

**Save:** 0 = No Effect 1 = Save Configuration Data in Flash (Coil will revert to zero once saved)



<b>Input Status</b>	<b>Read Only</b>		
<b>Address</b>	<b>Bits</b>	<b>Description</b>	<b>Functions Supported</b>
1	1	Alarm1 Energised	2
2	1	Alarm2 Energised	2
3	1	Input Fault Status	2
4	1	Configuration Not Saved	2
5	1	Alarm Option Fitted	2
6	1	4/20 O/P Option Fitted	2
7	1	Tare Display Status	2
8	1	Write Error	2

Alarms:	0 = De-Energised	1 = Energised
Fault Status:	0 = Normal	1 = Fault
Configuration:	n: 0 = Saved	1 = Changed, but not saved
Options:	0 = Not Fitted	1 = Fitted
Tare Display:	0 = Gross	1 = Tare
Write	0 = No Error	1 = Error *

- A value of 1 indicates that the last attempt to write to the unit generated an error due to the fact that one or more of the data registers were outside the allowable range. It should be noted that any valid value within this same request would have still been processed, i.e. the entire write packet is not rejected.

Input Registers	Read Only		
Address	Registers	Description	Functions Supported
1	1	Input Type	4
2	2	Display Value (IEEE)	4
4	2	Max Hold Value (IEEE)	4
6	2	Min Hold Value (IEEE)	4
8	2	Display Value (32 bits Integer)	4
10	1	Display Value divisor (n/10)	4
11	2	Max Hold (32 bits Integer)	4
13	1	Max Hold divisor (n/10)	4
14	2	Min Hold (32 bits Integer)	4
16	1	Min Hold divisor (n/10)	4

**Notes:**

Input Type Enumeration:

0 = 0.1V

1 = 1V

2 = 10V

3 = 4/20 mA

4 = 0-50 mA

5 = Differential RTD

6 = 2-Wire RTD

7 = 3-Wire RTD

Address	Registers	Description	Default	Range	Exceptions	Functions Supported
1	2	Set Zero (IEEE)	0.0	float	Only applicable to Voltage & Current Inputs	3, 16
3	2	Set Span (IEEE)	100.0	float	Only applicable to Voltage & Current Inputs	3, 16
5	2	Bar Low (IEEE)	*	float		3, 16
7	2	Bar High (IEEE)	*	float		3, 16

9	2	Alarm1 Setpoint (IEEE)	0.0	float	Only applicable if Option fitted	3, 16
11	2	Alarm1 Hysteresis (IEEE)	0.0	float		3, 16
13	2	Alarm2 Setpoint (IEEE)	0.0	float		3, 16
15	2	Alarm2 Hysteresis (IEEE)	0.0	float		3, 16
17	2	4/20 O/P Zero (IEEE)	*	float		3, 16
19	2	4/20 O/P Span (IEEE)	*	float		3, 16
21	1	Input Units	0	0...4	Only applicable to RTD Inputs	3, 6,16
22	1	Function (Root Extraction)	0	0...1	Only applicable to Current Inputs	3, 6,16
23	1	Resolution (of least significant digit)	0	0...3		3, 6,16
24	1	D.P. (Decimal Point position on the display)	*	0...5		3, 6,16
25	1	Bar Type	1	0...4		3, 6,16
26	1	Alarm1 Hi/Lo	0	0...1	Only applicable if Option fitted Not all characters are available. See Note.	3, 6,16
27	1	Alarm1 ND/NE	0	0...1		3, 6,16
28	1	Alarm1 Delay (in seconds)	0	0...3600		3, 6,16
29	1	Alarm1 Silence	0	0...3600		3, 6,16
30	1	Alarm1 Colour (Colour Preset Number)	1	1...7		3, 6,16
31	1	Alarm1 Flash Enable	1	0...1		3, 6,16
32	1	Alarm1 Latch Enable	0	0...1		3, 6,16
33	1	Alarm2 Hi/Lo	0	0...1		3, 6,16
34	1	Alarm2 ND/NE	0	0...1		3, 6,16
35	1	Alarm2 Delay (in seconds)	0	0...3600		3, 6,16
36	1	Alarm2 Silence	0	0...3600		3, 6,16
37	1	Alarm2 Colour (Colour Preset Number)	1	1...7		3, 6,16
38	1	Alarm2 Flash Enable	1	0...1		3, 6,16
39	1	Alarm2 Latch Enable	0	0...1		3, 6,16
40	2	Alarms Access Code	"0000"	ASCII		3,16
42	1	ACSP Enable	0	0...1		3, 6,16
43	1	Tare Enable	0	0...1	3, 6,16	

44	1	Hold Enable	0	0...1		3, 6,16
45	1	Hold clear	0	0...1		3, 6,16
46	1	U – P (Function of P Button)	0	0...1		3, 6,16
47	1	Serial Baud	1	0...4		3, 6,16
48	1	Serial Par	2	0...2		3, 6,16
49	1	Serial Stop	1	1...2		3, 6,16
50	1	Serial Addr	1	1... 247		3, 6,16
51	1	4/20 O/P RTD Fault Current	0	0...3	Only applicable if Option fitted	3, 6,16
52	2	Security Code	“0000 ”	ASCII	Not all characters are available. See Note.	3,16
54	1	Menu Colour Preset	4	1...7		3, 6,16
55	1	Calibration source	0	0...1		3, 6,16
201	2	Set Zero	0	sigint	Only applicable to Voltage & Current Inputs	3,16
203	1	Set Zero Divisor	2	0...4	Only applicable to Voltage & Current Inputs	3, 6,16
204	2	Set Span	1000 0	sigint	Only applicable to Voltage & Current Inputs	3,16
206	1	Set Span Divisor	2	0...4	Only applicable to Voltage & Current Inputs	3, 6,16
207	2	Bar Low	*	sigint		3,16
209	1	Bar Low Divisor	*	0...4		3, 6,16
210	2	Bar High	*	sigint		3,16
212	1	Bar High Divisor	*	0...4		3, 6,16
213	2	Alarm1 Setpoint	*	sigint	Only applicable if Option fitted	3,16
215	1	Alarm1 Setpoint Divisor	*	0...4		3, 6,16
216	2	Alarm1 Hysteresis	*	sigint		3,16
218	1	Alarm1 Hysteresis Divisor	*	0...4		3, 6,16
219	2	Alarm2 Setpoint	*	sigint		3,16
221	1	Alarm2 Setpoint Divisor	*	0...4		3, 6,16
222	2	Alarm2 Hysteresis	*	sigint		3,16
224	1	Alarm2 Hysteresis Divisor	*	0...4		3, 6,16
225	2	4/20 O/P Zero	*	sigint		3,16
227	1	4/20 O/P Zero Divisor	*	0...4		3, 6,16
228	8	4/20 O/P Span	*	sigint		3,16

230	1	4/20 O/P Span Divisor	*	0...4	3, 6,16
-----	---	-----------------------	---	-------	---------

\* = Default values are input type dependent 10

**Notes**

Input Unit Enumeration: (Only for Temperature Inputs)	0 = Degrees Celsius 2 = Degrees Fahrenheit 4 = Resistance	1 = Degrees Kelvin 3 = Degrees Rankine
Function (Root extraction) (Only for Current Inputs)	0 = No Root extraction	1 = Root extraction
Resolution (of least significant digit)	0 = 1 2 = 5	1 = 2 3 = 10
D.P. (Decimal Point position on the Display:)	0 = 00000 (No Decimal Point) 2 = 000.00 4 = 0.0000	1 = 0000.0 3 = 00.000 5 = Auto (gives best resolution)
Bar Type	0 = OFF 4 = Asps (if alarms are fitted)	1 = Left 3 = Right
Alarm Hi/Lo	0 = Alarm is a Low Alarm	1 = Alarm is a High Alarm
Alarm ND/NE	0 = Alarm Normally De-Energized	1 = Alarm Normally Energized
Alarm Flash Enable	0 = Disables Alarm Flashing	1 = Enables Alarm Flashing
Alarm Latch Enable	0 = Disables Alarm Latching	1 = Enables Alarm Latching
ACSP Enable	0 = Disables Alarm Menu shortcut	1 = Enables Alarm Menu shortcut
Tare Enable	0 = Disables Tare function	1 = Enables Tare Function
Hold Enable	0 = Disables Hold function	1 = Enables Hold Function
Hold Clear	0 = No effect	1 = Clears max/min held values.
U – P (Function of P Button) Serial Baud (Modbus baud rate)	0 = % of Span 0 = 9600 2 = 38400 4 = 115200	1 = Analogue Input 1 = 19200 3 = 57600
Serial Par (Modbus Parity)	0 = None 2 = Even	1 = Odd
Factory Default Colours Codes (each color assigned to a code can be adjusted manually through the menu)	1 = Red 2 = Orange 3 = Light Green 4 = Green	5 = Blue 6 = Purple 7 = White
4/20 O/P RTD Fault Current	0 = No Fault Current 1 = 3.6 mA	2 = 3.8 mA 3 = 21 mA
Calibration source	0 = Factory (SET)	1 = User (CAL)
float = IEEE Floating Point	The entire 32 bits value has to be written and read as one command rather than separately otherwise an ILLEGAL ADDRESS exception will be raised	
sigint = 32 bits Signed Integer with Divisor	The divisor register defines the number of times the integer value is divided by ten. The divisor and 32 bits value have to be written and read together otherwise an ILLEGAL ADDRESS exception will be raised	

For 32 bits registers (either integers or floats), the Most Significant 16 bits word is the one with the highest Modbus address.


If the register written to does not apply to the option fitted or the input type, the write will be allowed but the underlying value will not be changed and the write rejected flag will not be set. Read requests will return a value of 0. This behavior avoids generating exceptions which would prevent a full group write. The ASCII Character set for access codes is limited by the characters that can be displayed on a 7 segment digit. The following characters may be used:

**0,1,2,3,4,5,6,7,8,9,A,B,C,D,E,F,G,H,I,J,L,N,O,P,R,T,U,V,Y**

BEKA Associates  
Old Charlton Road  
Hitchin  
Hertfordshire  
SG5 2DA  
Tel: +44 (0)1462 438301  
Fax: +44 (0)1462 453971  
Web: [www.beka.co.uk](http://www.beka.co.uk)  
Email: [support@beka.co.uk](mailto:support@beka.co.uk)  
or [sales@beka.co.uk](mailto:sales@beka.co.uk)



## Documents / Resources

 A photograph of the BEKA Advisor A90 Modbus Interface unit, showing its front panel with a digital display and various ports.	<p><a href="#">BEKA Advisor A90 Modbus Interface</a> [pdf] User Guide Advisor A90 Modbus Interface, Advisor A90, Modbus Interface, Interface</p>
---	--

## References

- [BEKA associates Ltd.](#)
- [BEKA associates Ltd.](#)

[Manuals+](#)