



BERG EN-1176 Standard Public Use Trampolines Instructions

[Home](#) » [BERG](#) » BERG EN-1176 Standard Public Use Trampolines Instructions 

Contents

- [1 BERG EN-1176 Standard Public Use Trampolines](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Instructions](#)
- [5 Additional warnings for public use](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



BERG EN-1176 Standard Public Use Trampolines



Product Information

Product Name: Additional Warnings for Public Use

Product Usage Instructions

1. Ensure that the product is securely installed in a visible location.
2. Prior to use, familiarize yourself with the additional warnings provided.
3. Read and understand the instructions in the user manual before proceeding.
4. Follow all safety guidelines and regulations relevant to public use.
5. Regularly inspect the product for any damage or signs of wear and tear.
6. If any issues are detected, discontinue use and contact customer support for assistance.
7. When using the additional warnings, ensure they are clearly visible to the public.
8. Periodically review and update the warnings as needed.
9. Keep the product clean and free from obstructions that may hinder its effectiveness.
10. Store the product in a safe and dry place when not in use.

Note: For detailed instructions on how to install and maintain the product, refer to the user manual provided.


Instructions

Instructions for using the 'Additional warnings for public use'

- This document is only provided digitally.
- The manager of the trampoline is required to place these warnings in the vicinity of the product.
- The manager is free to choose the manner of display suitable to the location, as long as the warnings are placed in a properly visible location and are protected against the weather. Possibilities include: printing-out the warnings on paper and laminating it, having a perspex sign printed, having a sign or board engraved etc.
- Ensure in all cases that the warnings are clearly visible and are easily readable. Use at least the provided A4 format to guarantee readability.

Additional warnings for public use

- Supervision by an adult is required during use.
- Ensure that the space under the BERG trampoline is free of objects and obstacles. No individuals or animals may be under the trampoline.
- Before starting to jump, users must remove shoes, glasses, chains, jewellery, buckles and other sharp objects, and pockets must be emptied to prevent any damage to the trampoline or injury.
- An area of at least 2 metres must be kept free around the trampoline, free of any trees, fencing or any other obstacle.
- Only jump on the trampoline when the upper surface of the jumping mat is dry.
- Never jump if there is a fierce or strong wind.
- Do not use the BERG trampoline in the dark.
- Do not smoke while using the trampoline.
- Never perform somersaults!! This could lead to serious back or neck injury.
- **Maximum user weight:** 100kg

	<p>BERG EN-1176 Standard Public Use Trampolines [pdf] Instructions</p> <p>EN-1176 Standard Public Use Trampolines, EN-1176 Standard, Public Use Trampolines, Trampolines</p>
---	---