



BITMAIN S9i Antminer Server Installation Guide

[Home](#) » [BITMAIN](#) » BITMAIN S9i Antminer Server Installation Guide 

BITMAIN S9i Antminer Server Installation Guide



Contents

- 1 Overview
 - 1.1 S9i Server Components
 - 1.2 Specifications
- 2 Connecting to the Power Supply
- 3 Setting Up the Server
- 4 Configuring the Server
- 5 Monitoring Your server
- 6 Administering Your Server
 - 6.1 Checking Your Firmware Version
 - 6.2 Upgrading Your System
 - 6.3 Modifying Your Password
 - 6.4 Restoring Initial Settings
- 7 Environmental Requirements
 - 7.1 Other Environmental Requirements
- 8 Regulation
- 9 Documents / Resources
- 10 Related Posts

Overview


The S9i server is one of the products in Bitmain's S9 miner series. All S9i servers are tested and configured prior to shipping to ensure easy set up



You must provide your own ATX power supply.

S9i Server Components

The S9i server main components and controller front panel are shown in the following figure:



Specifications

Hash Rate	S9i-13 TH/s. 13.5 TH/s. 14 TH/s. 14.5 TH/s
Power Consumption	1290 W (13 TH/s) 1310 W (13.5 TH/s) 1320 W (14 TH/s) 1365 W(14.5 TH/s)
Power Efficiency	99 I/TH (13 TH/s) 97)/TH (13.5 TH/s) 94)/TH (14 TH/s) 94.14 I/TH (14,5 TH/s)
Rated Voltage	11.60 -13.00 V
Frequency	Auto-frequency
Network connection mode	Ethernet
Operating temperature	0 – 40 °C
Storage temperature	-40 – 85°C
Operating humidity	5C5RH-95C5RH. No condensation
Product weight (without package)	4.2 kg
Product dimensions	350mm(L) x 135mm(W) x 158mm(H)

Connecting to the Power Supply

Ten PCI-e connectors are located at the top of the S9i server for connecting the PSU as follows:

- Nine PCI-e connectors for the hash boards. Each hash board has three PCI e connectors.
- One PCI-e connector located on the controller.



Each hash board must be powered by the same PSU to prevent possible damage and instability.

To connect the power supply:

1. Connect PSU power cable connectors to each of the nine PCI-e connectors on the top of the S9i server, ensuring that each hash board is powered by the same PSU.



2. Connect a PSU power cable connector to the S9i PCI-e connector on the controller.
3. Connect the network cable to the ETH port.

4. To power up your S9i server, connect the PSUs to the power wall outlet.



If you are using more than one PSU, power up the PSU connected to the controller AFTER you have Powered up the other PSU(s).

Setting Up the Server

To set up the server:



The file IPReporter.zip is supported by Microsoft Windows only.

1. Go to the following site:

<https://shop.bitmain.com/support.htm pid=00720160906053730999PVD2K0vz0693>

2. Download the following file: IPReporter.zip

3. Extract the file.




The default DHCP network protocol distributes IP addresses automatically.

4. Right-click IPReporter.exe and run it as Administrator.


5. Select one of the following options:

- Shelf, Step, Position – suitable for farm servers to mark the location of the servers.
- Default – suitable for home servers.


6. Click Start.




7. On the controller board, click the IP Report button. Hold it down until it beeps (about 5 seconds).



The IP address will be displayed in a window on your computer screen.



8. In your web browser, enter the IP address provided.
9. Proceed to login using root for both the username and password.
10. In the Network section, you can assign a DHCP IP address (optional).
11. Click Save & Apply.



Configuring the Server


Setting Up the Pool

To configure the server:

1. click General Settings. (Here takes S9i-14T running under the firmware with “Normal” mode as an example)



2. Set the options according to the following table:

Option	Description
Pool URL	<p>Enter the URL of your desired pool</p>  <p>The S9i server can be set up with three mining pools, with decreasing priority from the first pool (pool 1) to the third pool (pool 3). The pools with low priority will only be used if all higher priority pools are offline.</p>
Worker	Your worker ID on the selected pool.
Password	The password for your selected worker.

3. Click Save & Apply to save and restart the server.

Monitoring Your server

To check the operating status of your server:

1. Click the status marked below. (Here takes S9i-14T running under the firmware with “Normal” mode as an example)



2. monitor your server according to the descriptions in the following table:

Option	Description
ASIC	Number of chips detected in the chain.
Frequency	ASIC frequency setting.
GH/S(RT)	Hash rate of each hash board (GH/s)
Temp(PCB)	Temperature of each hash board (°C).(Applied only to server with fixed frequency)
Temp(Chip)	Temperature of the chips on each hash board (°C).
ASIC status	<p>One of the following statuses will appear:</p> <ul style="list-style-type: none"> • O – indicates • X – indicates error • – indicates dead



Note: The S9i server is with automatic frequency. Firmware will stop running when the Temp (PCB) reaches to 90°C there will be an error message “Fatal Error: Temperature is too high!” shown in the bottom of kernel log page.

Administering Your Server

Checking Your Firmware Version

To check your firmware version:

1. In System, click the Overview tab.
2. File System Version displays the date of the firmware your server use. In the example below, the server is using firmware version 20190730




Upgrading Your System




Make sure that the S9i server remains powered during the upgrade process. If power fails before the upgrade is completed, you will need to return it to Bitmain for repair.

To upgrade the server's firmware:

1. In System, click Upgrade.



2. For Keep Settings:
 - Select the check box to keep your current settings (default).
 - Clear the check box to reset the server to default settings.
3. Click **选择文件** the (Browse) button and navigate to the upgrade file. Select the upgrade file, then click Flash image. A message appears notifying you if the S9i firmware can be upgraded and if yes, will then proceed to flash the image.
4. When the upgrade is completed, the following message appears:




5. Click one of the following options:
 - Reboot – to restart the server with the new firmware.
 - Go Back – to continue mining with the current firmware. The server will load the new firmware next time it is restarted.

Modifying Your Password

To change your login password:

1. In System, click the Administration tab.
2. Set your new password, then click Save & Apply.



Restoring Initial Settings

To restore your initial settings

1. Turn on the server and let it run for 5 minutes.
2. On the controller front panel, press and hold the Reset button for 10 seconds.

Resetting your server will reboot it and restore its default settings. The red LED will automatically flash once every 15 seconds if the reset is operated successfully

Environmental Requirements

Please run your server in accordance with the following requirements

Basic Environmental Requirements:

Climatic Conditions:

Description	Requirement
Operating Temperature	0-40°C
Operating Humidity	10-90%RH (non-condensing)
Storage Temperature	-20-70°C
Storage Humidity	5-95%RH non-condensing
Altitude	<2000m

Site Requirements of the Server Running Room:

Please keep the server running room away from industrial pollution sources:

For heavy pollution sources such as smelters and coal mines, the distance should be more than 5km.

For moderate pollution sources such as chemical industries, rubber and electroplating industries, the distance should be more than 3.7km.

For light pollution sources such as food factories and leather processing factories, the distance should be more than 2km.

If unavoidable, the site should be chosen in the perennial upwind direction of the pollution source.

Please do not set your location within 3.7km from the seaside or the salt lake. If unavoidable, it should be built as airtight as possible, equipped with air conditioning for cooling.

Electromagnetic Environmental Conditions:

Please keep your site away from transformers, high-voltage cables, transmission lines and high-current equipment, for example, there should be no high-power AC transformers (>10KA) within 20 meters, and no high-voltage power lines within 50 meters.

Please keep your site away from high-power radio transmitters, for example, there should be no high-power radio transmitters (>1500W) within 100 meters.

Other Environmental Requirements

The server running room shall be free of explosive, conductive, magnetically conductive and corrosive dust. The requirements of mechanical active substances are shown below:

Requirements of Mechanical Active Substances

Mechanical Active Substance	Requirement
Sand	$\leq 30\text{mg/m}^3$
Dust (suspended)	$\leq 0.2\text{mg/m}^3$
Dust (deposited)	$\leq 1.5\text{mg/m}^2 \text{ h}$

Requirements of Corrosive Gas

Corrosive Gas	Unit	Concentration
H ₂ S	ppb	< 3
SO ₂	ppb	< 10
Cl ₂	ppb	< 1
NO ₂	ppb	< 50
HF	ppb	< 1
NH ₃	ppb	< 500
O ₃	ppb	< 2
Note: ppb (part per billion) refers to the unit of concentration 1ppb stands for the volume ratio of part per billion.		

Regulation

FCC Notice (FOR FCC CERTIFIED MODELS):

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference

when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

EU WEEE: Disposal of Waste Equipment by Users in Private Household in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Documents / Resources

	BITMAIN S9i Antminer Server [pdf] Installation Guide S9i, Antminer Server, S9i Antminer Server
------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------