

# **BOSCH HQA.34B.3 Built In Oven User Guide**

Home » Bosch » BOSCH HQA.34B.3 Built In Oven User Guide 12



HQA.34B.3
User manual and installation instructions

### **Contents**

- 1 HQA.34B.3 Built In Oven
- 2 Safety
- 3 Preventing material damage
- 4 Environmental protection and saving energy
- 5 Familiarising yourself with your appliance
- **6 Accessories**
- 7 Before using for the first time
- 8 Basic operation
- 9 Rapid heating
- 10 Time-setting options
- 11 Steam assistance
- 12 Childproof lock
- 13 Cleaning and servicing
- 14 Cleaning aid
- 15 Appliance door
- 16 Shelf supports
- 17 Troubleshooting
- 18 Disposal
- 19 Customer Service
- 20 Installation instructions
- 21 Documents / Resources
  - 21.1 References



Register your new device on MyBosch now and get free benefits: bosch-home.com/welcome

Further information and explanations are available online:



https://digitalguide.bsh-group.com/?mat-no=9001918995&brand =BOSCH&name=Oven&vib=HQA.34B.3&default=en



Observe the following safety instructions.

#### 1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

### 1.2 Intended use

This appliance is designed only to be built into kitchen units. Read the special installation instructions. Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under the warranty.

Only use this appliance:

- To prepare meals and drinks.
- in private households and in enclosed spaces in a domestic environment.
- up to an altitude of max. 4000 m above sea level.

Do not use the appliance:

• with an external timer or a remote control.

### 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance. Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

### 1.4 Safe use

Always place accessories in the cooking compartment the right way round.



# 

Combustible objects that are left in the cook-ing compartment may catch fire.

- ▶ Never store combustible objects in the cooking compartment.
- ▶ If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire.

▶ Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Opening the appliance door creates a draught. Greaseproof paper may come into contact with the heating element and catch fire.

- ▶ Never place greaseproof paper loosely over accessories when preheating the appliance and while cooking.
- ▶ Always cut greaseproof paper to size and use a plate or baking tin to hold it down.

# ✓! WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- ▶ Caution should be exercised here in order to avoid touching heating elements.
- ➤ Young children under 8 years of age must be kept away from the appliance.

Accessories and cookware get very hot.

▶ Always use oven gloves to remove accessories or cookware from the cooking compartment.

When the cooking compartment is hot, any alcoholic vapours inside may catch fire. The appliance door may spring open. Hot steam and jets of flame may escape.

- ▶ Only use small quantities of drinks with a high alcohol content in food.
- ▶ Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).
- ▶ Open the appliance door carefully.



# ✓! WARNING – Risk of scalding!

The accessible parts of the appliance become hot during operation.

- ► Never touch these hot parts.
- ► Keep children at a safe distance.

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- ▶ Open the appliance door carefully.
- ► Keep children at a safe distance.

If there is water in the cooking compartment when it is hot, this may create hot steam.

▶ Never pour water into the cooking compartment when the cooking compartment is hot.



# WARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

▶ Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

The appliance and its parts that can be touched may have sharp edges.

- ▶ Take care when handling and cleaning them.
- ▶ If possible, wear protective gloves.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

► Keep your hands away from the hinges.

Components inside the appliance door may have sharp edges.

▶ Wear protective gloves.

Alcoholic vapours may catch fire in the hot cooking compartment, and the appliance door may spring open and may fall off. The door panels may shatter and fragment.

→ "Preventing material damage", Page 4

- ▶ Only use small quantities of drinks with a high alcohol content in food.
- Do not heat spirits (≥ 15% vol.) when undi-luted (e.g. for marinating or pouring over food).
- ▶ Open the appliance door carefully.



# WARNING - Risk of electric shock!

Improper repairs are dangerous.

- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repair-ing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

If the insulation of the power cord is damaged, this is dangerous.

- ▶ Never let the power cord come into contact with hot appliance parts or heat sources.
- ▶ Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

An ingress of moisture can cause an electric shock.

▶ Do not use steam- or high-pressure cleaners to clean the appliance.

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 21



# ✓!\ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

### 1.5 Halogen bulb



# **△!** WARNING – Risk of burns!

The bulbs in the cooking compartment get very hot. There is still a risk of burning for some time after they have been switched off.

- ▶ Do not touch the glass cover.
- ► Avoid contact with your skin when cleaning.



# ✓! WARNING – Risk of electric shock!

When changing the bulb, the bulb socket contacts are live.

- ▶ Before replacing the bulb, ensure that the appliance is switched off in order to prevent a potential electric shock.
- ▶ Also unplug the appliance from the mains or switch off the fuse in the fuse box.

### 1.6 Steam assistance

Follow these instructions when using steam assistance.



**WARNING** – Risk of burns!

While the appliance is in operation, the water bowl reaches high temperatures.

- ▶ Never remove the water bowl while the appliance is in operation.
- ▶ Only remove the water bowl once it has cooled down.



# **WARNING** – Risk of fire!

Due to the hot surfaces, vapours from flammable liquids may catch fire in the cooking compartment and cause an explosion. The appliance door may spring open. Hot steam and jets of flame may escape.

▶ Do not fill the water bowl with any flam-mable fluids, e.g. alcoholic drinks.

# Preventing material damage

### 2.1 General

### ATTENTION!

Alcoholic vapours may catch fire in the hot cooking compartment and cause permanent damage to the appliance. The appliance door may spring open due to an explosion and it may fall off. The door panels may shatter and fragment. Due to the resulting negative pressure, the cooking compartment may become considerably deformed inwards.

▶ Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120 °C, this will damage the enamel.

- ▶ Do not use the appliance if there is water on the cooking compartment floor.
- ▶ Wipe away any water on the cooking compartment floor before operation.

Objects on the cooking compartment floor at over 50 °C will cause heat to build up. The baking and roasting times will no longer be correct and the enamel will be damaged.

- ▶ Do not place any accessories, greaseproof paper or foil of any kind on the cooking compartment floor.
- ▶ At cooking temperatures above 50 °C, do not place any cookware on the cooking compartment floor. The exception is the water bowl for using the steam assistant.

When the cooking compartment is hot, any water inside it will create steam. The change in temperature may cause damage.

- ▶ Never pour water into the cooking compartment when it is still hot.
- ▶ Never place reservoirs containing water on the cooking compartment floor. The exception is the water bowl for using added steam.

The prolonged presence of moisture in the cooking compartment leads to corrosion.

- ▶ Allow the cooking compartment to dry after use.
- ▶ Do not keep moist food in the cooking compartment for a long time with the door closed.
- ▶ Do not store food in the cooking compartment.
- ► Take care not to trap anything in the appliance door.

Fruit juice dripping from the baking tray leaves stains that cannot be removed.

- ▶ When baking very juicy fruit flans, do not pack too much on the baking tray.
- ▶ If possible, use the deeper universal pan.

Using oven cleaner in a hot cooking compartment damages the enamel.

- ▶ Never use oven cleaner in the cooking compartment when it is still warm.
- ▶ Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

If the seal is very dirty, the appliance door will no longer close properly during operation. This may damage the front of adjacent kitchen units.

- ► Keep the seal clean at all times.
- ▶ Never operate the appliance if the seal is damaged or missing.

Sitting or placing objects on the appliance door may damage it.

- ▶ Do not place, hang or support objects on the appliance door.
- ▶ Do not place cookware or accessories on the appliance door.

With certain models, accessories may scratch the door pane when closing the appliance door.

▶ Always push accessories fully into the cooking compartment.

If aluminium foil comes into contact with the door pane, it could cause permanent discolouration.

▶ Do not allow aluminium foil in the cooking compartment to come into contact with the door pane.

### **Environmental protection and saving energy**

### 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

▶ Sort the individual components by type and dispose of them separately.

### 3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Only preheat the appliance if the recipe or the recommended settings tell you to do so.

- → "How it works", Page 21
- Not preheating the appliance can reduce the energy used by up to 20%.

Use dark-coloured, black-coated or enamelled baking tins.

■ These types of baking tin absorb the heat particularly well.

Open the appliance door as little as possible during operation.

- This maintains the temperature in the cooking compartment and eliminates the need for the appliance to reheat. When baking multiple dishes, do so in succession or in parallel.
- The cooking compartment is heated after baking the first dish. This reduces the baking time for the subsequent cakes.

For longer cooking times, you can switch the appliance off 10 minutes before the cooking time ends.

■ There is sufficient residual heat to finish cooking the dish.

Remove any accessories that are not being used from the cooking compartment.

■ Accessories that are not being used do not need to be heated.

Allow frozen food to defrost before cooking.

■ This saves the energy that would otherwise be required to defrost it.

You can find product information in accordance with (EU) 65/2014 and (EU) 66/2014 below the energy label and online on the product page for your appliance.


Note: In standby mode, the appliance requires max. 1 W.

### Familiarising yourself with your appliance

#### 4.1 Control elements

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

**Note:** On certain models, specific details such as colour and shape may differ from those pictured.



### 1. Buttons and display

The buttons are touch-sensitive surfaces. To select a function, simply press lightly on the relevant field.

The display shows symbols for active functions and the time-setting options.

→ "Buttons and display", Page 6

#### 2. Function selector

Use the function selector to set the types of heating and other functions.

You can turn the function selector clockwise or anti-clockwise from the zero setting o.

Depending on the appliance, the function selector can be pushed in. Press on the function selector to click it into or out of the zero setting o.

→ "Types of heating and functions", Page 6

### 3. Temperature selector

Use the temperature selector to set the temperature for the type of heating and select settings for other

functions.

You can only turn the temperature selector clockwise from the zero setting ● until it offers resistance. You cannot turn it any further than this.

Depending on the appliance, the temperature selector can be pushed in. Press on the temperature selector to click it into or out of the zero setting •.

→ "Temperature and setting levels", Page 7

### 4.2 Buttons and display

You can use the buttons to set various functions for your appliance. The display shows the settings. If a function is active, the corresponding symbol lights up on the display.

Symbol	Function	
Φ,	Select the timer ♠, cooking time → I, end time → and time.  To select the individual time-setting options, press the → button several times.  → "Time-setting options", Page 11	
_ +	Decrease the setting values. Increase the setting values.	
<u>©</u>	To activate or deactivate the childproof lock, press and hold for approx. 3 seconds.  → "Childproof lock", Page 13	

### 4.3 Types of heating and functions

To ensure that you always find the right type of heating to cook your food, we explain the differences and applications below.

Symbol	Type of heating	What it's used for and how it works	
	3D hot air	Bake or roast on one or more levels. The fan distributes the heat from the ring heating element in the back wall evenly around the cooking compartment.	
<b>(%)</b>	Hot air steam	Baking and frying with steam assistance is particularly well suited t o frying meat and to baking bread and cakes.  The fan distributes the heat and the steam evenly throughout the c ooking compartment.  Notes  ■ Always use the appliance with the water bowl.  ■ Observe the information on steam.  → "Steam assistance", Page 12	

<b>®</b>	Hot air gentle	Cook selected dishes gently on one level without preheating. The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment.  The food is cooked in phases using residual heat. Always keep the appliance door closed when cooking. The food is cooked in phases using residual heat.  Always keep the appliance door closed when cooking. If you open the appliance door even briefly, the appliance will continue to heat without utilising any residual heat.  Select a temperature between 120 °C and 230 °C.  This type of heating is used to determine the energy consumption in air recirculation mode and the energy efficiency class.
<b>B</b>	Bottom heating	Cook pizza or food that requires a lot of heat from below. The bottom heating element and the ring heating element in the ba ck wall heat the cooking compartment.
	Pizza setting	Final baking or cook food in a bain marie. The heat is emitted from below.
	Full-surface grill Grill settings: 1 = low 2 = medium 3 = high	Grill flat items such as vegetables and sausages, or make toast. G ratinate food.  The entire area below the grill element becomes hot.
	Hot air grilling	Roast poultry, whole fish or larger pieces of meat. The grill element and the fan switch on and off alternately. The fan circulates the hot air around the food.
	Top/bottom heating	Traditionally bake or roast on one level. This type of heating is esp ecially good for cakes with moist toppings. The heat is emitted evenly from above and below. This type of heating is used to measure the energy consumption in the conventional mode.

## Other functions

This is where you can find an overview of other functions on the function selector or in the menu of your appliance.

Symbol	Lighting	Use
<b></b>	Rapid heating	Rapidly preheat the cooking compartment without accessories.  → "Rapid heating", Page 11
-,	Function	Light up the cooking compartment without heating.  → "Lighting", Page 8

# 4.4 Temperature and setting levels

There are different settings for the types of heating and functions.

**Note:** For temperature settings above 250 °C, the appliance reduces the temperature to approx. 240 °C after approx. 10 minutes. If your appliance has the top/bottom heating or bottom heating types, this temperature

reduction does not take place there.

Symbol	Zero setting	Use
•	Function	The appliance is not heating up.
50 – 275	Temperature range	Set the temperature in the cooking compartment in °C.
1, 2, 3 or I, II, III	Grill settings	Set the grill settings for Full-surface grill  1 = low  2 = medium  3 = high

### **Heat-up indicator**

The appliance indicates when it is heating up.

When the appliance is heating, the symbol lights up on the display. This symbol goes out when heating is paused.

When you preheat the appliance, the optimal time to place your food in the cooking compartment is when the symbol first goes out.

**Note:** Due to thermal inertia, the temperature displayed may differ slightly from the actual temperature inside the cooking compartment.

### 4.5 Cooking compartment

The functions in the cooking compartment make your appliance easier to use.


### **Shelf supports**

The shelf supports in the cooking compartment enable you to place accessories at different heights.

Your appliance has 5 shelf positions. The shelf positions are numbered from bottom to top.

You can remove the shelf supports, e.g. for cleaning.

→ "Shelf supports", Page 19



### **Self-cleaning surfaces**

The back wall in the cooking compartment is self-cleaning.

The self-cleaning surfaces are coated with a porous, matt ceramic layer and have a rough surface.

When the appliance is in operation, the self-cleaning surfaces absorb splashes from roasting or grilling and break them down.

If the self-cleaning surfaces no longer clean themselves adequately during operation, heat up the cooking compartment specifically to the right temperature.

→ "Cleaning self-cleaning surfaces in the cooking compartment", Page 15

## Lighting

The oven lamp lights up the cooking compartment.

With most types of heating and functions, the lighting lights up during operation. The lighting goes off when operation ends.

The oven light setting on the function selector can be used to switch on the light without heating.

The cooling fan also runs in the oven light position.

### Cooling fan

The cooling fan switches on automatically during operation.

The hot air escapes above the door.

### **ATTENTION!**

Covering the ventilation slots will cause the appliance to overheat.

▶ Do not cover the ventilation slots.

To ensure that the appliance cools down more quickly after operation, the cooling fan continues to run for a certain period afterwards.

### **Appliance door**

If you open the appliance door during operation, the operation continues.

### **Accessories**

Use original accessories. These have been made especially for your appliance.

**Note:** Accessories may become deformed if they get hot. Deformation has no effect on function. As the accessory cools down, it will regain its original shape.

The accessories supplied may differ depending on the appliance model.

Accessories		Use
Wire rack		<ul> <li>■ Cake tins</li> <li>■ Ovenproof dishes</li> <li>■ Tableware</li> <li>■ Meat, e.g. roasting joints or steak</li> <li>■ Frozen meals</li> </ul>
Universal pan		<ul> <li>Moist cakes</li> <li>Baked items</li> <li>Bread</li> <li>Large roasts</li> <li>Frozen meals</li> <li>Catching dripping liquids, e.g. fat when grilling foo d on the wire rack.</li> </ul>
Water bowl	200-11 Island 300-11 Island 300-11 Island	Cooking with the steam function The horizontal markings on the water bowl indicate t he volume of water:  100 ml 150 ml 200 ml Note: Max. 250 ml

### 5.1 Locking function


The locking function prevents the accessories from tilting when they are pulled out.

You can pull out the accessories approximately halfway without them tipping. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

### 5.2 Sliding accessories into the cooking compartment

Always slide accessories into the cooking compartment correctly. This is the only way to ensure that accessories can be pulled out approximately halfway without tipping.

- 1. Turn the accessories so that the notch a is at the rear and is facing downwards.
- 2. Insert accessories between the two guide rods for the shelf position.



3. Push the accessory all the way in, making sure that it does not touch the appliance door.


**Note:** Take any accessories that you will not be using out of the cooking compartment while the appliance is in operation.

### **Combining accessories**

You can combine the wire rack with the universal pan to catch any liquid that drips down.

- 1. Place the wire rack on the universal pan so that both spacers are on the rear edge of the universal pan.
- 2. Insert the universal pan between the two guide rods for a shelf position. In so doing, the wire rack is on top of the upper guide rod.

Wire rack on universal pan



#### 5.3 Other accessories

You can purchase other accessories from our customer service, specialist retailers or online.

You will find a comprehensive range of products for your appliance in our brochures and online: <a href="https://www.bosch-bome.com">www.bosch-bome.com</a>

Accessories are appliance-specific. When purchasing accessories, always quote the exact product number (E no.) of your appliance.

You can find out which accessories are available for your appliance in our online shop or from our customer service.

### Before using for the first time

Configure the settings for initial start-up. Clean the appliance and accessories.

#### 6.1 Initial use

You need to make settings for initial use before you can use your appliance.

### Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

**Requirement:** The function selector must be set to the "Off" position 0.

- 1. Use the or + button to set the time.
- 2. Press the button.
  - ✓ The time that is set appears in the display.

### 6.2 Cleaning the appliance before using it for the first time

Before using the appliance to cook food for the first time, you must clean the cooking compartment and accessories.

- 1. Remove the product information and the accessories from the cooking compartment. Remove any leftover packaging, such as polystyrene pellets, and any adhesive tape that is in or on the appliance.
- 2. Wipe the smooth surfaces in the cooking compartment with a soft, damp cloth.
- 3. Set the type of heating and the temperature.
  - → "Basic operation", Page 10

Type of heating	3D hot air
Temperature	Maximum
Duration	1 hour

- 4. Ventilate the kitchen while the appliance is heating.
- 5. Switch off the appliance after the specified cooking time.
- 6. Once the appliance has cooled down, clean the smooth surfaces in the cooking compartment with a detergent solution and a dish cloth.
- 7. Clean the accessories with soapy water and a dish cloth or soft brush.

### **Basic operation**

### 7.1 Switching the appliance on and off

- 1. To switch on the appliance, turn the function selector to any position other than the zero setting 0.
- 2. To switch off the appliance, turn the function selector to the zero setting 0.

### 7.2 Setting the type of heating and temperature

- 1. Use the function selector to set the type of heating.
- 2. Use the temperature selector to set the temperature or grill setting.
  - ✓ The appliance starts heating after a few seconds.
- 3. When your food is ready, switch off the appliance.

Tip: The most suitable type of heating for your food can be found in the description of the type of heating.

→ "Types of heating and functions", Page 6

**Note:** You can also set a cooking time and an operation end time on the appliance.

→ "Time-setting options", Page 11

### Changing the type of heating

You can change the type of heating at any time.

- ▶ Use the function selector to change the type of heating.
- ✓ The appliance applies the change after a few seconds.

### Changing the temperature

You can change the temperature at any time.

- ▶ Use the temperature selector to change the temperature.
- ✓ The appliance applies the change after a few seconds.

### Rapid heating

To save time, you can use rapid heating to shorten the preheat time.

# 8.1 Setting rapid heating


To ensure an even cooking result, do not place the food in the cooking compartment until rapid heating has come

- 1. Use the function selector to select rapid heating
- 2. Use the temperature selector to set the temperature.

Only use rapid heating when a temperature of over 100 °C has been set.

- ✓ Rapid heating starts after a few seconds.
- ✓ When the rapid heating process ends, an audible signal sounds and the heating indicator goes out.
- 3. Use the function selector to set a suitable type of heating.

The most suitable types of heating are:



4. Place the food in the cooking compartment.

# **Time-setting options**

Your appliance has different time-setting options, with which you can control its operation.

## 9.1 Overview of the time-setting options

Use the button to select the different time-setting options.

Time-setting option	Use
Timer 🗘	You can set the timer to run independently of the operation. It does not affect the a ppliance.
Cooking time I→I	If you set a cooking time, the appliance stops heating automatically once this time has elapsed.
End →I	For the cooking time, you can set the time at which you want the operation to end. The appliance starts up automatically so that the operation finishes at the required time.
Time	You can set the time.

### 9.2 Setting the timer

The timer runs independently during the operation. You can set the timer to times of up to 23 hours and 59 minutes, regardless of whether the appliance is on or off. The timer has its own signal so that you can tell whether it is the timer or a cooking time that has elapsed.

**Note:** The timer and cooking time cannot count down at the same time. If a cooking time has already been set, you cannot set the timer.

- 1. Press the  $\stackrel{\bigcirc}{\approx}$  button repeatedly until  $\stackrel{\triangle}{\hookrightarrow}$  is highlighted on the display.
- 2. Use the or + button to set the timer duration.

Button	Default value
_	5 minutes
+	10 minutes

The timer duration can be set in 30-second increments up to 10 minutes. The time increments then become bigger as the value increases.

- ✓ The timer starts and the timer duration begins to count down after a few seconds.
- ✓ An audible signal sounds and the timer duration is zero in the display when the timer duration has elapsed.
- 3. Press any button to switch off the timer.

# Changing the timer

You can change the timer duration at any time.

Requirement:  $\triangle$  is highlighted in the display.

- ▶ Use the or + button to change the timer duration.
- ✓ The appliance applies the change after a few seconds.

### Cancelling the timer

You can cancel the timer duration at any time.

Requirement:  $\triangle$  is highlighted in the display.

- ▶ Use the button to reset the timer duration to zero.
- ✓ After a few seconds, the appliance applies the change and Q goes out.

### 9.3 Setting the cooking time

You can set the cooking time for operation of up to 23 hours 59 minutes.

Requirement: The type of heating and a temperature or setting have been set.

- 1. Press the  $\stackrel{\bigcirc}{\sim}$  button repeatedly until  $|\rightarrow|$  is highlighted on the display.
- 2. Use the or + button to set the time.

Button	Default value
-	10 minutes
+	30 minutes

The cooking time can be set in one-minute increments up to one hour, and then in five-minute increments.

- ✓ After a few seconds, the appliance starts heating and the cooking time counts down.
- ✓ When the cooking time has elapsed, a signal sounds and the duration is at zero on the display.
- 3. Once the cooking time has elapsed:
  - Press any button to end the signal prematurely.
  - To set another cooking time, press the + button.

- When your food is ready, switch off the appliance.

### Changing the cooking time

You can change the cooking time at any time.

**Requirement:**  $\rightarrow$  is highlighted in the display.

- ► Change the cooking time using the or + button.
- ✓ The appliance applies the change after a few seconds.

### Cancelling the cooking time

You can cancel the cooking time at any time.

**Requirement:**  $\rightarrow$  is highlighted in the display.

- ▶ Reset the cooking time to zero using the button.
- ✓ After a few seconds, the appliance applies the change and continues to heat without a cooking time.

### 9.4 Setting the end time

You can delay the time at which cooking is due to finish by up to 23 hours and 59 minutes.

### **Notes**

- The end time cannot be set for types of heating with grill function.
- In order to achieve a good cooking result, do not delay the end time once the appliance is already in operation.
- Food will spoil if you leave it in the cooking compartment too long.

## Requirements

- The type of heating and a temperature or setting have been set.
- A cooking time is set.
- 1. Press the button repeatedly until is highlighted in the display.
- 2. Press the or + button.
  - ✓ The display shows the calculated end time.
- 3. Use the or + button to delay the end time.
  - ✓ After a few seconds, the appliance applies the set-ting and the display shows the set end time.
  - ✓ Once the calculated start time is reached, the appliance starts heating up and the cooking time counts down.
  - ✓ When the cooking time has elapsed, a signal sounds and the duration is at zero on the display.
- 4. Once the cooking time has elapsed:
  - Press any button to end the signal prematurely.
  - To set another cooking time, press the + button.
  - When your food is ready, switch off the appliance.

### Changing the end time

In order to achieve a good cooking result, you can only change the set end time before operation starts and the cooking time starts counting down.

**Requirement:** → is highlighted on the display.

- ▶ Use the or + button to delay the end time.
- ✓ The appliance applies the change after a few seconds.

### Cancelling the end time

You can delete the set end time at any time.

**Requirement:** → is highlighted on the display.

- ▶ Reset the end time to the current time plus the set cooking time using the button.
- ✓ After a few seconds, the appliance applies the change and starts heating up. The cooking time counts down.

### 9.5 Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

**Requirement:** The function selector must be set to the "Off" position 0.

- 1. Use the or + button to set the time.
- 2. Press the button.
  - ✓ The time that is set appears in the display.

### Changing the time on the clock

You can change the time on the clock at any time.

**Requirement:** The function selector must be set to the "Off" position 0.

- 1. Press and hold the button until the clock flashes on the display.
- 2. Use the or + button to change the time.
  - ✓ The appliance applies the change after a few seconds.

### Steam assistance

When cooking with steam assistance, steam is generated in the cooking compartment. This gives your food a crispy crust and a glossy surface. Food stays juicy and tender, and only undergoes a minimum reduction in volume.



# ✓!\ WARNING – Risk of burns!

While the appliance is in operation, the water bowl reaches high temperatures.

- ▶ Never remove the water bowl while the appliance is in operation.
- ▶ Only remove the water bowl once it has cooled down.



# ✓! WARNING – Risk of scalding!

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- ► Open the appliance door carefully.
- ► Keep children at a safe distance.

#### ATTENTION!

Only use the water bowl that is enclosed with the appliance.

▶ Never fill the bowl while cooking.

Only use the water bowl to cook with steam assistance.

- ▶ Before you use other functions, first remove the water bowl.
- ▶ Do not use hard, metallic or sharp objects or aggressive cleaning agents.

### 10.1 Before using the steam function

Before using the steam function each time, make sure that your appliance is supplied with sufficient water.

### Inserting a water bowl

- 1. Place the water bowl in the middle of the cooking compartment floor.
- 2. Fill the water bowl sufficiently.

The markings on the edge of the water bowl indicate the volume of water:

- 100 ml
- 150 ml
- 200 ml

Note: Max. 250 ml

You can find information on suitable volumes of water for steam assistance in the section on

→ "How it works", Page 21.

# 10.2 Setting steam-assisted cooking

### Requirements

- The cooking compartment is cold.
- The water bowl is placed in the cooking compartment and has been filled.
- → "Before using the steam function", Page 13
- 1. Use the function selector to set Hot air steam .



- 2. Use the temperature selector to set the required temperature.
  - Set a temperature above 100 °C to ensure optimum steam generation.
  - ✓ The appliance starts heating after a few seconds.
- 3. When the food is ready, switch off the appliance.
- 4. Dry the cooking compartment.
  - → "After using steam operation", Page 13

### 10.3 After using steam operation

Dry the appliance after each steam operation.

Note: Observe the information on cleaning.

→ "Cleaning and servicing", Page 13

### Drying the cooking compartment

**Requirement:** The appliance has cooled down.

- 1. Take the water bowl out of the cooking compartment and clean it with a soft cloth.
- 2. Dry the cooking compartment with a sponge or a soft cloth.
- 3. Remove any limescale marks with a cloth soaked in vinegar, then wipe with clean water and dry with a soft cloth.

# Childproof lock

You can secure your appliance to prevent children from accidentally switching it on or changing the settings.

### 11.1 Activating and deactivating the childproof lock

**Requirement:** The function selector must be set to the zero setting 0.

- ▶ Press and hold the button until appears on the display.
- Note: After a power cut, the childproof lock is deactivated.

# Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

### 12.1 Cleaning products

In order to avoid damaging the various oven surfaces on the appliance, do not use unsuitable cleaning products.



# ✓! WARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

▶ Do not use steam- or high-pressure cleaners to clean the appliance.

#### ATTENTION!

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive cleaning products.
- ▶ Do not use cleaning products with a high alcohol content.
- ▶ Do not use hard scouring pads or cleaning sponges.
- ▶ Do not use any special cleaners for cleaning the appliance while it is hot.

Using oven cleaner in a hot cooking compartment damages the enamel.

- ▶ Never use oven cleaner in the cooking compartment when it is still warm.
- ▶ Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

New sponge cloths contain residues from production.

▶ Wash new sponge cloths thoroughly before use.

### 12.2 Suitable cleaning agents

Only use cleaning agents that are suitable for the different surfaces on your appliance.

Follow the instructions on cleaning the appliance.

### **Appliance front**

Surface	Suitable cleaning agents	Hints
Stainless steel	■ Hot soapy water Hot soapy water ■ Special stainless steel cleaning products suitable for hot surfaces	To prevent corrosion, remove any patches of limescale, gr ease, starch or albumin (e.g. egg white) from stainless ste el surfaces immediately. Apply a thin layer of the stainless steel cleaning product.
Plastic or painted surfaces E.g. con trol panel	¡ Hot soapy water Hot soapy w ater	Do not use glass cleaner or a glass scraper.

## **Appliance door**

Area	Suitable cleaning agents	Hints
Door panels	■ Hot soapy water Hot soapy water	Do not use a glass scraper or steel wool. <b>Tip:</b> Remove the door panels in order to clean them thoro ughly.  → "Appliance door", Page 16
Door cover	■ Made of stainless steel: Stainless steel cleaner ■ Made of plastic: Hot soapy waterHot soapy wat er	Do not use glass cleaner or a glass scraper. <b>Tip:</b> Remove the door cover for thorough cleaning.  → "Appliance door", Page 16
Door handle	■ Hot soapy waterHot soapy water	To avoid permanent stains, remove descaling agents from the door handle immediately.
Door seal	■ Hot soapy water	Do not remove or scrub.

# **Cooking compartment**

Area	Suitable cleaning agents	Hints
Enamel surfaces	<ul> <li>■ Hot soapy water Hot soapy water</li> <li>■ Vinegar solution</li> <li>■ Oven cleaner</li> </ul>	Soak any heavily soiled areas and use a brush or steel w ool.  Leave the appliance door open to dry the cooking compa rtment after cleaning it.  Notes  Enamel burns at very high temperatures, causing min or discol-ouration. The functionality of your appliance is n ot affected by this.  The edges of thin trays cannot be completely enamelled and may be rough. This does not impair the c orrosion protection.  Food residues leave a white coating on the enamel sur faces. The coating does not pose a health risk. The functionality of your appliance is not affected by this. You can remove residues with lemon juice.
Self-cleaning surfaces		Follow the instructions for self-cleaning surfaces.
Glass cover for the oven light	■ Hot soapy waterHot soapy water	Use oven cleaner to remove very heavy soiling.
Shelf supports	■ Hot soapy waterHot soapy water	Soak any heavily soiled areas and use a brush or steel w ool. <b>Tip:</b> Remove the shelf supports for cleaning.  → "Shelf supports", Page 19
Accessory/ies	■ Hot soapy waterHot soapy water ■ Oven cleaner	Soak any heavily soiled areas and use a brush or steel w ool.  Enamelled accessories are dishwasher-safe.
Water bowl	■ Hot soapy water Hot soapy water	Wash and dry with a soft cloth. The water bowl is dishwasher-proof. Do not use hard, metallic or sharp objects or aggressive cleaning agents.  → "Steam assistance", Page 12  Note: Wipe off limescale stains with a soft cloth and vine gar water.

### 12.3 Cleaning the appliance

In order to avoid damaging the appliance, you must clean your appliance only as specified, and with suitable cleaning products.



# WARNING – Risk of burns!

The appliance becomes hot during operation.

▶ Allow the appliance to cool down before cleaning.



# WARNING – Risk of fire!

Loose food remnants, fat and meat juices may catch fire.

▶ Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Requirement: Read the information on cleaning agents.

→ "Cleaning products", Page 13

- 1. Clean the appliance using hot soapy water and a dish cloth.
  - For some surfaces, you can use alternative cleaning agents.
  - → "Suitable cleaning agents", Page 14
- 2. Dry with a soft cloth.

### 12.4 Cleaning self-cleaning surfaces in the cooking compartment

The back panel in the cooking compartment is selfcleaning.

The self-cleaning surfaces are coated with a porous, matt ceramic layer and have a rough surface. When the appliance is in operation, the self-cleaning surfaces absorb splashes from baking, roasting or grilling, and break them down. If the self-cleaning surfaces no longer clean themselves adequately during operation, heat up the cooking compartment specifically to the right temperature.

### ATTENTION!

If you do not clean the self-cleaning surfaces regularly, they may become damaged.

- ▶ If dark stains are visible on the self-cleaning surfaces, heat up the cooking compartment.
- ▶ Do not use oven cleaner or abrasive cleaning aids. If oven cleaner accidentally comes into contact with the self-cleaning surfaces, dab it off immediately using water and a sponge cloth. Do not rub.
- 1. Remove accessories and cookware from the cooking compartment.
- 2. Detach the shelf supports and remove them from the cooking compartment.
  - → "Shelf supports", Page 19
- 3. Remove coarse dirt using soapy water and a soft cloth:
  - From the smooth enamel surfaces
  - From the inside of the appliance door
  - From the glass cover on the oven lamp

This prevents stains that cannot be removed.

- 4. Remove any objects from the cooking compartment. The cooking compartment must be empty.
- 5. Set 3D hot air.
- 6. Set the maximum temperature.
  - ✓ The appliance starts heating after a few seconds.
- 7. Switch off the appliance after one hour.
- 8. Once the appliance has cooled down, wipe the cooking compartment with a damp cloth.

**Note:** Marks may appear on the self-cleaning surfaces.

Residues of sugars and proteins in the food are not removed and stick to the surfaces. Red stains are residues from salty food – they are not rust.

The marks are not hazardous to health. These marks do not impair the cleaning ability of the selfcleaning surfaces.

- 9. Attach the shelf supports.
  - → "Shelf supports", Page 19

### Cleaning aid

The Cleaning aid is a quick alternative for occasionally cleaning the cooking compartment. The cleaning aid softens dirt by evaporating the soapy water. It is then easier to remove the dirt.

### 13.1 Setting the cleaning aid

# MARNING – Risk of scalding!

If there is water in the cooking compartment when it is hot, this may create hot steam.

▶ Never pour water into the cooking compartment when the cooking compartment is hot.

**Requirement:** The cooking compartment must have cooled down completely.

- 1. Remove any accessories from the cooking compartment.
- 2. Mix 0.4 litres water with a drop of washing-up liquid and pour into the centre of the cooking compartment floor. Close the appliance door. Do not use distilled water.
- 3. Use the function selector to set the Bottom heating by type of heating.
- 4. Use the temperature selector to set 80 °C.
- 5. Press the  $\stackrel{\bigcirc}{\sim}$  button repeatedly until  $|\rightarrow|$  is highlighted on the display.
- 6. Use the or + button to set the time to 4 minutes.
  - ✓ After a few seconds, the appliance starts heating and the cooking time counts down.
  - ✓ When the cooking time has elapsed, a signal sounds and the duration is at zero on the display.
- 7. Switch off the appliance and leave the cooking compartment to cool down for approx. 20 minutes.

### 13.2 Cleaning the cooking compartment after using the cleaning aid

### ATTENTION!

The prolonged presence of moisture in the cooking compartment leads to corrosion.

▶ After using the cleaning assistance, wipe the cooking compartment and allow it to dry completely.

Requirement: The cooking compartment has cooled down.

- 1. Wipe out the remaining water in the cooking compartment using an absorbent sponge cloth.
- 2. Clean the smooth enamel surfaces in the cooking compartment with a dish cloth or a soft brush. Remove stubborn food remnants using a stainless steel scouring pad.
- 3. Remove limescale with a cloth soaked in vinegar, and wipe this away with clean water.
- 4. Dry the cooking compartment with a soft cloth.
- 5. Once the cooking compartment is sufficiently clean:
  - In order to dry the cooking compartment, leave the appliance door open in the detent position (approx. 30°) for approx. 1 hour.
  - To dry the cooking compartment quickly, heat up the appliance for approx. 5 minutes at 3D hot air and 50 °C while the door is open.

### **Appliance door**

To clean the appliance door thoroughly, you can disassemble the appliance door.

### 14.1 Detaching the appliance door

WARNING – Risk of injury!

Components inside the appliance door may have sharp edges.

➤ Wear protective gloves.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

► Keep your hands away from the hinges.


1. Open the appliance door fully.

2. WARNING – Risk of injury!

When the hinges are not secured, they can snap shut with great force.


► Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open. Open the locking levers on the left- and right-hand hinges.

### Locking levers opened




The hinge is now secured and cannot snap shut.

Locking levers closed



The appliance door is secured and cannot be detached.

- ✓ The locking levers are open. The hinges are now secured and cannot snap shut.
- 3. Close the appliance door fully ①. Grab hold of the appliance door with both hands (on the left and right) and pull it upwards and out ②.



4. Carefully place the appliance door on a level surface.

### 14.2 Attaching the appliance door




# WARNING - Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

► Keep your hands away from the hinges.

When the hinges are not secured, they can snap shut with great force.

- ▶ Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open.
- 1. Slide the appliance door straight onto the two hinges ①. Slide the appliance door on as far as it will go.
- 2. Open the appliance door fully.
- 3. Close the locking levers on the left- and right-hand hinges ②.



- ✓ The locking levers are closed. The appliance door is secured and cannot be detached.
- 4. Close the appliance door.

### 14.3 Removing the door panes




## WARNING - Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


► Keep your hands away from the hinges.

Components inside the appliance door may have sharp edges.


- ► Wear protective gloves.
- 1. Open the appliance door fully.
- 2. Open the locking levers on the left- and right-hand hinges ①.
  - ✓ The locking levers are open. The hinges are now secured and cannot snap shut.
- 3. Close the appliance door fully 2.




- 4. Push on the left- and right-hand side of the door cover from the outside  ${\tt @}$  until it is released.
- 5. Remove the door cover ②.




6. Lift out the inner pane and set it down carefully on a flat surface.




7. Open the appliance door and remove the door seal.



8. Lift out the intermediate pane and set it down carefully on a flat surface.



- 9. If necessary, you can remove the condensate trough for cleaning.
  - Open the appliance door.
  - Tilt the condensate trough upwards and remove it.



# 10. WARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

▶ Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

Clean the removed door panels on both sides with glass cleaner and a soft cloth.

- 11. Clean the condensate trough with a cloth and hot soapy water.
- 12. Clean the appliance door.
  - → "Suitable cleaning agents", Page 14
- 13. Dry the door panels and refit them.
  - → "Fitting the door panes", Page 18

# 14.4 Fitting the door panes




# WARNING - Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


▶ Keep your hands away from the hinges.

Components inside the appliance door may have sharp edges.


- ▶ Wear protective gloves.
- 1. Open the appliance door fully.
- 2. Place the condensate trough vertically into the retainer and turn it downwards.




3. Slide the intermediate pane into the left- and righthand retainers a.




4. Push the intermediate pane upwards until it is in the left- and right-hand retainers a.




5. Open the appliance door and attach the door seal.




6. Slide the inner pane into the left- and right-hand retainers a.



7. Push the inner pane upwards until it is in the leftand right-hand retainers a.



- 8. Put the door cover into position ① and push down on it until you hear it click into place.
- 9. Open the appliance door fully.
- 10. Close the locking levers on the left- and right-hand hinges 2.



- ✓ The locking levers are closed. The appliance door is secured and cannot be detached.
- 11. Close the appliance door.

Note: Do not use the cooking compartment again until the door panes have been correctly fitted.

## **Shelf supports**

To clean the rails and the cooking compartment, or to replace the rails, you can remove these.


# 15.1 Detaching the shelf supports



WARNING - Risk of burns!

The shelf supports get very hot

- ▶ Never touch the shelf supports when hot.
- ► Always allow the appliance to cool down.
- ► Keep children at a safe distance.
- 1. Lift the rail forwards slightly ① and detach it ②.
- 2. Pull the whole rail to the front 3 and remove it.




- 3. Clean the rail.
  - → "Cleaning products", Page 13

# 15.2 Attaching the shelf supports

Note: The rails only fit on the right or left.

- 1. First, push the rail into the middle of the rear socket ① until the rail rests against the cooking compartment wall, and then push this back 2.
- 2. Push the rail into the front socket 3 until the rail also rests against the cooking compartment wall, and then press this downwards 4.



### **Troubleshooting**

You can rectify minor faults on your appliance yourself.

Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



# ✓! WARNING – Risk of injury!

Improper repairs are dangerous.

- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ If the appliance is defective, call Customer Service.



# WARNING – Risk of electric shock!

Improper repairs are dangerous.

- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

### 16.1 Malfunctions

Fault	Cause and troubleshooting
The appliance is not	The circuit breaker in the fuse box has tripped.  ► Check the circuit breaker in the fuse box.
working.	There has been a power cut.  ► Check whether the lighting in your room or other appliances are working.
The time flashes in t he display.	There has been a power cut.  ► Reset the time.  → "Setting the time on the clock", Page 12
The appliance does not switch off fully at the end of a cooking time.	At the end of a cooking time, the appliance stops heating up. The oven light and cooling fan do not switch off.  For types of heating with recirculation, the fan continues to run in the back wall of the cooking compartment.  Turn the function selector to the off position.  The appliance is switched off.  The oven light and the fan in the back wall are switched off.  The cooling fan switches off automatically as soon as the appliance has cooled down.
<b>SPFE</b> lights up in the display and no settings can be made on the appliance.	Childproof lock is activated.  ► Use the  button to deactivate the childproof lock.  → "Childproof lock", Page 13
A message with $\stackrel{\textstyle E}{}$ a ppears in the display, e.g. $\stackrel{\textstyle E05-32}{}$ .	Electronics fault  1. Press the button.  If required, reset the time.  ✓ If the fault was a one-off, the error message disappears.  2. If the error message appears again, call the after-sales service.  Quote the exact error message and the E no. of your appliance.  → "Customer Service", Page 21

### 16.2 Replacing the oven light bulb

If the light in the cooking compartment fails, change the oven light bulb.

Note: Heat-resistant, 40 – 43-watt, 230 V halogen bulbs are available from the after-sales service or specialist retailers. Only use these bulbs. Hold the new halogen bulbs only with a clean, dry towel. This increases the service life of the bulb.



# WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- ▶ Caution should be exercised here in order to avoid touching heating elements.
- ▶ Young children under 8 years of age must be kept away from the appliance.



# WARNING – Risk of electric shock!

When changing the bulb, the bulb socket contacts are live.

- ▶ Before replacing the bulb, ensure that the appliance is switched off in order to prevent a potential electric shock.
- ▶ Also unplug the appliance from the mains or switch off the fuse in the fuse box.



# ✓! WARNING – Risk of injury!


The glass cover may already have broken due to external influences or it may break due to excessive pressure when being installed or removed.

- ▶ Exercise caution when installing or removing the glass cover.
- ▶ Use gloves or a tea towel.

### Requirements

- The appliance is disconnected from the power supply.
- The cooking compartment has cooled down.
- You must have a new halogen lamp to replace the old one.
- 1. Place a tea towel in the cooking compartment to prevent damage.
- 2. Turn the glass cover anti-clockwise to remove it ①.
- 3. Pull out the halogen bulb without turning it ②.





- 4. Insert the new halogen bulb and press it firmly into the socket.
  - Make sure that the pins are positioned correctly.
- 5. Depending on the appliance model, the glass cover may have a sealing ring. Attach the sealing ring.
- 6. Screw in the glass cover.
- 7. Remove the tea towel from the cooking compartment.
- 8. Connect the appliance to the power supply.

### Disposal

### 17.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.

This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment – WEEE).

The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

#### **Customer Service**

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-№) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

This product contains light sources from energy efficiency class G.

### 18.1 Product number (E-Nº) and production number (FD)

You can find the product number (E-№) and the production number (FD) on the appliance's rating plate. You will see the rating plate with these numbers if you open the appliance door.



Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

#### How it works

Here, you can find the ideal settings for various types of food as well as the best accessories and cookware. We have perfectly tailored these recommendations to your appliance.

### 19.1 General cooking tips

Take note of the following information when cooking all types of food.

- The temperature and cooking time depend on the amount of food and the recipe. Settings ranges are specified for this reason. Try using the lower values to start with.
- The setting values apply to food placed in the cooking compartment while the cooking compartment is still cold. If you want to preheat anyway, do not place accessories into the cooking compartment until it has finished preheating.
- Remove any accessories that are not being used from the cooking compartment.

### **ATTENTION!**

Acidic food may damage the wire rack

▶ Do not place acidic food, such as fruit or food with an acidic marinade directly on the wire rack.

### Information for those allergic to nickel

In rare cases, small amounts of nickel may pass into the food.

You can buy suitable accessories from customer service, from specialist retailers or online.

→ "Other accessories", Page 10

### 19.2 Notes on baking

When baking, use the shelf positions indicated.

Baking on one level	Height
Deep baked goods or tin on wire rack	2
Flat baked goods or goods in a baking tray	3
Baking on two levels	Height
Universal pan	3
Baking tray	1
Baking tins on the wire rack:	Height
First wire rack	3
Second wire rack	1
Baking on three levels	Height
Baking tray	5
Universal pan	3
Baking tray	1

#### **Notes**

- When baking on several layers, use hot air. Baked goods that are placed in the oven at the same time will not necessarily be ready at the same time.
- Position baking tins/dishes either next to one another or offset on different shelves so that they are not directly one above the other in the cooking compartment.
- For best results, we recommend using dark-coloured metal baking tins.

### 19.3 Notes on roasting and grilling

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry, meat or fish is placed into a cold cooking compartment.

- The larger the poultry, meat or fish, the lower the cooking temperature and the longer the cooking time.
- Turn the poultry, meat or fish after approx. 1/2 to 2/3 of the time listed.
- When you turn poultry, ensure that the breast side or skin side is underneath to begin with.

### Roasting and grilling on the wire rack

Roasting on the wire rack works particularly well for large poultry or for multiple pieces at the same time.

- Depending on the size and type of the food to be roasted, add up to 1/2 litre water to the universal pan. You can make a sauce from the juices that are collected. This also means that less smoke is produced and the cooking compartment does not become as dirty.
- Keep the appliance door closed when using the grill.

Never grill with the appliance door open.

■ Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. This means that any dripping fat is caught.

### Roasting in cookware

When preparing food in cookware with a lid, the cooking compartment remains cleaner.

Follow the manufacturer's instructions for your roasting dishes. Glass cookware is best.

#### Cookware without lid

- Use a deep roasting dish.
- Place the cookware onto the wire rack.
- If you do not have any suitable cookware, use the universal pan.

### Cookware with lid

- Place the cookware onto the wire rack.
- Meat, poultry and fish can also become crispy in a covered roasting dish. Use a roasting dish with a glass lid. Set a higher temperature.



# WARNING – Risk of injury!

If hot glass cookware is placed on a wet or cold surface, the glass may shatter.

▶ Place hot glass ovenware on a dry mat after cooking.



# WARNING – Risk of scalding!

Very hot steam may escape when the lid is opened after cooking. Steam may not be visible, depending on the temperature.

- ▶ Lift the lid in such a way that the hot steam can escape away from you.
- ► Keep children away from the appliance.

### 19.4 List of foods

Recommended settings for a variety of foods, sorted into food categories.

### Recommended settings for various types of food

Food	Accessory/cookwa re	Height	Type of heating	Temperature i n °C/grill setti ng	Cooking time in mins
Sponge cake, simple	Ring-shaped tin or L oaf tin	2		150-170	50-70
Sponge cake, delicate (spring- form tin)	Ring-shaped tin or L oaf tin	2		150-170	60-80
Cake, 2 levels	Ring-shaped tin or L oaf tin	3+1	<b>(a)</b>	140-150	70-85
Fruit tart or cheesecake with s hortcrust pastry base	Springform cake tin, diameter 26 cm.	2		170-190	55-80
Brioche, 900 g, unfilled	Springform cake tin Ø 28 cm	2	<b>(3)</b>	155	25-40
Fatless sponge cake, 6 eggs	Springform cake tin Ø 28 cm	2		150-160 <sup>1</sup>	30-40
Marble cake, 2 kg	Universal pan	3	<b>®</b>	170	30-50
Swiss roll	Universal pan	3		180-200 <sup>1</sup>	10-15
Nussecken, 1.6 kg	Universal pan	3	<b>®</b>	165	25-45

Shortcrust tart with moist topping	Universal pan	2		160-180	55-95
Butter cake, 900 g	Universal pan	3	<b>®</b>	150	20-35
Yeast cake with moist topping	Universal pan	3		180-200	30-55
Muffins	Muffin tray	2		170-190	20-40
Small yeast cakes	Universal pan	3		160-180	25-35
Biscuits	Universal pan	3		140-160	15-25
Biscuits, 2 levels	Universal pan + Baking tray	3+1		140-160	15-25
Biscuits, 3 levels	Universal pan + x 2 Baking tray	5+3+1		140-160	15-25
Meringues	Universal pan	3		80-90 <sup>1</sup>	120-150
Bread, 1000 g (in a loaf tin or fr ee-form)	Universal pan or Lo af tin	2		<b>1.</b> 210-220 <sup>1</sup> <b>2.</b> 180-190 <sup>1</sup>	<b>1.</b> 10-15 <b>2.</b> 40-50
Pizza, fresh, on a baking tray	Universal pan	3	<b>B</b>	180-200	20-30
Pizza, fresh, thin-crust, on a pi zza tray	Pizza tray	2	Œ	250-270 <sup>1</sup>	8-13
Quiche	Tart dish or tin or Bl ack tray	2	Œ	190-210	25-35
Börek	Universal pan	1		180-200	40-50

Bake, savoury, cooked ingredients	Ovenproof dish	2		200-220	30-60
Chicken, 1.3 kg, unstuffed	Uncovered cookware	2	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	200-220	60-70
Small chicken portions, 250 g each	Uncovered cookware	3	<b>~</b>	220-230	30-35
Goose, unstuffed, 3 kg	Uncovered cookware	2	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	<b>1.</b> 140 <b>2.</b> 160	<b>1.</b> 130-140 <b>2.</b> 50-60
Joint of pork without rind, e.g. neck, 1.5kg	Uncovered cookware	2		160-170	130-150
Fillet of beef, medium, 1 kg <sup>2</sup>	Universal pan + Pan support	3		210-220	40-50 <sup>3</sup>
Pot-roasted beef, 1.5 kg <sup>4</sup>	Covered cookware	2		200-220	130-150
Sirloin, medium, 1.5 kg	Universal pan + Pan support	3	<b>%</b>	200-220	60-70 <sup>3</sup>
Burger, 3–4 cm thick <sup>5</sup>	Pan support	4		3	25-30 <sup>6</sup>
Leg of lamb, boned, medium, 1.0 kg, tied <sup>7</sup>	Uncovered cookware	2	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	170-190	70-808
Fish, grilled, whole, 300 g, e.g . trout <sup>2</sup>	Pan support	2	(%)	160-180	20-30

- 1. Preheat the appliance.
- 2. Slide the universal pan underneath the wire rack.
- 3. Turn the dish between halfway and two-thirds through the cooking time.
- 4. At the start, add liquid to the cookware so that at least 2/3 of the joint is covered in liquid
- 5. Slide the universal pan in underneath at shelf position 2.
- 6. Turn the dish 2/3 of the way through the cooking time.
- 7. Pour water into the dish so that it covers the base.
- 8. Do not turn the food.

# **Yoghurt**

Use your appliance to make yoghurt.

### **Preparing yoghurt**

- 1. Remove the accessories and shelf supports from the cooking compartment.
- 2. Pour the previously prepared yoghurt mixture into small containers, e.g. into cups or small jars.
- 3. Cover the containers with foil, e. g. with cling film.
- 4. Place the containers on the cooking compartment floor.
- 5. Set the appliance according to the recommended setting.
- 6. After making the yoghurt, leave it to cool in the refrigerator.

### **Recommended settings for desserts**

Food	Accessory/coo kware	Height	Type of heatin	Temperature in °C	Cooking time in mins
Yoghu rt	Individual mould s	Cooking compartment floor	1. 2. 4.	1. 100 2	1 <sup>1</sup> 2. 8-9 h

<sup>&</sup>lt;sup>1</sup>Preheat the appliance for 15 minutes. Do not use the rapid heating function.

### 19.5 Special cooking methods and other applications

Information and recommended settings for special cooking methods and other applications, e.g. low-temperature cooking.

### Steam assistance

If you are using steam-assisted cooking, steam is produced in the cooking compartment. This gives the food a crispy crust and a shiny surface. Furthermore, the food becomes tender and juicy inside and there is only a minimal reduction in its volume.

### Recommended settings for steam-assisted cooking

The water tank must always contain the recommended amount of water when placed on the base of the appliance.

Food	Accessory/cook ware	Height	Type of heating	Temperature in °C	Volume of water in ml	Cooking t ime in mi ns
White bread, 750 g	Universal pan	2		<b>1</b> . 220 <b>2</b> . 180	100	<b>1.</b> 15 <b>2.</b> 25-35
Bread, 1000 g (in a loaf tin or free-for m)	Universal pan	2	( <del>\&amp;</del> )	1. 220 2. 180	100	<b>1.</b> 15 <b>2.</b> 40-50
Flatbread	Universal pan	3	(S)	230-240	150	20-30
Bread rolls, fresh	Universal pan	3		180-190	100	25-30
Part-cooked rolls or ba guette, pre-baked	Pan support	3	(%)	190-200 <sup>1</sup>	100	8-10
Bread rolls, sweet, fres	Universal pan	3		190-200 <sup>1</sup>	100	15-20
Yeast cake in springfor m tin	Springform cake ti n Ø 28 cm	2		150-160	100	35-45
Plaited loaf, plaited ring	Universal pan	2		150-160	100	30-40
Small yeast cakes	Universal pan	2	(%)	160-170	100	25-35
Pizza, frozen, thin-crus t, x 1	Wire rack	2	<b>(%)</b>	190-200	100	15-20

Bake, savoury, cooked ingredients	Ovenproof dish	2	(S)	170-180	150	35-45
Small chicken portions, 250 g each	Uncovered cook- ware	2	<b>(%)</b>	220-230	150	30-40
Chicken, 1.3 kg, un- st uffed	Uncovered cook- ware	2	<b>(%)</b>	200-220	200	65-75
Joint of pork without rin d, e.g. neck, 1.5 kg	Uncovered cook- ware	2	<b>€</b> 3	160-180	250	130-150
Fish, baked, whole, 30 0 g, e.g. trout	Uncovered cook- ware	2	(S)	180-190	100	25-35
Pizza, baked, reheating	Pan support	2	<b>(%)</b>	170-180 <sup>1</sup>	100	7-10
Bakes, e.g. lasagne, p otato gratin, 1 portion, r eheating	Uncovered cook- ware	2	(%)	150-160	100	15-20
Bread rolls, baguette, r eheating	Pan support	2	<b>(%)</b>	150-160 <sup>1</sup>	100	6-8
<sup>1</sup> Preheat the appliance.						

### 19.6 Test dishes

### **Baking**

- The setting values apply to food that is placed into a cold cooking compartment.
- Take note of the information on preheating in the recommended settings tables. These setting values apply without rapid heat-up.
- For baking, use the lower of the temperatures indicated first.
- Items that are placed in the appliance on baking trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.
- Shelf positions when baking on 2 levels:
- Universal pan: Shelf position 3
  Baking tray: Shelf position 1
  Baking tins on the wire rack:
  First wire rack: Shelf position 3
  Second wire rack: Shelf position 1
- Shelf positions when baking on 3 levels:
- Baking tray: Shelf position 5Universal pan: Shelf position 3Baking tray: Shelf position 1
- Hot water sponge cake
- When baking on 2 levels, place the springform tins each in the centre of the wire racks.
- As an alternative to a pan support, you can also use the Air Fry baking tray offered by us.

### Recommended settings for baking

Food	Accessory/cookwar e	Height	Type of heating	Temperature i n °C	Cooking time in mins
Shortbread	Universal pan	3		140-150 <sup>1</sup>	25-35
Shortbread	Universal pan	3		140-150 <sup>1</sup>	20-30
Viennese whirls, 2 levels	Universal pan + Baki ng tray	3+1	<b>®</b>	140-150 <sup>1</sup>	25-35
Viennese whirls, 3 levels	Universal pan + x 2 Baking tray	5+3+1	<b>®</b>	130-140 <sup>1</sup>	35-55
Small Cakes	Universal pan	3		150-160 <sup>1</sup>	25-35
Small Cakes	Universal pan	3		150 <sup>1</sup>	20-30
Small Cakes	Universal pan	3	<b>®</b>	155	25-40
Small Cakes, 2 levels	Universal pan + Baki ng tray	3+1	<b>®</b>	150 <sup>1</sup>	25-35
Small Cakes, 3 levels	Universal pan + x 2 Baking tray	5+3+1	<b>®</b>	140 <sup>1</sup>	30-40
Hot water sponge cake	Springform cake tin, diameter 26 cm.	2		160-170 <sup>2</sup>	25-35
Hot water sponge cake	Springform cake tin, diameter 26 cm.	2	<b>®</b>	160	25-45
Hot water sponge cake, 2 levels	Springform cake tin, diameter 26 cm.	3+1		150-160 <sup>2</sup>	35-50

 $<sup>^{\</sup>rm 1}$  Preheat the appliance for five minutes. Do not use the rapid heating function.  $^{\rm 2}$  Preheat the appliance. Do not use the rapid heating function.

# Grilling **Recommended settings for grilling**

Food	Accessory/cookwar e	Height	Type of heat ing	Temperature in °C/grill setting	Cooking time in mins
Toasting brea d	Pan support	5		31	0.5-1.5

# **Installation instructions**

Observe this information when installing the appliance.





### 20.1 General installation instructions


Follow these instructions before you start in-stalling the appliance.

- The safe operation of this appliance can only be guaranteed if it has been installed to a professional standard in accordance with these installation instructions. The installer shall be liable for damages incurred as a result of incorrect installation.
- Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.
- Before starting up the appliance, remove any packaging material and adhesive film from the cooking compartment and the door.
- Proceed in accordance with the installation sheets for installing accessories.
- Fitted units must be heat-resistant up to 95 °C, and adjacent unit fronts up to 70 °C.
- Do not install the appliance behind a decorative door or the door of a kitchen unit. There is a risk of overheating.
- Cut-out work on the units should be carried out before installing the appliance. Remove any shavings.

Otherwise, the correct operation of electrical components may be adversely affected.

- Position the appliance on a horizontal surface.
- The mains socket for the appliance must either be located in the hatched area ⓐ or outside of the area where the appliance is installed.

Any unsecured units must be secured to the wall using a standard bracket **b**.



- Wear protective gloves so that you do not cut yourself. Parts that are accessible during installation may have sharp edges.
- Dimensions of the figures in mm.

#### ■ WARNING - Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ Only use adapters and power cords ap-proved by the manufacturer.
- ▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.


#### **ATTENTION!**

Carrying the appliance by the door handle could break it. The door handle cannot support the weight of the appliance.

▶ Do not carry or hold the appliance by the door handle.


### 20.2 Appliance dimensions

You will find the dimensions of the appliance here



### 20.3 Installation below a worktop


Observe the installation dimensions and the installation instructions when installing below a worktop.



- To ventilate the appliance, the intermediate floor must have a ventilation cut-out.
- In combination with induction hobs, the gap between the worktop and appliance must not be sealed using additional strips.
- The worktop must be secured to the fitted unit.
- Observe any available installation instructions for the hob.
- Observe different national installation instructions for the hob.

### 20.4 Installation in a tall unit


Observe the installation dimensions and the installation instructions when installing in a tall unit.




- To ventilate the appliance, the intermediate floors must have a ventilation cut-out.
- If the tall unit has another back panel in addition to the element back panels, this must be removed.
- Only fit the appliance up to a height which allows accessories to be easily removed.

### 20.5 Installing two appliances on top of each other

Your appliance can also be installed above or below another appliance. Observe the installation dimensions and the installation instructions when installing appliances on top of each other.




- To ventilate the appliances, the intermediate floor must have a ventilation cut-out.
- To ensure sufficient ventilation of the two appliances, there must be a ventilation opening of at least 200 cm² in the base area. To do this, trim the base panel or fit a ventilation grille.
- Ensure that air exchange is guaranteed in accordance with the diagram.



■ Only fit appliances up to a height that allows accessories to be easily removed.

### 20.6 Corner installation

Observe the installation dimensions and the installation instructions when installing in a corner.




■ To ensure that the appliance door can be opened, you must take the minimum dimensions into consideration when installing in a corner. The dimension a is dependent on the thickness of the unit front and the handle.

#### 20.7 Electrical connection

In order to safely connect the appliance to the electrical system, follow these instructions.

- The appliance corresponds to protection class I and must only be operated with a protective earth connection.
- The fuse protection must correspond to the power rating specified on the appliance's rating plate and to the local regulations.
- The appliance must be disconnected from the power supply whenever installation work is being carried out.
- The appliance must only be connected using the power cable provided.
- The power cable must be plugged in at the rear of the appliance until you hear a clicking sound. A 3 m power cable can be obtained from customer service.



- The power cable must only be replaced with a cable from the original manufacturer. This is available from aftersales service.
- Contact protection must be guaranteed by the installation.

### Electrically connect the appliance with the protective contact plug

Note: The appliance must only be connected to a protective contact socket that has been correctly installed.

▶ Insert the plug into the protective contact socket. When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.

### Electrically connecting an appliance without a protective contact plug

**Note:** Only licensed specialists may connect the appliance. Damage caused by incorrect connection is not covered under the warranty.

An isolating switch must be integrated into the permanent electrical installation according to the installation regulations.

1. Identify the phase and neutral conductors in the socket.

The appliance may be damaged if it is not connected correctly.


2. Connect the hob in accordance with the connection diagram.

See the rating plate for the voltage.


- 3. Connect the wires of the mains power cable according to the colour coding:
  - Green/yellow = Protective conductor ⊕
  - Blue = Neutral conductor
  - Brown = Phase (external conductor)

### 20.8 Installing the appliance

1. Slide the appliance in fully and centre it.




2. Screw the appliance into place.




**Note:** The gap between the worktop and the appliance must not be closed by additional battens. Thermal insulation strips must not be fitted to the side panels of the surround unit.

## 20.9 For handleless kitchens with vertical bar handle strips:


1. Attach a suitable filling piece on both sides in order to cover any sharp edges and to guarantee safe installation.



- 2. Secure the filling piece to the unit.
- 3. Pre-drill the filling piece and the unit to establish a screw connection.



4. Secure the appliance using a suitable screw.



## 20.10 Removing the appliance

- 1. Disconnect the appliance from the power supply.
- 2. Undo the fastening screws.
- 3. Lift the appliance slightly and pull it out completely.



# Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: <u>www.bosch-home.com/welcome</u>



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts. Find out everything about the many ways Bosch can support you: <a href="https://www.bosch-home.com/service">www.bosch-home.com/service</a> Contact data of all countries are listed in the attached service directory.

### **BSH Hausgeräte GmbH**

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com A Bosch Company



**9001944775** (040719)

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom

### **Documents / Resources**



BOSCH HQA.34B.3 Built In Oven [pdf] User Guide HQA.34B.3 Built In Oven, HQA.34B.3, Built In Oven, Oven

### References

- Marian Home Appliances Global Website | Bosch
- Home Appliances Global Website | Bosch
- Bosch Service | Service worldwide
- Welcome to MyBosch
- User Manual

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.