




BOSCH PRA3A6B70, PRB3A6B70 Built In Gas Hob Instruction Manual

[Home](#) » [Bosch](#) » BOSCH PRA3A6B70, PRB3A6B70 Built In Gas Hob Instruction Manual 

BOSCH PRA3A6B70, PRB3A6B70 Built In Gas Hob




Contents


- 1 Component
- 2 Safety
 - 2.1 General information
 - 2.2 Intended use
 - 2.3 Restriction on user group
 - 2.4 Safe use
- 3 Preventing Material Damage
- 4 Environmental Protection And Saving Energy
 - 4.1 Saving energy
 - 4.2 Disposing of packaging
- 5 Familiarising Yourself With Your Appliance
 - 5.1 Control knob
 - 5.2 Burner
 - 5.3 Pan Supports
- 6 Accessories
 - 6.1 Installation accessories
- 7 Basic Operation
 - 7.1 Igniting a gas burner
 - 7.2 Safety system
 - 7.3 Igniting a gas burner manually
 - 7.4 Switching off a burner
 - 7.5 Normal behaviour during operation
- 8 Cookware
 - 8.1 Suitable cookware
 - 8.2 Using cookware
- 9 Recommended settings for cooking
 - 9.1 Tips
- 10 Cleaning and servicing
 - 10.1 Cleaning product
 - 10.2 Cleaning the appliance
 - 10.3 Cleaning the burners
 - 10.4 Cleaning the pan supports
- 11 Troubleshooting
 - 11.1 Malfunctions
- 12 Customer Service
 - 12.1 Product number (E-Nº) and production number (FD)
- 13 Disposal
 - 13.1 Disposing of old appliance
- 14 Customer Support
- 15 Documents / Resources
 - 15.1 References
- 16 Related Posts

Component

- PRA3A6B70



- PRB3A6B70



1	Component	
A	Pan support	–
B	Control knob	–
D	Standard-output burner	1.90 kW
E	High-output burner	2.80 kW
H	Dual-wok multi-crown burner	5.80 / 6.10 kW
1. The images shown in these instructions are for guidance only.		



Safety

Observe the following safety instructions.

General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

Intended use

The appliance can only be used safely if it is correctly installed according to the safety instructions. The installer is responsible for ensuring that the appliance works perfectly at its installation location.

Only use this appliance:

- For cooking purposes.
- Under supervision. Never leave the appliance unattended when cooking for short periods.
- In a private household and in a domestic environment.
- Up to an altitude of max. 2000 m above sea level.

Do not use the appliance:

- On boats or in vehicles.
- as a room heater.
- with an external timer or a remote control.
- Outdoors.

Call the after-sales service if you want to convert your appliance to a different type of gas.

Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

Safe use



WARNING – Risk of explosion! Escaping gas may cause an explosion. WHAT TO DO IF YOU SMELL GAS OR IF THERE ARE FAULTS IN THE GAS INSTALLATION

- Immediately shut off the gas supply or close the gas cylinder valve.
- Immediately extinguish all naked flames and cigarettes.
- Do not operate any light switches or appliance switches.
- Do not pull any plugs out of any sockets.
- Do not use any telephones or mobile phones within the building.
- Open windows and ventilate the room.
- Call the after sales service or the gas supplier.

Escaping gas may cause an explosion. Small amounts of gas can collect over a longer period of time and ignite.

- Close the safety valve for the gas supply when the appliance is out of use for prolonged periods. Escaping gas may cause an explosion.

If the liquefied gas bottle is not upright, liquefied propane/butane can enter the appliance. Intense darting flames may therefore escape from the burners. Components may become damaged and start to leak over time so that gas escapes uncontrollably.

- Always use liquefied gas bottles in an upright position.



WARNING – Risk of poisoning!

Using the gas cooking appliance leads to a build-up of heat, moisture and combustion products in the room where the appliance is installed.

- Ensure that the kitchen is sufficiently ventilated, in particular when operating the gas cooking appliance.
- If the appliance is used intensively and for prolonged periods, ensure that there is additional ventilation so that the combustion products are safely fed to the outside, e.g. if using existing ventilation equipment, set a higher performance level and, at the same time, ensure that the air is replaced with fresh air in the room where the appliance is installed.
- Consult specialist personnel when installing additional ventilation equipment.



WARNING – Risk of fire!

Leaving fat or oil cooking on an unattended hob can be dangerous and may lead to fires.

- Never leave hot oil or fat unattended.
- Never attempt to extinguish a fire using water; instead, switch off the appliance and then cover with a lid or a fire blanket. The appliance becomes very hot.
- Never place flammable objects on the cooktop or in its immediate vicinity.
- Never store any objects on the cooktop. The appliance will become hot.
- Do not keep combustible objects or aerosol cans in drawers directly underneath the hob.
- Never store or use combustible materials (e.g. spray cans or cleaning agents) under the appliance or in its immediate vicinity. Hob covers can cause accidents, for example due to overheating, catching fire or materials shattering.
- Do not use hob covers. When gas burners are in operation without any cookware placed on them, they can build up a lot of heat. The extractor hood above it may become damaged or catch fire.
- Only operate the gas burners with cookware on them. The appliance becomes very hot, fabrics and other objects may ignite.
- Keep fabrics (e.g. garments or curtains) away from the flames.
- Never reach over the flames.
- Do not place combustible objects (e.g. tea towels or newspapers) on, next to or behind the appliance. Escaping gas may ignite.
- If the burner does not ignite after 10 seconds, turn the control knob to the “Off” position and open the door or window in the room. Do not attempt to re-ignite the burner for at least one minute.
- In the event of the burner flames being accidentally extinguished, turn off the burner control. Do not attempt to re-ignite the burner for at least one minute. Food may catch fire.
- The cooking process must be monitored. A short process must be monitored continuously.



WARNING – Risk of burns!

The accessible parts can become hot during operation.

- Small children should be kept away from the appliance. Hob protective grilles may cause accidents.
- Never use hob protective grilles. Empty cookware becomes extremely hot when set on gas burners that are operating.
- Never heat up empty cookware. The appliance becomes hot during operation.
- Allow the appliance to cool down before cleaning



WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk. If the appliance or the power cord is damaged, this is dangerous.
- Never operate a damaged appliance.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.

- If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the gas supply.
- Call customer services. An ingress of moisture can cause an electric shock.
- Do not use steam- or high-pressure cleaners to clean the appliance.
The insulation on cables of electrical appliances may melt if it touches hot parts of the appliance.
- Never bring electrical appliance cables into contact with hot parts of the appliance.



WARNING – Risk of injury!

Faults or damage to the appliance and repairs that have not been carried out correctly are dangerous.

- Never switch on the appliance if there is a fault with it.
- If the appliance is faulty, unplug the mains plug or switch off the fuse in the fuse box. Shut off the gas supply and call the after sales service.
- Always have repairs carried out to the appliance and damaged gas lines replaced by trained, specialist personnel. Cracks or fractures in the glass surface are dangerous.
- All of the burners and each electrical heating element switch off immediately and disconnect the appliance from the power supply.
- Shut off the gas supply.
- Do not touch the surface of the appliance
- Do not use the appliance.
- Call the customer service. Cookware that is not the right size, or that is damaged or incorrectly positioned may cause serious injuries.
- See the notes on cookware. When switching on the burner, sparks are generated in the ignition plugs.
- Never touch the ignition plugs while the burner is being lit. If a control knob is too stiff to turn or it is loose, it must no longer be used.
- Contact our after-sales service immediately to have the control knob repaired or replaced. An appliance with a cracked or broken surface can cause cuts.
- Do not use the appliance if it has a cracked or broken surface.



WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- Keep packaging material away from children.
- Do not let children play with packaging material. Children may breathe in or swallow small parts, causing them to suffocate.
- Keep small parts away from children.
- Do not let children play with small parts.

Preventing Material Damage

ATTENTION!

Heat can cause damage to adjacent appliances or kitchen units. If the appliance is in operation for an extended period, heat and moisture will be generated.

- Open a window or switch on an extractor hood leading to the outside.
A build-up of heat may damage the appliance.
- Do not use two burners or heat sources to heat one single item of cookware.
- Do not use griddle plates, clay pots, etc. for a long time at full power.
A build-up of heat may damage the controls.
- Do not use a large item of cookware on burners that are close to the control knobs.
If a control knob is in the wrong position, this could lead to malfunctions.
- Always turn the control knob to the “Off” position when the appliance is not being used.
Handling the cookware roughly may damage the surface of the appliance.
- Handle the cookware on the hob carefully.
- Do not place any heavy objects on the hob. Moving the cookware may scratch the glass.
- Lift the cookware when moving it.
Damage may occur if hard or pointed objects fall on the hob.
- Do not let hard or pointed objects fall onto the hob.
- Do not bump into any of the edges of the hob.
Salt, sugar or sand that may fall from the vegetables will scratch the glass.
- Do not use the hob as a work surface or storage space.
Melted sugar or food with a high sugar content may damage the glass.
- Remove boiled-over food immediately with a glass scraper.

Environmental Protection And Saving Energy

Saving energy

If you follow these instructions, your appliance will use less energy.

Choose a burner roughly the same size as your pan.

Centre the cookware on the hob.

Tip: Cookware manufacturers often give the upper diameter of the saucepan. It is often larger than the base diameter.

- Unsuitable cookware or incompletely covered cooking zones consume a lot of energy. Cover saucepans with suitable lids.
- Cooking without a lid consumes considerably more energy.
Lift lids as infrequently as possible.
- When you lift the lid, a lot of energy escapes. Use a glass lid.
- You can see into the pan through a glass lid without having to lift it.

Use cookware that is suitable for the quantity of food.

- Large items of cookware containing little food need more energy to heat up.
Cook with only a little water.
- The more water that is contained in the cookware, the more energy is required to heat it up. Turn down to a lower power level early on.
- If you use an ongoing power level that is too high, you will waste energy.
Product Information according (EU) 66/2014 can be found on the attached appliance pass and online on the

product page for your appliance.

Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.


- Sort the individual components by type and dispose of them separately





Familiarising Yourself With Your Appliance

Control knob

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.


You can use the control knobs to set the flame height to different power levels.



Display	Meaning
	Burner assigned to the control knob.
	Burner off.
 9	Highest power setting and electric ignition of the burner.
1 	Lowest power setting.

Dual-wok multi-crown burner

With the dual-wok multi-crown burner, you can regulate the inner and outer flames independently of each other.




Power level	Meaning
⑨ 9	Inner and outer flame on full power.
4	Outer flame on minimum, inner flame on full power.
3	Inner flame on full power.
1 ①	Inner flame on minimum power.

Burner


You can find an overview of the parts of the burner [here](#).

1	Burner cover
2	Burner cup
3	Burner cup base
4	Thermocouple for the flame monitoring
5	Ignition plug



Pan Supports

- Insert the pan supports correctly.



Place the cookware correctly on the pan supports.

Never place the cookware directly on the burner.

Always carefully remove the pan supports. When moving a pan support, the pan supports next to it may also move.

Tip: You can remove the metal residue that remains when some items of cookware are moved on the pan support by cleaning it properly.

→ “Cleaning the pan supports”,




Accessories

You can buy accessories from the after-sales service, from specialist retailers or online. Only use original accessories, as these have been specifically designed for your appliance.

Accessories vary from one appliance to another. When purchasing accessories, always quote the exact product number (E no.) of your appliance.

You can find out which accessories are available for your appliance in our catalogue, in the online shop or from our after-sales service.

www.bosch-home.com

Accessories	Description	Use
Additional wok grid		<ul style="list-style-type: none"> • Only use on the multi-crown burner. • Always use for cookware with a rounded base. • Recommended in order to extend the service life of the appliance.
Additional espresso maker grid		<ul style="list-style-type: none"> • Only use on the burner with the lowest power setting. • Use with cookware with a diameter smaller than 12.
Simmer plate		<ul style="list-style-type: none"> • For cooking on a low heat. • Use the economy burner or the standard output burner. If there are several standard-output burners, it is preferable to use the rear or front-right burner. • Place it on the pan support with the bumps facing up – never place it directly on the burner.

Installation accessories

- To combine appliances of the same brand, use the installation accessory.

Basic Operation

Igniting a gas burner

The hob has automatic ignition of the burners.



WARNING – Risk of fire!
Escaping gas may ignite.

- If the burner does not ignite after 10 seconds, turn the control knob to the “Off” position and open the door or window in the room. Do not attempt to re-ignite the burner for at least one minute.
- In the event of the burner flames being accidentally extinguished, turn off the burner control. Do not attempt to re-ignite the burner for at least one minute.

ATTENTION!

If you turn the control knob directly between position and 1, malfunctions may occur.

- For this reason, never turn directly from position to position 1 or vice versa.
1. Press the control knob for the selected burner and turn it anti-clockwise to the highest level.
Keep the control knob pressed in.
a For all of the burners, sparks are generated and the flame ignites.
 2. Wait a few seconds and release the control knob.
→ “Safety system”,
 3. Turn the control knob to the required position.
 4. If the burner does not ignite, turn the control knob to the off position and repeat the steps described above. This time, hold the control knob down for longer (up to 10 seconds).

Note:

Take the following information into account to ensure that the appliance works correctly:

- The burner parts and the pan supports must be inserted correctly.
- Do not swap the burner caps around.
- It is important to keep the appliance clean. Clean the ignition plugs regularly with a small, non-metallic brush.
Take care to prevent the ignition plugs from suffering any heavy knocks.
- The burner holes and grooves must be clean to ensure a correct flame. → “Cleaning the burners”,

Safety system

The safety system (thermocouple) interrupts the flow of gas if the burners accidentally go out. To ignite the burner, you must activate the system that enables the gas flow.

1. Ignite the burner without releasing the control knob.
a The flame ignites.
2. Press and hold the control knob for a further four seconds.

Igniting a gas burner manually

In the event of a power cut, you can light the burners manually.

1. Press the control knob for the selected burner and turn it anti-clockwise to the highest level.
2. Hold a lighter or a flame (lighter, match, etc.) against the burner.

Switching off a burner

- Turn the control knob clockwise to .

Normal behaviour during operation

This behaviour is normal for the appliance:

- Slight hissing noise from the ignited burner.
- Release of odours when using the appliance for the first time. These odours disappear after a short time.

Cookware

This information has been provided to help you save energy and avoid damaging your cookware.

Suitable cookware

Only use cookware with a suitable diameter. The cookware must not protrude over the edge of the cooktop. Never use small cookware on large burners. The flames must not touch the sides of the cookware.

Burner	Minimum dia- meter of the cookware base	Maximum dia- meter of the cookware base
Multi-crown burner	22 cm	30 cm
High-output burner	20 cm	26 cm
Standard-output burner	12 cm	22 cm

Only use cookware with a rounded base on the multicrown burner.

- The hob must have a multi-crown burner and additional wok grid.
- The additional wok grid must be correctly inserted. → “Accessories”, Page 7

Using cookware

The selection and positioning of the cookware affects the safety and energy efficiency of your appliance. → “Saving energy”, Page 6



WARNING – Risk of fire!

Flammable objects may ignite.

- Maintain a distance of at least 50 mm between the cookware and flammable objects.

Do not use deformed cookware. Only use cook- ware with a thick, flat base.	Deformed cookware is not stable on the hob and may tip over.
Place the cookware right in the centre of the burner.	The cookware may tip over if it is not placed in the centre of the burner.
Place the cookware correctly on the pan supports.	The cookware may tip over if you place it directly on the burner.

Recommended settings for cooking

You can use the control knobs on the appliance to set the flame height incrementally to different power levels from 1 to 9.

The cooking times and power levels may vary depending on the type of food, its weight and quality, on the type of gas used, and on the material from which the cookware is made.

Tips

- Cooking tips
 - When cooking soups, creams, lentils or chickpeas, add all of the ingredients to the cookware at the same time.
 - For pan-fried dishes, heat the oil up first. As soon as you have started frying, keep the temperature constant and adjust the power level as required. When preparing several portions, wait until the relevant temperature has been reached again.
Turn the food regularly.
- To reduce the cooking time:
 - Use a pressure cooker to cook creams and pulses. If you are using a pressure cooker, follow the manufacturer's instructions.
 - The water must be boiling before you add pasta, rice or potatoes. Then adjust the power level in order to continue boiling.
 - Always use a lid when cooking rice and potatoes.

Power level	Preparing meals
9	<ul style="list-style-type: none"> • Bringing water to the boil • Baking in a bain-marie: Sponge, blanc-mange, bread pudding. • Frying at a high temperature: Asian dishes.
7-9	<ul style="list-style-type: none"> • Starting the cooking process: Pasta, soups, creams, paella, pulses, rice pudding. • Deep-fat frying in oil: Tempura vegetables, croquettes, chips, potato omelettes, escalope, frozen food, baked items • Frying with a little oil: French omelette, steak, well-done sirloin steak, stir-fry. • Frying, searing: Vegetables, meat.
4-6	<ul style="list-style-type: none"> • Continuing the cooking process: Pasta, soups, creams, paella, pulses, rice pudding. • Deep frying with a little oil: Hamburgers, sausages, grilled salmon, rissoles. • Stew, pot roast: Ragout, goulash, ratatouille. • Cooking at a medium temperature: Cheese sauce, béchamel, carbonara, Neapolitan sauce, blancmange, crepes. • Defrosting: Frozen food.
1-3	<ul style="list-style-type: none"> • Finishing cooking: Paella rice, pulses, rice pudding • Steaming: Fish, vegetables. • Heating and keeping warm: Ready-to-eat meals.
1	Melting: Butter, chocolate, butter, gelatine, honey, caramel.

Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

Cleaning product

You can obtain suitable cleaning products from aftersales service or the online shop.

ATTENTION!

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use steel wool.
- Do not use a knife or sharp objects to remove dried-on food remnants from the hob.
- Do not use a knife or sharp objects to clean the connection between the glass and the burner panels, the metal frames or the glass/aluminium plates for cleaning.

- Do not use steam-cleaning appliances.

Cleaning the appliance

ATTENTION

When the control knob is removed while cleaning the appliance, humidity may get in and damage the interior of the appliance.

- When cleaning the appliance, do not remove the controls.
1. Allow the appliance to cool down.
 2. Clean using a sponge and soapy water.
 3. Dry with a soft cloth.
- Tip:** Remove spilled liquids immediately. This prevents food remains from sticking, and the time and effort required for subsequent cleaning is reduced.

Cleaning the burners

After each use, clean the surface of the burner parts.
This prevents food remains from burning on.

ATTENTION!

The burner parts can be damaged if you clean them in a dishwasher.

- Do not clean the burner parts in a dishwasher. Note: Read the information on the cleaning agents.
1. Allow the appliance to cool down.
 2. Clean using a non-metallic brush and soapy water.
 3. Completely dry the appliance. If there are water droplets or damp areas at the start of cooking, this may damage the enamel.
 4. Insert the burner parts. Ensure that the burner caps are correctly positioned on the flame spreader.

Cleaning the pan supports

Note: Read the information on the cleaning agents.

1. Allow the appliance to cool down.
2. Carefully remove the pan supports.
3. Clean using a non-metallic brush and soapy water. Carefully clean the area around the rubber pads. If the rubber pads come loose, the pan support may scratch the hob.
4. Alternatively, you can clean the pan supports in the dishwasher. Use the cleaning agents recommended by the dishwasher manufacturer. In the case of heavy soiling, we recommend precleaning the pan supports.
5. Completely dry the appliance. If there are water droplets or damp areas at the start of cooking, this may damage the enamel.
6. Insert the pan supports correctly.

Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



WARNING – Risk of injury!
Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- If the appliance is defective, call Customer Service.



WARNING – Risk of electric shock!
Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer’s Customer Service or a similarly qualified person in order to prevent any risk.

Malfunctions

Fault	Cause and troubleshooting
The general electrical operation is impaired.	<p>The circuit breaker is faulty.</p> <ul style="list-style-type: none">• Check the circuit breaker in the fuse box. <p>The circuit breaker or one of the residual-current circuit breakers has been triggered.</p> <ul style="list-style-type: none">• In the fuse box, check whether the circuit breaker or one of the residual-current circuit breakers has been triggered. <p>The mains plug of the power cord is not plugged in.</p> <ul style="list-style-type: none">• Connect the appliance to the power supply. <p>There has been a power cut.</p> <ul style="list-style-type: none">• Check whether the lighting in your kitchen or other appliances are working.

<p>Automatic ignition is not working.</p>	<p>Food remnants or dirt are located between the ignition plug and the burner.</p> <ul style="list-style-type: none"> • Clean the space between the ignition plugs and burners. <p>Burner parts are wet.</p> <ul style="list-style-type: none"> • Carefully dry the burner parts. <p>The burner parts are positioned incorrectly.</p> <ul style="list-style-type: none"> • Correctly position the burner parts. <p>The appliance is not earthed or has not been connected correctly, or the earth cable is damaged.</p> <ul style="list-style-type: none"> • Contact an electrician
<p>The burner flame is not uniform.</p>	<p>The burner parts are positioned incorrectly.</p> <ul style="list-style-type: none"> • Correctly position the burner parts. <p>Openings on the burner are soiled.</p> <ul style="list-style-type: none"> • Clean and dry the openings on the burner.
<p>The gas does not appear to be flowing normally or there is no gas being produced at all.</p>	<p>The gas supply has been shut off by the intermediate valves.</p> <ul style="list-style-type: none"> • Open the intermediate valves. <p>The gas cylinder is empty.</p> <ul style="list-style-type: none"> • Replace the gas cylinder

<p>There is a smell of gas in the kitchen.</p>	<p>The control knob is open.</p> <ul style="list-style-type: none"> • Close the control knob. <p>The gas cylinder has not been connected correctly.</p> <ul style="list-style-type: none"> • Ensure that the gas cylinder has been connected correctly. <p>The gas pipe to the appliance is leaking.</p> <ol style="list-style-type: none"> 1. Close the main gas tap. 2. Ventilate the room. 3. Immediately call an authorised installer, who can inspect the gas system and issue an installation certificate. 4. Do not use the appliance until you are sure that gas is not leaking from the installation or the appliance.
<p>The burner switches off as soon as you release the control knob.</p>	<p>Control knob not pressed down long enough.</p> <ol style="list-style-type: none"> 1. Keep the control knob pressed down for a few seconds after ignition. 2. Press the control knob down firmly. <p>Openings on the burner are soiled.</p> <ul style="list-style-type: none"> • Clean and dry the openings on the burner.

Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nº) and the production number (FD) of your appliance.

Product number (E-Nº) and production number (FD)

You can find the product number (E-Nº) and the production number (FD) on the appliance's rating plate. The rating plate can be found:

- on the appliance certificate.
- on the lower section of the hob.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

Disposal

Disposing of old appliance

Valuable raw materials can be reused by recycling.

1. Unplug the appliance from the mains.
2. Cut through the power cord.
3. Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.



■ This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment – WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.



Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: www.bosch-home.com/welcome



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts. Find out everything about the many ways Bosch can support you: www.bosch-home.com/service
Contact data of all countries are listed in the attached service directory.

Futher information and explanations are available online



Customer Support

BSH Hausgeräte GmbH Carl-Wery-Straße 34 81739 München, GERMANY
www.bosch-home.com



Documents / Resources

A small thumbnail image showing the front cover of a Bosch instruction manual. The cover is white with a grey geometric pattern at the bottom and the Bosch logo in the top left corner.	<p>BOSCH PRA3A6B70, PRB3A6B70 Built In Gas Hob [pdf] Instruction Manual PRA3A6B70 PRB3A6B70 Built In Gas Hob, PRA3A6B70, PRB3A6B70, PRA3A6B70 Built In Gas Hob, PRB3A6B70 Built In Gas Hob, Built In Gas Hob, Built In Hob, Gas Hob, Hob</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [Home Appliances Global Website | Bosch](#)
- [Home Appliances Global Website | Bosch](#)
- [BOSCH Service | Service worldwide](#)
- [Welcome to MyBosch](#)

