

BriteLite HC-1202F PS1000 Speaker User Manual

Home » BriteLite » BriteLite HC-1202F PS1000 Speaker User Manual

USER MANUAL



BriteLite PS1000 Speaker Model: HC-1202F

Contents

- 1 INSTRUCTION MANUAL
- 2 Accessories
- **3 CONTROL BUTTONS DESCRIPTION**

÷

- **4 Description of Remote Control**
- **5 Operating Instructions:**
- 6 Specifications
- **7 Warning Statement**
- **8 Related Posts**

INSTRUCTION MANUAL

Read the manual prior to first using the product and keep it for further reference.

For best sound performances, keep the unit away from water, moisture, direct sunlight, extreme temperatures. Place the unit in such a way that it can't fall down.

Never disassemble the unit. Otherwise, it may invalidate the warranty.


- 1. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus to avoid any accident.
- 2. To prevent fire or electric shock, please check the compliance of the voltage of power grid with the specified supply voltage of this unit.
- 3. The mains plug is used as the disconnect device, the disconnect device shall remain readily operable.

Accessories

- 1. Unit
- 2. User Manual
- 3. Remote Control
- 4. AUX input cable with 3.5mm jack
- 5. Power line

CONTROL BUTTONS DESCRIPTION:

TOP PANEL CONTROL BUTTONS:



- 1. Guitar input.
- 2. Microphone input
- 3. USB input
- 4. SD CARD input
- Microphone volume control.Works after connecting the MIC IN jack.
- 6. GT VOL

Adjust the guitar volume. Works after connecting the GUITAR IN jack (make sure MIC VOL is not set to 0).

7. ECHO

It can adjust the ECHO from the range EC00-EC30, Only can be adjusted after you connect the Guitar & MIC .

- 8. Bass +/-
- 9. Treble +/-
- 10. Volume

Main volume control.

11. EQ/BASS

Press Shortly this button, Equalizer to browse through different music styles (classical/pop/rock/jazz/nor) Press above 2 Seconds this button, Switch to the superbass function on and off .

12. Previous

In USB/SD/Bluetooth mode: Short press to previous song.

In FM mode,Long press this button to auto scan until previous station was found .Short press this button to select the previous frequency. Such as,87.8, 87.7.....

In AUX IN mode: no function

13. Play/pause

In USB/SD/BLUETOOTH mode, press this button to Play or Pause.

In FM mode, Long press this button to search the stations automatically until all the stations have been saved. After all the stataion have been saved, short press this button, you can choose station one by one.

In AUX IN mode, press this button to play or pause .

14. NEXT

In USB/SD/Bluetooth mode: Short press to next song.

In FM mode,Long press this button to auto scan until next station was found . Short press this button to select the next frequency,such as 90.1,90.2.....

In AUX IN mode: no function

15. MODE

Short press this button to skip to mode one by one, BLUETOOTH /AUX-IN/FM/USB/SD.

Long Press this button to open/close the voice prompt.


16. Standby


The first time you turn on the unit, it is in standby mode, 3 seconds later, Press this button, Then this unit will change into working mode.


If you want the unit stop working , You can press this button in any time , the unit will change into standby mode .

17. Display screen

BACK PANEL CONTROL BUTTONS:







18. FM ANT

For adjusting the radio-station-searching effect .

19. LED-OUT (Connecting with LED-IN)

20. AUX IN

For Connecting the external device under AUX- IN mode .

21. LED-OUT (Connecting with LED-IN)

Connect with LED-IN jack

22. L-OUT for Speakers

23. R-OUT for Speakers

24.POWER ON/OFF

25. AC IN

Use for connecting the cable and power supply . (AC 100V-240V~ 50/60Hz)


26. L-IN (Connecting with L-OUT)

27. LED-IN

28. LED-IN

29. R-IN(Connecting with R-OUT)

Description of Remote Control



- 1. **MUTE:** Press this button to turn on/ off the sound.
- 2. **Mic** priority Give priority to mic voice against music . only can work when the Mic jack connected .

3. Previous

In USB/SD/Bluetooth mode: Short press to previous song.

In FM mode,Long press this button to auto scan until previous station was found .Short press this button to select the previous frequency. Such as,87.8, 87.7.....

In AUX IN mode: no function

Play/pause

In USB/SD/BLUETOOTH mode, press this button to Play or Pause.

In FM mode , Long press this button to search the stations automatically until all the stations have been saved . After all the station have been saved , short press this button , you can choose station one by one.

In AUX IN mode, press this button to play or pause .

NEXT

In USB/SD/Bluetooth mode: Short press to next song.

In FM mode, Long press this button to auto scan until next station was found . Short press this button to select the next frequency, such as 90.1,90.2......

In AUX IN mode: no function

VoL-/+: Main volume control.

4. MVOL-/+

Microphone volume control.

5. **REC**

Short press to start the recording only under the Aux in/FM mode ,press again to stop the recording and back the previous state. Long press to delete the files when you play back the recorded files.

- 6. Treble+/-
- 7. Standby ON/OFF
- 8. Repeat

Under USB and SD CARD mode, press to make the single repeat and repeat all.

9. Mode

It could select the mode one by one, Bluetooth/USB /SD CARD/AUX IN/FM.

10. Light

LED Light On/Off.

11. REC PLAY

Short press to play back the recorded files.

12. Voice

Press this button to turn on/off Voice prompt.

13. EQ

You can chose different music styles (Pop/Rock/Classical/Vocal/Jazz/Normal)

Press above 2 Seconds this button, Switch to the superbass function on and off.

- 14. Bass +/-
- 15. 0-9 keys

Operating Instructions:

Bluetooth Pairing Mode:

Press MODE button on the unit or the remote control until BLUETOOTH is selected.

- 1. Put the cell phone within 3 meters;
- 2. Activate the Bluetooth features on your cell phone so that the cell phone starts to search for the Bluetooth device. Please refer to the users' manual for details
- 3. Select "PS1000 Stack" from the device found by the cell phone;
- 4. Press RETURN key on the cell phone to exit from the cell phone menu and play music with the unit when there is no barrier between two cell phones within 10 meters. At this time, you can play music with the unit.
- 5. Shortly press PLAY/PAUSE button to play or pause music. Short press " " or " " key to select the previous or next track.

FM (radio) Mode:

Press MODE button shortly after start up to switch over to "FM" status.

Auto radio station search and storage:Long Press the PLAY/PAUSE button and the unit will automatically search for radio stations in the radio frequency range between 87.5 and 108.0 MHz. After finished the searching , auto searching will stop and useful stations will save automatically .

AUX IN MODE:

Press MODE button on the unit or the remote control until AUX is selected. Play the music of the device connected to the AUX IN input on the rear panel.

USB Mode:

- 1. After start up, insert the USB device. The unit will automatically read and play the music in the USB device.
- 2. Press " | " key shortly to pause or play the track.
- 3. Shortly press " key to skip to the previous track.
- **4.** Shortly press "" key to skip to the next track.

SD Mode:

- 1. After start up, insert the SD card. The unit will automatically read and play the music in the SD card.
- 2. Press " | " key shortly to pause or play the music.
- 3. Shortly press " Key to skip to the previous track.
- 4. Shortly press " key to skip to the next track.

Specifications

Remarks: If the problem persists, please contact your dealer.



Electric products must not be put into household waste. Please bring them to a recycling centre. Ask your local authorities or your dealer about the way to proceed.

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

BriteLite-HC-1202F-PS1000-Speaker-Manual-Optimized

Optimized PDF

BriteLite-HC-1202F-PS1000-Speaker-Manual-Original

Download

Questions about your Manual? Post in the comments!

Manuals+,