



Cambrionix 2023 Command Line Interface User Manual

[Home](#) » [Cambrionix](#) » Cambrionix 2023 Command Line Interface User Manual 

Cambrionix CHARGE • CONNECT • MANAGE Command Line Interface User Manual CLI

Contents

- [1 Introduction](#)
- [2 Commands](#)
- [3 Errors](#)
- [4 Charging profiles](#)
- [5 Port modes](#)
- [6 LED control](#)
- [7 Internal hub Settings](#)
- [8 Supported Products](#)
- [9 ASCII Table](#)
- [10 Terminology](#)
- [11 Licensing](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)

Introduction

This manual describes how to control products via their control interface. The Command Line Interface (CLI) enables the hub or hubs to be integrated into a larger system that is controlled by a host computer. A Serial terminal emulator must be installed to be able to use the CLI, and the emulator requires access to the COM port, so no other software, such as LiveViewer, can access the port at the same time. An example emulator that can be used is puTTY which can be downloaded from the following link.

www.putty.org

Commands that are issued via the COM port are referred to as commands. Some settings modified by commands

in this document are volatile – that is, the settings are lost when the hub is rebooted or powered off, please see individual commands for detail.

Throughout this manual optional parameters are shown in square brackets: []. ASCII control characters are shown within <> brackets.

This document and commands are subject to change. Data should be parsed such to be tolerant of both upper and lower case, white space, additional new line characters ...etc.

You can download the latest version of this manual from our website at the following link.

www.cambrionix.com/cli

2.1. Device location

The system appears as a virtual serial port (also called a VCP). On Microsoft Windows™, the system will appear as a numbered communication (COM) port. The COM port number can be found by accessing device manager. On macOS®, a device file is created in the /dev directory. This is of the form/dev/tty.usbserial S where S is an alpha-numeric serial string unique to each device in the Universal Series.

2.2. USB Drivers

Communication to our products is enabled through a virtual COM port, this communication requires USB drivers. On Windows 7 or later, a driver may automatically be installed (if Windows is configured to download drivers from the internet automatically). If this is not the case, the driver can be downloaded from www.ftdichip.com. The VCP drivers are required. For Linux® or Mac® computers, the default OS drivers should be used.

2.3. Communication Settings

The default communications settings are as below.

Communication setting	Value
Number of bits per second (baud)	115200
Number of data bits	8
Parity	None
Number of stop bits	1
Flow control	None


ANSI terminal emulation should be selected. Command sent must be terminated with

<CR><LF>

Lines received by the hub are terminated with

<CR><LF>

The hub will accept back-to-back commands, however, the host computer should wait for a response before issuing a new command.

	CAUTION
	The hub may become unresponsive For serial communications you must wait for a response from any commands before issuing a new command. Failure to do so can cause the hub to become unresponsive and require a full power reset.

2.4. Boot text and command prompt

At boot, the hub will issue a string of ANSI escape sequences to reset an attached terminal emulator.

The title block follows this, then a command prompt.
The command prompt received is as below

```
>>
```

Except in boot mode where it is as below

```
boot>>
```

To reach a new boot prompt, send <ETX>. This cancels any partial command string.

2.5. Products and their Firmware

Below is a list of products, their part numbers and the Firmware type it uses.

Firmware	Part Number	Product Name
Universal	PP15S	PowerPad15S
Universal	PP15C	PowerPad15C
Universal	PP8S	PowerPad8S
Universal	SS15	SuperSync15
Universal	TS3-16	ThunderSync3-16
TS3-C10	TS3-C10	ThunderSync3-C10
Universal	U16S Spade	U16S Spade
Universal	U8S	U8S
PowerDelivery	PDS-C4	PDSync-C4
Universal	ModIT-Max	ModIT-Max
MotorControl	Motor control board	ModIT-Max

2.6. Command structure

Each command follows the below format.

```
Command mandatory-parameters [optional-parameters]<CR><LF>
```

The command will need to be entered first, if no parameters exist for the command then this will need to be followed immediately by <CR> and <LF> to send the command.

Not every command has mandatory parameters but if they are applicable then these will need to be entered for the command to work, once the command and mandatory parameters are entered then <CR> and <LF> will be required to signify the end of a command.

Optional parameters are shown inside square brackets e.g. [port]. These do not need to be entered for the command to be sent, but if they are included they will need to be followed by <CR> and <LF> to signify the end of a command.

2.7. Response structure

Each command will receive it's specific response followed by <CR><LF>, a command prompt and then a space.
The response is terminated as shown below.

```
>>
```

Some command responses are "live" meaning there will be a continuous response from the product until the

command is cancelled by sending an <ETX> command. In these instances you will not receive the standard response as above until <ETX> command has been sent. If you disconnect the product it will not stop the data stream and reconnecting will result in the continuation of the data stream.

Commands

Below is a list of commands that are supported by all products

Command	Description
bd	Product description
cef	Clear error flags
cls	Clear terminal screen
crf	Clear rebooted flag
health	Show voltages, temperature, errors and boot flag
host	Show if USB host is present, and set mode change
id	Show id string
l	Live view (Periodically sends responses on the current state of the product)
ledb	Sets the LED pattern using a bit format
leds	Sets the LED pattern using a string format
limits	Show voltage and temperature limits
loge	Log state and events
mode	Sets the mode for one or more ports
reboot	Reboots the product
remote	Enter or exit mode where LEDs are controlled manually or automatically
sef	Set error flags
state	Show state for one or more ports
system	Show system hardware and firmware information

Below is a table of commands specific to the Universal Firmware

Command	Description
beep	Makes the product beep
clcd	Clear LCD
en_profile	Enables or disables profile
get_profiles	Get list of profiles associated with a port
keys	Read key click event flags

lcd	Write a string to the LCD display
list_profiles	List all profiles on system
logc	Log current
sec	Set or get security mode
serial_speed	Change serial interface speed
set_delays	Change internal delays
set_profiles	Set profiles associated with a port

Below is a list of commands specific to the PD Sync and TS3-C10 Firmware

Command	Description
detail	show state for one or more ports
logp	Log current
power	set product max power or get product power for one or more ports
qcmode	set quick charge mode for one or more ports.

Below is a list of commands specific to the Motor Control Firmware

Command	Description
gate	Open, close or stop gates
keyswitch	Show state of keyswitch
proxy	Distinguish commands meant for Motorcontrol board
stall	Set stall current for motors,
rgb	Set LEDs to RGB override enable on ports
rgb_led	Set LEDs on ports to RGBA value in hex

3.1. Notes

1. Some products don't support all the commands. See the [Supported Products](#) section for
2. All commands meant for the Motor control board must be prefixed with the [proxy](#)

3.2. bd (Product Description)

The bd command provides a description of the architecture of the product. This includes all upstream and downstream ports. This is to provide external software the architecture of the USB connection tree.

Syntax: (see 'Command structure')

```
bd
```

Response: (see Response structure)

Name value pairs indicating the presence of features of the product. This is followed by a description of each USB hub in turn, listing what is attached to each port of that hub. Each port of a hub will be attached to a charging port, an expansion port, a downstream hub, a USB device or is unused.

The features are indicated by these entries:

Parameter	Value
Ports	The number of USB ports
Sync	A '1' indicates the product provides sync capability
Temp	A '1' indicates the product can measure temperature
EXTPSU	A '1' indicates the product is supplied with an external PSU that is greater than 5V

The attachment section can have the following entries, all indices are 1 based:

Parameter	Value	Description
Nodes	n	A number indicating the number of nodes this description set includes. A node will be either a USB hub or a USB controller.
Node i Type	type	i is an index indicating which node this is. type is an entry from the Node Table below.
Node i Ports	n	A number indicating how many ports this node has.

Hub <i> Port <p>	Hub <j>	The USB hub <i> has a down-stream hub <j> connected to its port <p>
	Control Port	The USB hub <i> has the USB serial port attached to port <p>
	Expansion Port <e>	The USB hub <i> has an expansion port attached to port <p>
	Port <c>	The USB hub <i> has the charging port <c> attached to port <p>
	Optional Hub <j>	The USB hub <i> may have a down-stream hub <j> connected to its port <p> but this is optional so may not be fitted
	Turbo Hub <j>	The USB hub <i> has a USB hub capable of operating in Turbo mode attached to port <p>
	USB3 Hub <j>	The USB hub <i> has a USB 3.x hub attached to port <p>
	Unused Port	The USB hub <i> has nothing attached to its port <p>

Node type can be one of the following:

Node Type	Description
Hub j	A USB 2.0 hub index j
Optional Hub j	A USB hub that may be fitted, index j
Root r	A USB controller with a root hub which also means the USB bus number will change
Turbo Hub j	A USB hub capable of operating in Turbo mode with index j
USB3 Hub j	A USB 3.x hub with index j

Example

```
>> bd
Ports: 15
Sync: 1
Temp: 1
EXTPSU: 1
Console: none
Nodes : 5
Node 1 Type : USB3 Hub 1
Node 1 Ports : 5
Hub 1 Port 1 : Turbo Hub 2
Hub 1 Port 2 : Turbo Hub 5
Hub 1 Port 3 : Turbo Hub 3
Hub 1 Port 4 : Turbo Hub 4
Hub 1 Port 5 : Control Port
Node 2 Type : Turbo Hub 2
Node 2 Ports : 4
Hub 2 Port 1 : Port 1
Hub 2 Port 2 : Port 2
Hub 2 Port 3 : Port 9
Hub 2 Port 4 : Port 8
Node 3 Type : Turbo Hub 3
Node 3 Ports : 4
Hub 3 Port 1 : Port 3
Hub 3 Port 2 : Port 4
Hub 3 Port 3 : Port 11
Hub 3 Port 4 : Port 10
Node 4 Type : Turbo Hub 4
Node 4 Ports : 4
Hub 4 Port 1 : Port 5
Hub 4 Port 2 : Unused Port
Hub 4 Port 3 : Port 13
Hub 4 Port 4 : Port 12
Node 5 Type : Turbo Hub 5
Node 5 Ports : 4
Hub 5 Port 1 : Port 6
Hub 5 Port 2 : Port 7
Hub 5 Port 3 : Port 15
Hub 5 Port 4 : Port 14
```

3.3 cef (Clear error flags)

The CLI has error flags which will signify if a specific error has occurred. The flags will only be cleared by using the cef command or through a product reset or power on / off cycle.

“UV”	Under-voltage event occurred
“OV”	Over-voltage event occurred
“OT”	Over-temperature (over-heat) event occurred

If the error condition persists, the hub will set the flag again after it is cleared.

Syntax: (see Command structure)

```
cef
```

Response: (see Response structure)

```
>>
```

3.4. cls (Clear screen)

Sends ANSI escape sequences to clear and reset the terminal screen.

Syntax: (see Command structure)

```
cls
```

Response: (see Response structure)

```
>>
```

3.5. crf (Clear rebooted flag)

The rebooted flag is to inform you if the hub has rebooted in between commands and can be cleared using the crf command.

If the rebooted flag is found to be set, then previous commands changing the volatile settings will have been lost.

Syntax: (see Command structure)

```
crf
```

Response: (see Response structure)

```
>>
```

3.6. health (System health)

The health command displays the supply voltages, PCB temperature, error flags and the rebooted flag.

Syntax: (see Command structure)

```
health
```

Response: (see Response structure)

parameter: value pairs, one pair per row.

Parameter	Description	Value	
Voltage Now	Present supply voltage		
Voltage Min	Lowest supply voltage seen		
Voltage Max	Highest supply voltage seen		
Voltage Flags	List of voltage supply rail error flags , separated by spaces		No flags: voltage is acceptable
		UV	Under-voltage event occurred
		OV	Over-voltage event occurred
Temperature Now	PCB temperature, °C	>100 C	Temperature is above 100°C
		<0.0 C	Temperature is below 0°C
		tt.t C	Temperature, e.g. 32.2°C
Temperature Min	Lowest PCB temperature seen, °C	<0.0 C	Temperature is below 0°C
Temperature Max	Highest PCB temperature seen, °C	>100 C	Temperature is above 100°C
Temperature Flags	Temperature error flags		No flags: temperature is acceptable
		OT	Over-temperature (over-heat) event occurred
Rebooted Flag	Used to detect if system has booted	R	System has booted or rebooted
			Flag cleared using crf command

Example

```
>> health
System up for:      69928 seconds
5V Now:    5.23
5V Min:    5.22
5V Max:    5.23
5V Flags:
12V Now: 12.10
12V Min: 12.06
12V Max: 12.16
12V Flags:
Temperature Now (C): 37.4
Temperature Max (C): 37.6
Temperature Flags:
PWM %:  0.0
Rebooted flag: R
```

*output from a SS15

3.7. host (Host detection)

The hub monitors the host USB socket for an attached host computer. In auto mode if the product detects a host it will change to sync mode.

The host command can be used to determine if a host computer is attached. It can also be used to prevent the hub from automatically changing modes.

Syntax: (see Command structure)

```
host [mode]
```

Table for mode in the Universal Firmware

Mode	Description
auto	The mode of all populated ports changes automatically when a host is connected or disconnected
manual	Only commands can be used to change modes. The presence or absence of a host will not change the mode

Table for mode in the PDSync and TS3-C10 Firmware

Mode	Description
auto	The ports will enable sync connectivity as the host comes and goes. Charging is always enabled unless the port is turned off.
off	If the host is no longer detected, all charging ports will be turned off.

Response if parameter is supplied: (see Response structure)

>>

Response if no parameter is supplied:

Present: (value) Mode change: (value)

Parameter	Description	Value
Present	Whether a host is present or not	Yes / No
Mode change	The mode the hub is in	Auto /Manual

Table for present in all firmware

Present	Description
yes	host is detected
no	host is not detected

Notes

1. The presence of the host computer is still reported if the mode is set to manual.
2. On charge only products the host command is present, but as the products are charge only and cannot obtain device information the command is redundant.
3. Only the U8S can report the host to be not present as it is the only product that has a separate control and host connection.
4. The default host mode is auto for all products.

Examples

To set host mode to manual:

```
host manual >>
```

To determine if a host is present, and the get the mode:

```
host Present: no Mode change: auto >>
```

And with a host attached:

```
host Present: yes Mode change: auto >>
```

3.8. id (Product identity)

The id command is used to identify the product and also provides some basic information about the firmware running on the product.

Syntax: (see Command structure)

```
id
```

Response: (see Response structure)

A single line of text containing multiple name:value pairs separated by commas, that can be used to identify the product.

```
mfr,mode,hw,hwid,fw,bl,sn.group,fc
```

Name	Value
<i>mfr</i>	Manufacturer string (eg, cambrionix)
<i>mode</i>	A string to describe which operating mode the firmware is in (eg, main)
<i>hw</i>	The part number of the hardware Part numbers)
<i>hwid</i>	A hexadecimal value used internally to identify the product (eg, 0x13)
<i>fw</i>	A pseudo number representing the firmware revision (eg, 1.68)
<i>bl</i>	A pseudo number representing the bootloader revision (eg, 0.15)
<i>sn</i>	A serial number. If not used will show all zeros (eg, 000000)
<i>group</i>	Used on some products to order firmware updates which is useful when updating products that are daisy-chained together so that down-stream products are updated and rebooted first.
<i>fc</i>	Firmware Code is used to denote which firmware type the product accepts

Example

```
id mfr:cambrionix,mode :main,h-  
w:PP15S,hwid:0x13,fw:1.68,bl:0.15,sn:000000,group:-,fc:un >>
```

3.9. l (Live view)

Live view provides a continuous stream of data to view the port states and flags. Ports can be commanded using single key presses as per the table below.

Syntax (see Command structure)

Live view is designed to be interactive using a terminal. It makes extensive use of ANSI escape sequences to control the cursor position. Do not try to script the control of the live view.
The terminal size (rows, columns) must be large enough or the display will be corrupted. The hub attempts to set the number of rows and columns of the terminal when entering live viewmode.

Commands :

Type the below commands to interact with live view.

Select a port by typing a 2-digit port number (e.g. 01) to toggle all ports use /

Command	Description
/	Toggle all ports
o	Turn port off
c	Turn port to charge only
s	Turn port to sync mode
q /<ETX>	Quit live view

Example

```
cambrionix SuperSync15 15 Port USB Charge+Sync (live view)

Port  Flags   mA   State           Profile      Start   End   Energy

> 01          0   Charge (idle)
 02          0   Charge (idle)
 03          0   Charge (idle)
 04          0   Charge (idle)
 05          0   Charge (idle)
 06          0   Charge (idle)
 07  A       55   Profiling       Profile 3
 08          0   Charge (idle)
 09          0   Charge (idle)
 10          0   Charge (idle)
 11          0   Charge (idle)
 12          0   Charge (idle)
 13          0   Charge (idle)
 14          0   Charge (idle)
 15          0   Charge (idle)

Host present: Yes
5V Rail 5.23V      Input : 12.12V   Temperature: 37.4C
Total Current:    55mA      Total Power :   0W
Seconds since power on: 70162

Flags:   A:Attached, E:System Error, e:Port Error
Commands: o)ff c)harge s)ync q)uit live view
          Type 2-digit port number (e.g. 01). / toggles all ports
          Selection: --
```

3.10. ledb (LED bit flash pattern)

The ledb command can be used to assign a flash bit pattern to an individual LED.

Syntax: (see Command structure)

```
ledb port row ptn [control]
```

port: is the port number, starting at 1

row: is the LED row number, starting at 1. Typically these are arranged as follows:

Row	LED Function
1	Charged
2	Charging
3	Sync mode

ptn: can be specified as decimal (range 0..255), hexadecimal (range 00h to ffh) or binary (range 00000000b to 11111111b). Hexadecimal number must end with 'h'. Binary numbers must end with 'b'. More significant digits can be omitted for all radices. For example, '0b' is the same as '00000000b'.

Hexadecimal numbers are not case-sensitive. The valid pattern characters can be seen in the LED control

Control

using the [H | R] optional parameters

Parameter	Description
H	takes over control of the LED without a remote command
R	releases control of the LED back to normal operation.

Example

To flash the charging LED on port 8 at 50/50 duty cycle, use:

```
ledb 8 2 11110000b >>
```

To turn on the port 1 charged LED continuously (i.e. no flashing):

```
ledb 1 1 ffh >>
```

To turn off the port 1 sync LED:

```
ledb 1 3 0 >>
```

Notes

1. When no LEDs are present the commands is not found.
2. The LED state is not re-established when remote mode is exited and then re-entered.

3.11. leds (LED string flash pattern)

The leds command can be used to assign a string of flash patterns to one row of LEDs. This is much faster for controlling an entire row of LEDs. Just three uses of the leds command can set all the LEDs on the system.

Syntax: (see Command structure)

```
leds row [ptnstr]
```

row: is address as for ledb above.

[ptnstr] is a string of characters, one per port, starting at port 1. Each character represents a different flash pattern to be assigned to the port. A string of characters will assign flash patterns to the ports.

The valid pattern characters can be seen in the LED control

Example

To set up the following flash pattern on the row containing LED one:

Port	LED function
1	Unchanged
2	On
3	Flash fast
4	Single pulse
5	Off
6	On continuously
7	On continuously
8	Unchanged

Issue the command:

```
leds 1 x1fp011 >>
```

Note that the first LED (port 1) needed to be skipped using the x character. Port 8 was not altered as the pattern string only contained 7 characters.

Notes

1. When no LEDs are present the commands is not found.
2. The LED state is not re-established when remote mode is exited and then re-entered.

3.12. limits (system limits)

To show the limits (thresholds) at which the under-voltage, over-voltage and over-temperature errors are triggered, issue the limits command.

Syntax (see Command structure)

```
limits
```

Example

```
>> limits
5V Min: 4.50
5V Max: 5.58
Input Min: 9.59
Input Max: 20.00
Temperature (C): 75.0
```

*output from SS15

Notes

1. The limits are fixed in the firmware and cannot be changed by a command.
2. The measurements are sampled every 1ms. The voltages must be over or under voltage for 20ms before a flag is raised.
3. The temperature is measured every 10ms. A running average of 32 samples are used to give the result.
4. If the downstream voltage is sampled twice in a row outside product specifications then the ports will be shutoff

3.13. logc (Log port current)

For the Universal firmware the logc command is used to display the current for all ports at a pre-set time interval. Alongside current temperature and fan speed.

The logging for both instances can be stopped by sending q or <ETX>.

Universal Firmware Syntax: (see Command structure)

```
logc seconds
```

seconds is the interval between responses in the range 1..32767

Response: (see Response structure)

CSV (comma separated values).

Example

```
>> logc 2
Logging seconds, mA, degrees C, PWM%% with period (mins:secs): 00:02
Press Ctrl-C to stop

000000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000,
0000, 0000, 0000, 37.4, 0.0
000002, 0000, 0000, 0000, 0000, 0000, 0000, 0078, 0000, 0000, 0000, 0000, 0000,
0000, 0000, 0000, 37.4, 0.0
000004, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000,
0000, 0000, 0000, 37.4, 0.0
000006, 0000, 0000, 0000, 0000, 0000, 0000, 0067, 0000, 0000, 0000, 0000, 0000,
0000, 0000, 0000, 37.4, 0.0
000008, 0000, 0000, 0000, 0000, 0000, 0000, 0055, 0000, 0000, 0000, 0000, 0000,
0000, 0000, 0000, 37.4, 0.0
000010, 0000, 0000, 0000, 0000, 0000, 0000, 0067, 0000, 0000, 0000, 0000, 0000,
0000, 0000, 0000, 37.4, 0.0
```

Notes

1. The parameter is specified in seconds, but is confirmed as minutes:seconds for convenience:
2. Current logging works in both charge and sync modes.
3. The output is rounded to 1mA prior to display

3.14. logp (Log port power)

For the PDSync and TS3-C10 firmware the logp command is used to display the current and voltage for all ports at a pre-set time interval.

The logging for both instances can be stopped by pressing q or CTRL C.

Syntax: (see Command structure)

```
logp [seconds]
```

[seconds] is the interval between responses in the range 1..32767

Response: (see Response structure)

CSV (comma separated values).

Example


```
>>logp
Logging current with period (mins:secs): 00:01 Press q or CTRL C to stop

000000, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000
000001, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000
000002, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000
000003, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000
000004, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000
000005, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000
000006, 0000, 0000, 0000, 0000, 0956, 0000, 0000, 0000
000007, 0000, 0000, 0000, 0000, 1005, 0000, 0000, 0000
000008, 0000, 0000, 0000, 0000, 1005, 0000, 0000, 0000
000009, 0000, 0000, 0000, 0000, 1024, 0000, 0000, 0000
000010, 0000, 0000, 0000, 0000, 1005, 0000, 0000, 0000
000011, 0000, 0000, 0000, 0000, 1034, 0000, 0000, 0000
000012, 0000, 0000, 0000, 0000, 0000, 0000, 0000, 0000
```

Notes

1. The parameter is specified in seconds, but is confirmed as minutes:seconds for convenience:
2. Current logging works in both charge and sync modes.
3. The output is rounded to 1mA prior to display

3.15. loge (Log events)

The loge command is used to report port status change events and periodically report the state of all ports. The logging is stopped by sending <ETX>

Syntax: (see Command structure)

```
loge [seconds]
```

[seconds] is the interval between responses in the range 0..32767

Response: (see Response structure)

CSV (comma separated values).

Example

Here is a device being attached to port 4, left for 6 seconds, and then removed:

```
>> loge
Logging events
Press Ctrl-C to stop

System up for 70632
1, 0000, R D I, 0, 0, x, 0.00
2, 0000, R D I, 0, 0, x, 0.00
3, 0000, R D I, 0, 0, x, 0.00
4, 0000, R D I, 0, 0, x, 0.00
5, 0000, R D I, 0, 0, x, 0.00
6, 0000, R D I, 0, 0, x, 0.00
7, 0078, R A P, 1, 0, x, 0.00
8, 0000, R D I, 0, 0, x, 0.00
9, 0000, R D I, 0, 0, x, 0.00
10, 0000, R D I, 0, 0, x, 0.00
11, 0000, R D I, 0, 0, x, 0.00
12, 0000, R D I, 0, 0, x, 0.00
13, 0000, R D I, 0, 0, x, 0.00
14, 0000, R D I, 0, 0, x, 0.00
15, 0000, R D I, 0, 0, x, 0.00
```

Notes

1. Commands are accepted while in this mode but commands are not echoed and the command prompt is not

issued.

2. If a seconds value of '0' is specified then the periodic reporting is disabled and only port status change events will be reported. If no seconds parameter is supplied a default value of 60s will be used.
3. A time stamp in seconds is output before each event or periodic report the time stamp is the time the hub is switched on.

3.16. mode (Hub mode)

Each port can be placed into one of four modes by using the mode command.

Syntax: (see Command structure)

```
mode m [p] [cp]
```

Parameter	Description
m	A valid mode character
p	The port number
cp	The charging profile

Response: (see 'Response structure)

```
>>
```

mode parameters for Universal Firmware

Parameter	Description	Value
Charge	The port is readied for charging a device, and can detect if a device is attached or detached. If a device is attached, the charger profiles enabled for that port are tried one by one. Then the device is charged using the profile that yielded the highest current. During the above, the port is disconnected from the host USB bus.	s
Sync	The port is attached to the host USB bus via a USB hub. The device may draw charging current from VBUS depending on the device capabilities.	b
Biased	Port is detected but no charging or syncing will take place.	o
Off	Power to the port is removed. No charging occurs. No device attach or detach detection is possible.	c

mode parameters for PDSync and TS3-C10 Firmware

Parameter	Description	Value
Sync	The device can charge whilst communicating with the host connected to the hub.	c
Off	Power (VBUS) to the port is removed. No charging occurs. No device attach or detach detection is possible.	o

The port parameter

[p], is optional. It can be used to specify the port number. If left blank, all ports are affected by the command.

The charging profile parameter

[cp] is optional but can only be used when putting a single port into charge mode. If specified then that port will directly enter charge mode using the chosen profile.

Profile paramete	Description
0	Intelligent charging algorithm which will select a profile 1-6
1	2.1A (Apple and others with short detection time)
2	BC1.2 Standard (This covers the majority of Android phones and other devices)
3	Samsung
4	2.1A (Apple and others with long detection time)
5	1.0A (Typically used by Apple)
6	2.4A (Typically used by Apple)

Examples

To turn off all ports:

```
mode o >>
```

To put just port 2 in charge mode:

```
mode c 2 >>
```

To put just port 4 in charge mode using profile 1:

```
mode c 4 1 >>
```

3.17. Reboot (reboot the product)

Reboots the product.

Syntax: (see Command structure)

```
reboot [watchdog]
```

If the watchdog parameter is included then the system will lock into an infinite, unresponsive loop whilst the watchdog timer expires. The expiration takes several seconds, after which the system will reboot.

If the reboot command is issued without a parameter, the reboot command is executed immediately.

Response: (see 'Response structure')

```
>>
```

The reboot command is a soft reset which will only affect software. To perform a full product reset you will need to power-cycle the hub.

Rebooting sets the 'R' (rebooted) flag, which is reported by the health and state commands.

3.18. remote (Remote control)

Some products have interface devices such as indicators, switches and displays which can be used to interact with the hub directly. The function of these interfaces can be controlled via commands. This command disables normal function, and allows control via commands instead.

Entering remote control mode

The indicators will be turned off when entering remote control mode. The display will be unaffected and previous text will remain. Use `clcd` to clear the display. To disable the console control from the firmware, and allow it to be controlled via commands, issue the remote command without parameters:

Syntax: (see Command structure)

```
remote [mode]
```

To leave remote control mode, and allow the console to be controlled by the firmware, issue an exit command parameter.

Parameter	Description
exit	The LEDs will be reset and the LCD cleared when leaving remote control mode.
kexit	Tells the hub to enter remote control mode, but exit automatically when a console key is pressed:

Notes

1. In remote kexit mode, the keys command will not return key press events.
2. You can move from remote mode into remote kexit mode, and vice-versa.
3. Charging, syncing and security still operate in remote mode. However, their status will not be reported to the console, and the user will need to poll the status flags (using the state and health commands) to determine the system state.
4. If the **keys**, **lcd**, **clcd**, **leds** or **ledb** commands are issued when not in remote or remote kexit mode, then an error message will be shown, and the command will not be executed.

3.19. sef (Set Error flags)

It can be useful to set the error flags to examine the system behaviour when an error occurs.

Syntax: (see Command structure)

```
sef flags
```

flags is one or more of the below parameters, when sending multiple flags a space is required between each parameter.

Parameter	Description
3UV	3V rail under-voltage
3OV	3V rail over-voltage
5UV	5V rail under-voltage
5OV	5V rail over-voltage
12UV	12V rail under-voltage
12OV	12V rail over-voltage
OT	PCB over-temperature

Example

To set the 5UV and OT flags:

```
sef 5UV OT
```

Notes

1. Calling sef without parameters is valid, and sets no error flags.
2. Error flags may be set using sef on any product even if the flag is not relevant to the hardware.

3.20. state (List port state)

After a port is placed into a particular mode (e.g. charge mode) it can transition into a number of states. The state command is used to list the state of each port. It also shows the current being delivered to the device, any error flags, and the charge profile employed.

Syntax: (see Command structure)

```
state [p]
```

[p] is the port number.

Response: (see Response structure)

Comma separated parameters, one row per port.

Row format: p, current_mA, flags, profile_id, time_charging,time_charged,energy

Parameter	Description
p	The port number pertaining to the row
current_mA	Current being delivered to the mobile device, in mA (milliamperes)
flags	See below tables
profile_id T	The unique profile ID number. "0" if not charging or profiling
time_charging	Time in seconds the port has been charging
time_charged	Time in seconds that the port has been charged for (x means not valid yet).
energy	Energy the device has consumed in watthours (calculated every second)

Note : See product manual for current measurement resolution.

Flags for the Universal firmware range

List of case-sensitive flag characters, separated by spaces. O, S, B, I, P, C, F are mutually exclusive. A, D are mutually exclusive.

Flag	Description
O	Port is in OFF mode
S	Port is in SYNC mode
B	Port is in Biased mode
I	Port is in charge mode, and is IDLE

P	Port is in charge mode, and is PROFILING
C	Port is in charge mode, and is CHARGING
F	Port is in charge mode, and is has FINISHED charging
A	Device is ATTACHED to this port
D	No device is attached to this port. Port is DETACHED
T	Device has been stolen from port: THEFT
E	ERRORs are present. See health command
R	System has REBOOTED. See crf command
r	Vbus is being reset during mode change

Flags for the PDSync and TS3-C10 firmware range

3 flags are always returned for the Powerync firmware

List of case-sensitive flag characters, separated by spaces. Flags may mean different things in different columns	
1st flag	Description
A	Device is ATTACHED to this port
D	No device is attached to this port. Port is DETACHED
P	Port has established a PD contract with device
C	Cable has non-type-C connector at far end, no device detected
2nd flag	
I	Port is IDLE
S	Port is the host port and is connected
C	Port is CHARGING
F	Port has FINISHED charging
O	Port is in OFF mode
c	Power is enabled on port but no device is detected
3rd flag	
—	Quick charge mode is disallowed

+	Quick charge mode is allowed but not enabled
q	Quick charge mode is enabled but not in use
Q	Quick charge mode is in use

Flags for the Motor Control firmware range

Case sensitive flag characters. One of o, O, c, C, U will always be present. T and S are only present when their condition is detected.

Flag	Description
o	Gate is opening
O	Gate is open
c	Gate is closing
C	Gate is closed
U	Gate position is unknown, neither open nor closed and not moving
S	A stall condition was detected for this gate when it was last commanded to move
T	A timeout condition was detected for this gate when it was last commanded to move. ie the gate did not finish moving in a reasonable time nor did it stall.

Examples

A device connected to port 5, which is charging at 1044mA using profile_id 1

```
>>state
1, 0000, D I, 0, 0, x, 0.00
2, 0000, D I, 0, 0, x, 0.00
3, 0000, D I, 0, 0, x, 0.00
4, 0000, D I, 0, 0, x, 0.00
5, 1044, A C, 1, 5, x, 0.01
6, 0000, D I, 0, 0, x, 0.00
7, 0000, D I, 0, 0, x, 0.00
8, 0000, D I, 0, 0, x, 0.00
```

Another device attached to port 8. This is being profiled using profile_id 2 prior to charging:

```
>>state
1, 0000, D I, 0, 0, x, 0.00
2, 0000, D I, 0, 0, x, 0.00
3, 0000, D I, 0, 0, x, 0.00
4, 0000, D I, 0, 0, x, 0.00
```

```
5, 0927, A C, 1, 10, x, 0.05
6, 0000, D I, 0, 0, x, 0.000
7, 0000, D I, 0, 0, x, 0.00
8, 0048, A P, 2, 5, x, 0.01
```

A global system error reported by the EE flag:

```
>>state
1, 0000, E D I, 0, 0, x, 0.00
2, 0000, E D I, 0, 0, x, 0.00
3, 0000, E D I, 0, 0, x, 0.00
4, 0000, E D I, 0, 0, x, 0.00
5, 0927, E A C, 1, 15, x, 0.00
6, 0000, E D I, 0, 0, x, 0.00
7, 0000, E D I, 0, 0, x, 0.00
8, 0048, E A P, 2, 2, x, 0.01
```

3.21. system (View system parameters)

To view system parameters, issue the system command.

Syntax: (see Command structure)

```
system
```

Response: (see Response structure)

First row: system title text.

Subsequent rows: parameter:value pairs, one pair per row.

```
Title text Hardware: Firmware: Compiled: Group: Panel ID:
```

Parameter	Description	Possible values
Hardware	Part number	
Firmware	Firmware version string	In a “n.nn” format, n is a decimal number 0..9
Compiled	Release time and date of the Firmware	
Group	Group letter read from PCB jumpers	1 character, 16 values: “-”, “A” .. “O” “-” means no group jumper is fitted
Panel ID	Panel ID number of front panel product	“None” if no panel was detected Otherwise “0” .. “15”
LCD	Presence of LCD display	“Absent” or “Present” If product can support an LCD

Notes

1. The system title text may change across firmware releases.
2. The ‘Panel ID’ is updated at power-up or reboot.
3. The ‘LCD’ parameter can only become ‘Present’ at power-up or reboot. It can become ‘Absent’ during run-time if the LCD is no longer detected. Only applicable to products with removable displays.

3.22. beep (Make product beep)

Makes the sounder beep for a specified amount of time. The beep is performed as a background task – so the system can process other commands whilst the beep is produced.

Syntax: (see Command structure)

```
beep [ms]
```

Parameter	Description
ms	the length of beep in milliseconds (range 0..32767)

Response: (see Response structure)

```
>>
```

Notes

1. The time [ms] has a resolution of 10ms
2. A beep will not be interrupted by a shorter or zero-length beep.
3. The beep from an alarm is overridden by the continuous tone from a beep command. when the continuous beep completes, the system will return to the alarm beep.
4. Sending <BEL> from the terminal will cause a short beep to be generated.
5. Beeps are only audible on products with sounders fitted.

3.23. clcd (Clear LCD)

The lcd is cleared by using the clcd command.

Syntax: (see **Command structure**)

```
clcd
```

Response: (see **Response structure**)

```
>>
```

Notes

1. This is only applicable to products fitted with displays.

3.24. get_profiles (get port profiles)

To get the profiles assigned to a port, use the get_profiles command. For more information on profiles see Charging profiles

Syntax: (see **Command structure**)

```
get_profiles p
```

p: is the port number

Response: (see **Response structure'**)

Port profiles are listed and defined whether they are enabled or disabled

Example

To get the profiles assigned to port 1:

```
>> get_profiles 1
1, enabled
2, enabled
3, enabled
4, enabled
5, disabled
6, disabled
```

3.25. set_profiles (set port profiles)

To assign profiles to an individual port, use the set_profiles command. For more information on profiles see Charging profiles

Syntax: (see **Command structure**)

```
set_profiles p [cp]
```

Parameter	Description
p	Port number
cp	Charging profile

To assign all system profiles to a port, issue set_profiles without a list of profiles.

Response: (see **Response structure**)

```
>>
```

Example

To set profiles 2 and 3 for port 5:

```
set_profiles 5 2 3
```

To assign all profiles to port 8:


```
set_profiles 8
```

Notes

1. Use get_profiles to obtain list of profiles set on each port.

3.26. list_profiles (List global profiles)

The list of profiles can be obtained by using the list_profiles command: For more information on profiles see Charging profiles

Syntax: (see Command structure)

```
list_profiles
```

Response: (see Response structure)

Each profile listed has 2 parameters separated by a comma: profile_id, enabled_flag.

The profile_id is a unique number that always corresponds to one profile type. It is a positive integer starting at 1. A profile_id of 0 is reserved for when the absence of a profile is to be indicated.

enabled_flag can be enabled or disabled depending on whether the profile is active on the product.

Example

```
>> list_profiles
1, enabled
2, enabled
3, enabled
4, enabled
5, disabled
6, disabled
```

3.27. en_profile (Enable / disable profiles)

The en_profile command is used to enable and disable each profile. The effect applies to all ports.

Syntax: (see Command structure)

```
en_profile i e
```

Parameter	Description	Value
i	Profile parameter	see below table
e	Enable flag	1 = enabled 0 = disabled

Profile parameter	Description
0	Intelligent charging algorithm which will select a profile 1-6
1	2.1A (Apple and others with short detection time)
2	BC1.2 Standard (This covers the majority of Android phones and other devices)
3	Samsung
4	2.1A (Apple and others with long detection time)
5	1.0A (Typically used by Apple)
6	2.4A (Typically used by Apple)

Response: (see Response structure)

```
>>
```

Example

To disable a profile for all ports use the command:

```
en_profile 2 0 >>
```

Operation with no enabled profiles

If all profiles for a port are disabled, the port will transition into the Biased port state. This permits device attach and detach detection to work, but no charging will occur. Security (theft detection) will still operate if all profiles are disabled, as will the attach (AA) and detach (DD) flags reported by the state command.

Notes

1. This command has an immediate effect. If the command is issued whilst a port is profiling, then the command will only have an effect if that profile has not yet been reached.

3.28. keys (Key states)

The product may be fitted with up to three buttons. When a button is pressed, a key 'click' flag is set. This flag remains set until it is read. To read the key click flags, use the keys command. The result is a comma-separated list, with one flag per key:

Syntax: (see Command structure)

```
keys
```

Keys A, B and C are listed respectively. A '1' means the key has been pressed since the keys command was last called. The flags are cleared after keys is run:

Notes

- The keys command only works in remote mode. It does not work in remote kexit mode
- This command will only work on products with buttons installed.

3.29. lcd (Write to the LCD)

If an LCD is attached, it can be written to by using this command.

Syntax: (see 'Command structure)

```
lcd row col string
```

Parameter	Description
row	0 is the first row, 1 is for the second row
col	The column number, starting at 0
string	Displayed on the LCD. It may contain spaces before, within and after.

Example

To write "Hello, world" on the far left of the second row:

```
lcd 1 0 Hello, world >>
```

Displaying Icons

As well as ASCII characters, the LCD can display several custom icons. These are accessed by sending the escape sequence <ESC> c, where c is the character '1' .. '8':

c	Icon
1	Empty battery
2	Continuously animated battery
3	Cambrionix filled 'o' glyph
4	Full battery
5	Padlock
6	Egg timer
7	Custom numeral 1 (aligned to right of bitmap)
8	Custom numeral 1 (aligned to middle of bitmap)

3.30. sec (Device security)

The product can log if a device was unexpectedly removed from a port. The sec command can be used to put all ports into an 'armed' security state. If a device is removed in the armed state, then an alarm can be triggered, and the T flag is shown.

Syntax: (see Command structure)

```
sec [arm|disarm]
```

Response to no parameters: (see Response structure)

```
armed|disarmed >>
```

Response to arm|disarm parameter: (see Response structure)

```
>>
```

Examples

To arm the system:

```
sec arm >>
```

To disarm the system:

```
sec disarm >>
```

To obtain the armed state:

```
sec disarmed >>
```

Notes

- If theft detection is needed, but no device charging or syncing is desired, set the ports to Biased mode. If using Biased mode and the device battery runs out then the alarm will be raised
- To clear all theft bits and silence a sounding alarm, disarm then re-arm the system.

3.31. serial_speed (Set serial speed)

Sets the serial speed.

Syntax: (see Command structure)

```
serial_speed [speed]
```

Parameter	Description
test	Test whether the product supports an increase in serial speed from current speed
fast	Increase serial speed
slow	Reduce serial speed

Response: (see Response structure)

```
Response >>
```

Response	Description
OK	The product supports an increase in speed
Error	The product does not support an increase in speed

You should flush the serial buffer after the first “serial_speed fast” before the speed is changed to 1Mbaud. If during operation at 1Mbaud any serial errors are detected the speed is automatically dropped to 115200baud without warning. The host code must be aware of this and take suitable action. If the link regularly fails do not to try increase the speed again.

Example

To increase the serial speed to 1Mbaud use the following sequence:

```
serial_speed test OK >> serial_speed fast
```

If any error is detected in the above sequence the speed increase won't occur or will be reset.

Before exiting the host should return the speed back to 115200baud with the following command

```
serial_speed slow
```

Failure to do so will result in the first characters being lost until the hub detects the incorrect baud rate as serial errors and drops back to 115200baud.

3.32. set_delays (Set delays)

Sets internal delays

Syntax: (see Command structure)

```
set_delays port_reset_delay_ms attach_blanking_ms deattach_count deattach_sync_count
```

Parameter	Description	Default values
port_reset_delay_ms	Time left unpowered when changing modes. (ms)	400
attach_blanking_ms	Time device attach detection will be delayed to avoid a quick insert and removal. (ms)	2000
deattach_count	Reserved for future use.	30
deattach_sync_count	A number value to set the depth of filtering a deattach event in sync mode	14

Response: (see Response structure)

```
>>
```

Notes

- The use of this command may prevent correct charging.
- ADET_PIN gives a false positive (it shows a device is attached when none is present). It remains in this erroneous state for about 1 second after leaving PORT_MODE_OFF.

3.33. boot (Enter boot-loader)

Boot mode is used to update the firmware within the hub. We do not provide public information about using the hub in boot mode.

If you find the product in boot mode, you can return to normal operation by sending the reboot command or by power-cycling the system.

Syntax: (see Command structure)

```
boot
```

Response: (see Response structure)

```
boot>>
```

3.34. gate (Gate command)

The gate command is used to control the movement of gates.

Syntax: (see Command structure)

```
gate position port [strength]
```

Parameter	Description
position	The desired gate command (stop open close)
port	Either the port number or 'all' for all ports
strength	An integer that alters the speed of movement (0-2047)

Response: (see Response structure)

```
>>
```

3.35. proxy

In order to distinguish commands targeted at the Motor Control Board from those for the host unit itself, there is a host unit command 'proxy' which takes as its arguments the commands for the Motor Control Board.

The user must prefix all the commands meant for the Motor Control board with 'proxy' when they are sent to the host unit's command line interface.

Syntax: (see Command structure)

```
proxy
```

3.36. keyswitch

To show the current position of the keyswitch issue the keyswitch command.

Syntax: (see Command structure)

```
keyswitch
```

Response: (see Response structure)

```
keyswitch: (parameter) >>
```

Parameter	Description
Open	The keyswitch is in the open position.
Closed	The keyswitch is in the closed position.

3.37. rgb

The rgb command is used to set one or more ports into LED override mode. In order to set the individual RGB LED levels on a port, the port must first be set into LED override mode which will stop the mirroring of the host unit's LEDs onto that port. On entering LED override mode the LEDs on that port will all be turned off.

Syntax: (see Command structure)

```
rgb override [p]
```

Override parameter	Description
start	Used to enter RGB override mode
leave	Used to exit override mode

p is the port number.

Response: (see Response structure)

```
>>
```

3.38. rgb_led

The rgb_led command is used to set the RGB LED levels on one or more ports to the value specified.

Syntax: (see Command structure)

```
rgb_led p level
```

Override parameter	Description
p	A single port or a range of ports.
level	An eight digit hex number that represents the levels to set for the RGB LEDs. in the format 'aarrggbb'

level parameters	Description
aa	Sets the maximum level for the LEDs on this port, the other LEDs are all scaled from this setting
rr	Sets the level for the Red LED
gg	Sets the level for the Green LED
bb	Sets the level for the Blue LED

Response: (see Response structure)

```
>>
```

3.39. stall

The stall command is used to set the current at which it is determined that a gate has stalled.

Syntax: (see Command structure)

```
stall current
```

Parameter	Description
current	The value in mA that will be used as the level of current draw by the motor above which it is determined that a gate has stalled.

Response: (see Response structure)

```
>>
```

Errors

Failed commands will respond with an error code of the form below.

```
*Ennn: Explanation
```

“nnn” is always a three digit decimal number.

Command error codes

Error code	Error name	Description
400	ERR_COMMAND_NOT_RECOGNISED	Command is not valid
401	ERR_EXTRANEIOUS_PARAMETER	Too many parameters
402	ERR_INVALID_PARAMETER	Parameter is not valid
403	ERR_WRONG_PASSWORD	Invalid password
404	ERR_MISSING_PARAMETER	Mandatory parameter missing
405	ERR_SMBUS_READ_ERR	Internal system management communication read error
406	ERR_SMBUS_WRITE_ERR	Internal system management communication write error
407	ERR_UNKNOWN_PROFILE_ID	Invalid profile ID
408	ERR_PROFILE_LIST_TOO_LONG	Profile list exceeds limit
409	ERR_MISSING_PROFILE_ID	Required profile ID missing
410	ERR_INVALID_PORT_NUMBER	Port number not valid for this product
411	ERR_MALFORMED_HEXADECIMAL	Invalid hexadecimal value
412	ERR_BAD_HEX_DIGIT	Invalid hex digit
413	ERR_MALFORMED_BINARY	Invalid binary
414	ERR_BAD_BINARY_DIGIT	Invalid binary digit
415	ERR_BAD_DECIMAL_DIGIT	Invalid decimal digit
416	ERR_OUT_OF_RANGE	Not within defined range
417	ERR_ADDRESS_TOO_LONG	Address exceeds character limit
418	ERR_MISSING_PASSWORD	Required password missing
419	ERR_MISSING_PORT_NUMBER	Required port number missing

420	ERR_MISSING_MODE_CHAR	Required mode character missing
421	ERR_INVALID_MODE_CHAR	Invalid mode character
422	ERR_MODE_CHANGE_SYS_ERR_FLAG	System error on mode change
423	ERR_CONSOLE_MODE_NOT_REMOTE	Remote mode required for product
424	ERR_PARAMETER_TOO_LONG	Parameter has too many characters
425	ERR_BAD_LED_PATTERN	Invalid LED pattern
426	ERR_BAD_ERROR_FLAG	Invalid error flag

Example

Specifying a non-existent port to the mode command:

```
>> mode c 17 *E410: Port number must be 1..8
```


4.1. Fatal errors

When the system encounters a fatal error, the error is reported to the terminal immediately in the following format:

```
*FATAL ERROR Ennn: Explanation
```

“nnn” is a three-digit error reference number.

“Explanation” describes the error.

When a fatal error has occurred the CLI will only respond to <ETX> and <CR>. If either of these are received, then the system will enter boot mode. If <ETX> or <CR> are not received within the watchdog timeout period (approximately 9 seconds) then the system will reboot.

Important

If a fatal error occurs whilst a command is sending a <ETX> or ENTER character to the hub, then boot mode will be entered. If the product enters boot mode then you will need to send the reboot command to return to normal operation.

Boot mode is indicated by receiving the below response (sent on a new line)

```
boot
```

In boot mode, non-bootloader commands will be responded to with:

```
*E900: Invalid bootloader command
```

For testing purposes, boot mode can be entered by using the boot command.

Charging profiles

When a device is attached to a hub, the product can provide a variety of different charging levels.

Each of these different variations is called a ‘profile’. Some devices will not charge properly unless presented with the correct profile. A device not presented with a charging profile it recognises will draw less than 500mA as per USB specifications.

When a device is attached to the product, and it is in ‘charge mode’, it tries each profile in turn. Once all the profiles have been tried, the hub selects the profile that drew the highest current.

In some cases it may not be desirable for the hub to scan all the profiles in this way. For example, if only devices from one manufacturer are attached, then only that specific profile will need to be active. This reduces the time delay when a user attaches a device, and sees evidence of the device charging properly.

The hub provides the means to limit the profiles tried, both on a ‘global’ level (across all ports) and on a port-by-port basis.

Profile parameter	Description
0	Intelligent charging algorithm which will select a profile 1-6
1	2.1A (Apple and others with short detection time)
2	BC1.2 Standard (This covers the majority of Android phones and other devices)
3	Samsung
4	2.1A (Apple and others with long detection time)
5	1.0A (Typically used by Apple)
6	2.4A (Typically used by Apple)

Port modes

The port modes are defined by the 'host' and 'mode' commands.

Charge	Turn specific ports or the whole hub to charge mode
Sync	Turn specific ports or the whole hub to sync mode (data and power channels open)
Biased	Detect the presence of a device but it will not sync or charge it.
Off	Turn specific ports on or off or switch the whole hub on or off. (no power and no data channels open)

Not all products have each mode available, check individual product user manuals for the modes that are supported.

LED control

There are two methods to control to the LEDs in remote control mode: ledb and leds. First, however, the operation of the LEDs will be described.

The flash pattern is an 8-bit byte. Each bit is repeatedly scanned in sequence fromMSB to LSB (i.e. left to right). A '1' bit turns the LED on, and a '0' turns it off. For example, a bit pattern of decimal 128 (binary 10000000b) would pulse the LED briefly. A bit pattern of decimal 127 (binary 01111111b) would see the LED on for most of the time, only turning off briefly.

Pattern Character	LED function	Flash pattern
0 (number)	Off	00000000
1	On continuously (not flashing)	11111111
f	Flash fast	10101010
m	Flash medium speed	11001100
s	Flash slowly	11110000
p	Single pulse	10000000
d	Double pulse	10100000
O (Capital letter)	Off (no remote command needed)	00000000
C	On (no remote command needed)	11111111
F	Flash fast (no remote command needed)	10101010
M	Flash medium speed (no remote command needed)	11001100
S	Flash slowly (no remote command needed)	11110000
P	Single pulse (no remote command needed)	10000000
D	Double pulse (no remote command needed)	10100000
R	Release "no remote command needed " LEDs back to normal use	
x	unchanged	unchanged

In auto mode the defaults can be seen in the table below, some products may vary so please see individual

product user manuals to confirm LED functions.

www.cambrionix.com/product-user-manuals

LED Type	Meaning	Conditions	Indicator Light Display
Power	Power Off	● Soft power off (standby) or no power	Off
Power	Power On No Host Connected	● Power on ● No fault with the product	Green
Power	Power On Host Connected	● Power on ● No fault with the product ● Host connected	Blue
Power	Fault with code	● Major fault condition	Red Flashing (Fault code pattern)
Port	Device Disconnected / Port Disabled	● Device disconnected or port disabled	Off
Port	Not Ready / Warning	● Device resetting, starting, changing mode of operation or updating firmware	Yellow
Port	Charge Mode Profiling	● Fault with connected device	Green Flashing (on/off in once second intervals)
Port	Charge Mode Charging	● Port in charge mode ● Device connected and charging	Green Pulsing (dim/brightens in one second intervals)
Port	Charge Mode Charged	● Port in charge mode ● Device connected, and charge threshold met or unknown	Green
Port	Sync Mode	● Port in sync mode	Blue
Port	Fault	● Fault with connected device	Red


Internal hub Settings

8.1. Introduction

Cambrionix products have Internal settings which are used to store settings which need to remain even after the product has had power removed. This section describes how to apply Internal hub setting changes along with their affect on the product they are applied to.

There are two methods for changing the product settings:

1. Entering the required command settings.
2. Change the settings on the LiveViewer application.

	CAUTION
	Changing Internal hub settings on a Cambrionix product may cause the product to function incorrectly.

8.2. Internal hub settings and their correct usage.

Notes:

- Only if a command succeeds will there be a visible response within the terminal window.
- The command settings_unlock needs to be entered prior to a settings_set or settings_reset command

Setting	Usage
settings_unlock	This command unlocks the memory for writing. This command must directly precede settings_set and settings_reset. It is not possible to change NV RAM settings without entering this command.
settings_display	Displays the current NV RAM settings in a form which can be copied and pasted back into the serial terminal. Also useful to create a .txt file backup of your settings for future reference.
settings_reset	This command resets the memory back to the default settings. This command must be preceded by settings_unlock. The existing settings are displayed before being reset. Only if the command succeeds will there be a response.
company_name <name>	Sets the company name. The name cannot contain '%' or '\'. Maximum length of the name is 16 characters. This command must be preceded by settings_set
default_profile <list>	Sets the default profile to be used by each port. <list> is a space separated list of the profile number to be applied to each port in ascending order. Specifying a profile of '0' for any port means that there is no default profile applied to that port, this is the default behaviour on reset. All ports must have an entry in the list. This command must be preceded by settings_set 1 = Apple 2.1A or 2.4A if the product supports 2.4A charging (short detect time). 2 = BC1.2 which covers a number of standard devices. 3 = Samsung charging profile. 4 = Apple 2.1A or 2.4A if the product supports 2.4A charging (long detection time). 5 = Apple 1A profile. 6 = Apple 2.4A profile.
remap_ports <list>	This setting allows you to map ports numbers on the Cambrionix products to port numbers on your own product, which may not have the same number order. This command must be preceded by settings_set
ports_on <list>	Sets a port to be always powered regardless of attach status. This must only be used in conjunction with a default profile. <list> is a space separated list of flags for each port in ascending order. A '1' denotes that the port will be always powered. A '0' denotes default behaviour which is that the port will not be powered until an attached device is detected. This command must be preceded by settings_set
sync_chrg <list>	'1' denotes that CDP is enabled for a port. CDP cannot be turned off with ThunderSync products. This command must be preceded by settings_set
charged_threshold <0000>	Sets the charged_threshold in 0.1mA steps must have leading zeros to make a four digit number. This command must be preceded by settings_set

8.3. Examples

To reset a Cambrionix product back to factory defaults:

```
settings_unlock
settings_reset
```

To view the current settings on a Cambrionix product:

```
settings_display
```

To configure a PowerPad15S to perform in a similar manner to the discontinued BusMan product (ie. no automatic switching between charging and sync modes if a host is connected or disconnected)

```
settings_unlock  
settings_set attach_threshold 3
```

To change the attach threshold on a Cambrionix product to 30mA

```
settings_unlock  
settings_set attach_threshold 3
```

To set the Company and Product name on a Cambrionix product to match your own (applicable to OEM products only):

```
settings_unlock  
settings_set company_name ChargeInc  
settings_unlock  
settings_set product_name SuperCharge
```

Supported Products

Here you can find a table with all commands and which products they are valid for.

	U8S	U16S S pade	PP15S	PP8S	PP15C	SS15	TS2- 16	TS3- 16	TS3- C10	PDS- C4	ModIT- Max
bd	x	x	x	x	x	x	x	x	x	x	x
cef	x	x	x	x	x	x	x	x	x	x	x
cls	x	x	x	x	x	x	x	x	x	x	x
crf	x	x	x	x	x	x	x	x	x	x	x
health	x	x	x	x	x	x	x	x	x	x	x
host	x	x	x	x		x	x	x	x	x	x
id	x	x	x	x	x	x	x	x	x	x	x
l	x	x	x	x	x	x	x	x	x	x	x
ledb	x	x					x	x	x	x	x
leds	x	x					x	x	x	x	x
limits	x	x	x	x	x	x	x	x	x	x	x
loge	x	x	x	x	x	x	x	x	x	x	x
mode	x	x	x	x	x	x	x	x	x	x	x
reboot	x	x	x	x	x	x	x	x	x	x	x
remote	x	x					x	x	x	x	x
sef	x	x	x	x	x	x	x	x	x	x	x
state	x	x	x	x	x	x	x	x	x	x	x
system	x	x	x	x	x	x	x	x	x	x	x
beep	x	x	x	x	x	x	x	x	x	x	x
clcd	x	x					x				
en_profile	x	x	x	x	x	x	x	x			x
get_profile s	x	x	x	x	x	x	x	x			x
keys	x	x					x				
lcd	x	x					x				

list_profiles	x	x	x	x	x	x	x	x			x
logc	x	x	x	x	x	x	x	x			x
sec	x	x					x				
serial_speed	x	x	x	x	x	x	x	x			x
set_delays	x	x	x	x	x	x	x	x			x
set_profiles	x	x	x	x	x	x	x	x			x
detail	x	x	x	x	x	x	x	x	x	x	x
logp									x	x	
power									x	x	
qcmode										x	
gate											x
keyswitch											x
proxy											x
stall											x
rgb											x
rgb_led											x

ASCII Table

dec	hex	oct	char	Ctrl char
0	0	000	<NULL>	ctrl-@
1	1	001	<SOH>	ctrl-A
2	2	002	<STX>	ctrl-B
3	3	003	<ETX>	ctrl-C
4	4	004	<EOT>	ctrl-D
5	5	005	<ENQ>	ctrl-E
6	6	006	<ACK>	ctrl-F
7	7	007	<BEL>	ctrl-G
8	8	010	<BS>	ctrl-H
9	9	011	<TAB>	ctrl-I
10	a	012	<LF>	ctrl-J
11	b	013	<VT>	ctrl-K
12	c	014	<FF>	ctrl-L
13	d	015	<CR>	ctrl-M
14	e	016	<SOH>	ctrl-N
15	f	017	<SI>	ctrl-O
16	10	020	<DLE>	ctrl-P
17	11	021	<DC1>	ctrl-Q
18	12	022	<DC2>	ctrl-R
19	13	023	<DC3>	ctrl-S
20	14	024	<DC4>	ctrl-T
21	15	025	<NAK>	ctrl-U
22	16	026	<SYN>	ctrl-V
23	17	027	<ETB>	ctrl-W
24	18	030	<CAN>	ctrl-X
25	19	031		ctrl-Y

26	1a	032	<SUB>	ctrl-Z
27	1b	033	<ESC>	ctrl-[
28	1c	034	<FS>	ctrl-\
29	1d	035	<GS>	ctrl-]
30	1e	036	<RS>	ctrl-^
31	1f	037	<US>	ctrl-__
32	20	040	space	
33	21	041	!	
34	22	042	“	
35	23	043	#	
36	24	044	\$	
37	25	045	%	
38	26	046	&	
39	27	047	‘	
40	28	050	(
41	29	051)	
42	2a	052	*	
43	2b	053	+	
44	2c	054	,	
45	2d	055	—	
46	2e	056	.	
47	2f	057	/	
48	30	060	0	
49	31	061	1	
50	32	062	2	
51	33	063	3	
52	34	064	4	
53	35	065	5	

54	36	066	6	
55	37	067	7	
56	38	070	8	
57	39	071	9	
58	3a	072	:	
59	3b	073	;	
60	3c	074	<	
61	3d	075	=	
62	3e	076	>	
63	3f	077	?	
64	40	100	@	
65	41	101	A	
66	42	102	B	
67	43	103	C	
68	44	104	D	
69	45	105	E	
70	46	106	F	
71	47	107	G	
72	48	110	H	
73	49	111	I	
74	4a	112	J	
75	4b	113	K	
76	4c	114	L	
77	4d	115	M	
78	4e	116	N	
79	4f	117	O	
80	50	120	P	
81	51	121	Q	

82	52	122	R	
83	53	123	S	
84	54	124	T	
85	55	125	U	
86	56	126	V	
87	57	127	W	
88	58	130	X	
89	59	131	Y	
90	5a	132	Z	
91	5b	133	[
92	5c	134	\	
93	5d	135]	
94	5e	136	^	
95	5f	137	_	
96	60	140	`	
97	61	141	a	
98	62	142	b	
99	63	143	c	
100	64	144	d	
101	65	145	e	
102	66	146	f	
103	67	147	g	
104	68	150	h	
105	69	151	i	
106	6a	152	j	
107	6b	153	k	
108	6c	154	l	
109	6d	155	m	

110	6e	156	n	
111	6f	157	o	
112	70	160	p	
113	71	161	q	
114	72	162	r	
115	73	163	s	
116	74	164	t	
117	75	165	u	
118	76	166	v	
119	77	167	w	
120	78	170	x	
121	79	171	y	
122	7a	172	z	
123	7b	173	{	
124	7c	174		
125	7d	175	}	
126	7e	176	~	
127	7f	177	DEL	

Terminology

Term	Explanation
U8 devices	Any device in the U8 sub-series. E.g. U8C, U8C-EXT, U8S, U8S-EXT
U16 devices	Any device in the U16 sub-series. E.g. U16C, U16S Spade
VCP	Virtual COM port
/dev/	Devices directory on Linux® and macOS®
IC	Integrated Circuit
PWM	Pulse width modulation. The duty cycle is the percent of time the PWM is in the high (active) state
Sync mode	Synchronisation mode (hub provides USB connection to host computer)
Port	USB socket on the front of hub that is used to connect mobile devices.
MSB	Most significant bit
LSB	Least significant bit
Internal hub	Non-Volatile RAM

Licensing

The use of Command Line Interface is subject to the Cambrionix Licence agreement, the document can be downloaded and viewed using the following link.

<https://downloads.cambrionix.com/documentation/en/Cambrionix-Licence-Agreement.pdf>

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and or symbols of third-party companies not related in any way to Cambrionix. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by Cambrionix, or an endorsement of the product(s) to which this manual applies by the third-party company in question.

Cambrionix hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and /or symbols contained in this manual and related documents are the property of their respective holders

“Mac® and macOS® are trademarks of Apple Inc., registered in the U.S. and other countries and regions.”

“Intel® and the Intel logo are trademarks of Intel Corporation or its subsidiaries.”

“Thunderbolt™ and the Thunderbolt logo are trademarks of Intel Corporation or its subsidiaries.”

“Android™ is a trademark of Google LLC”

“Chromebook™ is a trademark of Google LLC.”

“iOS™ is a trademark or registered trademark of Apple Inc, in the US and other countries and is used under license.”

“Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries”

“Microsoft™ and Microsoft Windows™ are trademarks of the Microsoft group of companies.”

“Cambrionix® and the logo are trademarks of Cambrionix Limited.”


© 2023-05 Cambrionix Ltd. All rights reserved.

Cambrionix Limited
The Maurice Wilkes Building
Cowley Road
Cambridge CB4 0DS
United Kingdom

+44 (0) 1223 755520
enquiries@cambrionix.com
www.cambrionix.com

Cambrionix Ltd is a company registered in England and Wales
with the company number 06210854

Documents / Resources

	<p>Cambrionix 2023 Command Line Interface [pdf] User Manual 2023 Command Line Interface, 2023, Command Line Interface, Line Interface, Interface</p>
---	--

References

- [Cambrionix: USB Hub Experts - Smart Managed USB Hubs](#)
- [Command Line Instructions](#)
- [Product User Manuals - Cambrionix](#)
- [Home - FTDI](#)
- [Download PuTTY - a free SSH and telnet client for Windows](#)
- [Download PuTTY - a free SSH and telnet client for Windows](#)
- [User Manual](#)