



ChunHee HI03 Wireless Home Intercom System Instruction Manual

[Home](#) » [ChunHee](#) » ChunHee HI03 Wireless Home Intercom System Instruction Manual 

ChunHee HI03 Wireless Home Intercom System Instruction Manual



Contents

- 1 Features
- 2 Introduction
- 3 Parts List
- 4 Specification
- 5 Overview
- 6 Keys Introduction
- 7 Low Battery Reminder
- 8 Basic Operation
- 9 Troubleshooting
- 10 Warm Tips
- 11 Customer Guarantee
- 12 Customer Service
- 13 Documents / Resources
 - 13.1 References
- 14 Related Posts

Features

- 16 Channels
- Long Standby Time
- Adjustable Volume (4 Levels)
- Channel Lock/Unlock
- 1640ft Working Range
- Type-C Charge Port
- Rechargeable Battery
- Low Battery Alert
- Clear & Loud Voice

Introduction

The ChunHee HI03 Wireless Intercom is a simple and secure way to communicate between multiple intercoms (up to 16 units, total) within an area of up to 1,640ft (500m). The wireless intercoms operate on 16 channels but only support talk on the same channel.

- **Read this manual thoroughly. A clear understanding of the manual will make installation and operation much easier.**
- **The intercom contains no user-serviceable parts. Opening them may damage sensitive components and will void the warranty.**

Parts List

- Intercom



- Clip



- Charge Station



- USB Cable



***Power adapter not included.** The cable can be compatible amphitheater with the Input: AC 100-240V/Output: DC 5V/1A.

Specification

Frequency Range	UHF 460-470MHz
Number of Channel	16 Channels
Volume	4 Levels Available
Talk Range	500 Meters/1640ft
Battery	2500mAh Rechargeable Lithium-PolymerBattery
Standby Time	96 Hours
Usage Time	36 Hours
Charging Time	4-6 Hours for a Full Charge

Overview



1. Speaker
2. Power Button
3. Indicator
4. Talk Button
5. Charge Indicator
6. Charge Station
7. Type-C Charge Port
8. Volume
9. Channel Lock
10. Channel Increase
11. Channel Decrease

③ **Indicator of Intercom**

Red Color: Charging

Flashing Red Color: Low Battery

Blue Color: Fully Charged

Flashing Blue Color: Stand-by

* ⑤ **Indicator of Charge Base Station**

Red Color: Charging

Yellow Color: Fully Charged

Keys Introduction



Power Button: Hold it for 3 seconds to turn on/off the device.:



Talk Button: Hold it to speak with other released to listen to the response (Ensure all device is at multichannel).:



Volume Adjust Button: Press it to adjust the volume (4 levels available).



Channel Lock/Unlock: Hold it for 5 seconds till hear a "DI" sound to lock the channel, preventing further changes. Hold it for 5 seconds till hear a "DI-DI" sound to unlock the Channel.



Channel Increase: Press to increase the channels (16 channels available).

Channel Decrease: Press to decrease the channels (16 channels available)

Low Battery Reminder

The two-way radio will activate a voice prompt saying "Please charge the battery." while the battery level reaches 3%. This reminder will be broadcast every 5 minutes until the battery is completely depleted.

Note: * It is essential to recharge the battery promptly once the low battery reminder is activated to ensure uninterrupted communication.

* Charge the battery at least 4 hours for the first time, and 3 hours for subsequent charge.

Basic Operation

Power ON/OFF

Hold the power button for 3 seconds until hear the "DI- LI-LI-DI" sound to release it.



Talking

Hold the [Talk] button to speak, release the [TALK] button to finish.





Channel Change

Press the Back & Next buttons to change the channel.



Volume Adjust

Press the volume button to change the volume level(4Levels Available)



Channel Lock/Unlock

Hold the [volume] button for 5s to lock/unlock the channel.





Quick Start

Step 1: Hold power button for 5s to turn on the device;

Step 2: Set the channel for your device to the same;

Step 3: Press the Volume button to choose the volume level;

Step 4: Holding the TALK button start speaking!



Direct charge

Use the USB cable connect the device and power.

* Power Adapter is not provide



Base Stationcharge

Use the cable connect thecharge base andpower.

* Power Adapter isnot provide



Troubleshooting

buttonwhile speaking. Release the [TALK] buttontofinishspeaking." image-1="" headline-2="h2" question-2="Q3: No sound during communication" answer-2="A3(1): Check if the channel is at the same channel (Theunits must at the same channel, they cannot connectifthe device in the different channels.) A3(2):Other models device can not be workingtogether.A3(3):Please try to turn on again then adjust thevolume." image-2="" headline-3="h2" question-3="Q4: The two-way radio experience channel noise, increased background noise, or reduced communication distance." answer-3="A4(1): Stay away from electronic devices and high-voltage wires that may cause interference while using the two-way radio. A4(2): If interference occurs, try switching to another channel to

reduce the interference. A4(3): When using multiple device in a network, ensure they share the same channel setting to avoid conflicts." image-3="" count="4" html="true" css_class=""]

Warm Tips

Battery Use: Use the manufacturer recommended battery type and charger, avoid short-circuiting or violently squeezing the battery, and never dispose of it in a fire.

Moisture Prevention: Avoid using the radio in humid environments to prevent internal components from getting wet.

Cleaning and Dust Prevention: Use a soft, clean cloth to wipe the surface and screen, avoiding chemical solvents or sharp objects. Store the two- way radio in a clean container or bag when not in use to prevent dust and debris from entering.

Communication Range: Do not exceed the effective communication distance to avoid interruptions.

Volume Setting: Avoid prolonged use of high volume to protect your hearing.

Physical Damage: Protect the two-way radio from extreme temperatures, humidity, dust, vibration, or heavy impact to prevent device damage.

Children's Usage: Supervise children when they use the two-way radio, ensuring they follow safety guidelines and operate it correctly.

Customer Guarantee

We provide a 30-day money-back guarantee for any reason (free shipping) and 1-year warranty (transportation prepaid) to the original purchaser against manufacturing defects in materials and workmanship. **Note:** This Warranty is void if the damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair or alteration, improper or abnormal usage, or faulty installation, or any other reason.

Customer Service

Contact our friendly support team for quick solutions

Friendly reminder: When contacting us for help, be sure to have your product handy for troubleshooting!

Contact us

A. Order list—Choose the order—Get help with order.

B. Contact our email to get service, we will reply to your message in 24 hours.

Email: chunheeus@126.com

ChunHee

Documents / Resources



[ChunHee HI03 Wireless Home Intercom System](#) [pdf] Instruction Manual
HI03 Wireless Home Intercom System, HI03, Wireless Home Intercom System, Home Intercom System, Intercom System

References

- [User Manual](#)

Manuals+.