



Circutor ePick GPRS VPN Gateway Data Box User Manual

[Home](#) » [Circutor](#) » Circutor ePick GPRS VPN Gateway Data Box User Manual 

Circutor



ePick GPRS VPN
GATEWAY PARA PLATAFORMA DataBox
GATEWAY FOR DataBox PLATFORM

This manual is a ePick GPRS VPN installation guide. For further information, please download the full manual from the CIRCUTOR web site: www.circutor.com



IMPORTANT!

The unit must be disconnected from its power supply sources before undertaking any installation, repair or handling operations on the unit's connections. Contact the after-sales service if you suspect that there is an operational fault in the unit. The unit has been designed for easy replacement in case of malfunction.

The manufacturer of the unit is not responsible for any damage resulting from failure by the user or installer to heed the warnings and/or recommendations set out in this manual, nor for damage resulting from the use of non-original products or accessories or those made by other manufacturers.

Contents

- 1 DESCRIPTION**
- 2 INSTALLATION**
- 3 START-UP**
- 4 Documents / Resources**

DESCRIPTION

ePick GPRS VPN is a gateway designed to communicate with machines and sensors, collect and store their data and send it to the web for processing.

The device communicates via GPRS, has Ethernet, RS-485 and includes a SIM card with VPN communications to provide a 100% two-way connection without the need for configuration.

The ePick GPRS VPN always communicates with the DataBox platform via GPRS.

INSTALLATION

The ePick GPRS VPN has been designed for assembly on DIN rail.



IMPORTANT!

Take into account that when the device is connected, the terminals may be hazardous to the touch, and opening the covers or removing elements may provide access to parts that are dangerous to the touch. Do not use the device until it is fully installed.

The device must be connected to a power circuit protected by gL (IEC 60269) or M class fuses between 0.5 and 2A. It must be fitted with a circuit breaker or equivalent device to disconnect the device from the power supply.

The ePick GPRS VPN can be connected to a device (machines, sensors ...) via Ethernet or RS-485:

√ Ethernet:

A category 5 or higher network cable is required for the Ethernet connection.

√ RS-485:



The connection via RS-485 requires a twisted communication cable to be connected between terminals A+, B- and GND.



START-UP

The device must be configured from the Circutor Databox web platform, after it is connected to the auxiliary power supply (terminals L and N). See Instruction Manual M382B01-03-xxx.

Technical features


Power supply	CA /AC CC/DC
Rated voltage	85 ... 264V — 120... 300V =
Frequency	47 ... 63 Hz –
Consumption	8.8 ...10.5 VA 6.4 ... 6.5 W
Installation category	CAT III 300 V CAT III 300 V
Radio connection	
External antenna	Incluida /Included
Connector	SMA
SIM	Incluida / Included
RS-485 Communications	
Bus	RS-485
Protocol	Modbus RTU
Baud rate	9600-19200-38400-57600-115200 bps
Stop bits	1-2
Parity	sin – par -impar/ none – even -odd
Ethernet Communications	
Type	Ethernet 10/100 Mbps
Connector	RJ45
Protocol	TCP/IP
Secondary service IP address	100.0.0.1
User interface	
LED	3 LED
Environmental features	
Operating temperature	-20°C ... +50°C
Storage temperature	-25°C ... +75°C
Relative humidity (non-condensing)	5 ... 95%
Maximum altitude	2000 m
Protection degree IP	IP20
Protection degree IK	IK08
Pollution degree	2

Use	Interior/ Indoor
Mechanical features	
Terminals	
1 ... 5	1.5 mm ² 0.2 Nm  M2
Dimensions	87.5 x 88.5 x 48 mm
Weight	180 g.
Surround	Polycarbonato UL94 VO autoextinguible Polycarbonate UL94 Self-extinguishing VO
Attachment	Card DIN/ DIN rail
Electrical safety	
Protection against electric shock	Doble aislamiento clase II / Double insulation class II
Isolation	3 kV-




Dimensions

LEDs	
Power	Device status
	ON
	Green color Device ON
RS-485	ON
	Red color:Data transmission
Modem	ON
	Communications status
	Red color:Data transmission
	Green color:Data reception



Note: Device images are for illustrative purposes only and may differ from the actual device.

Terminal connections designations	
1	VI, Power supply
2	N, Power supply
3	B-, RS-485 Connection
4	A+, RS-485 Connection
5	GND, RS-485 Connection
6	Ethernet, Ethernet Connection



Technical service
CIRCUTOR SAT: 902 449 459 (SPAIN) / (+34) 937 452 919 (out of Spain)
Vial Sant Jordi, s/n
08232 – Viladecavalls (Barcelona)
Tel: (+34) 937 452 900 – Fax: (+34) 937 452 914
e-mail: sat@circutor.com
M382A01-44-23A

Documents / Resources



[Circutor ePick GPRS VPN Gateway Data Box](#) [pdf] User Manual
ePick GPRS VPN Gateway Data Box, ePick GPRS VPN, Gateway Data Box, Data Box, Box