

CISCO

CISCO AP-SIDD-A06 Parameters for
Access Points



CISCO AP-SIDD-A06 Parameters for Access Points User Guide

[Home](#) » [Cisco](#) » CISCO AP-SIDD-A06 Parameters for Access Points User Guide 

Contents

- [1 CISCO AP-SIDD-A06 Parameters for Access Points](#)
- [2 Product Usage Instructions](#)
- [3 2.4-GHz Radio Support](#)
- [4 5-GHz Radio Support](#)
- [5 6-GHz Radio Support](#)
- [6 Configuration](#)
- [7 Verification](#)
- [8 Frequently Asked Questions \(FAQ\)](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

CISCO

CISCO AP-SIDD-A06 Parameters for Access Points



Specifications

- Product: Cisco Access Points
- Frequency Support: 2.4 GHz and 5 GHz
- Supported Features: Spectrum Intelligence (SI), Antenna Configuration, Beamforming, Channel Assignment, CleanAir, Antenna Selection, Shutdown, Transmit Power Level
- Antenna Gain Range: 0 to 40 dBi
- Maximum Gain: 20 dBi

Product Usage Instructions

Configuring 2.4-GHz Radio Support

1. **Step 1:** Enable privileged EXEC mode. `Device# enable`
2. **Step 2:** Enable Spectrum Intelligence (SI) for the dedicated 2.4-GHz radio on slot 0. `Device# ap name ap-name dot11 24ghz slot 0 SI`
3. **Step 3:** Configure the antenna for the 2.4-GHz radio on slot 0. `Device# ap name ap-name dot11 24ghz slot 0 antenna selection internal`
4. **Step 4:** Configure beamforming for the 2.4-GHz radio on slot 0. `Device# ap name ap-name dot11 24ghz slot 0 beamforming`
5. **Step 5:** Configure the channel assignment for the 2.4-GHz radio on slot 0. `Device# ap name ap-name dot11 24ghz slot 0 channel auto`
6. **Step 6:** Enable CleanAir for the 2.4-GHz radio on slot 0. `Device# ap name ap-name dot11 24ghz slot 0 cleanair`
7. **Step 7:** Configure the antenna type (A, B, C, or D) for the 2.4-GHz radio on slot 0. `Device# ap name ap-name dot11 24ghz slot 0 dot11n antenna A`
8. **Step 8:** Shutdown the 2.4-GHz radio on slot 0. `Device# ap name ap-name dot11 24ghz slot 0 shutdown`
9. **Step 9:** Configure the transmit power level for the 2.4-GHz radio on slot 0. `Device# ap name ap-name dot11 24ghz slot 0 txpower auto`

Configuring 5-GHz Radio Support

2.4-GHz Radio Support

Configuring 2.4-GHz Radio Support for the Specified Slot Number

Before you begin

Note The term 802.11b radio or 2.4-GHz radio will be used interchangeably.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Device# enable	Enters privileged EXEC mode.
Step 2	ap name <i>ap-name</i> dot11 24ghz slot 0 SI Example:	Enables Spectrum Intelligence (SI) for the dedicated 2.4-GHz radio hosted on slot 0 for a

	Command or Action	Purpose
	Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 SI	specific access point. For more information, Spectrum Intelligence section in this guide. Here , 0 refers to the Slot ID.

Step 3	ap name <i>ap-name</i> dot11 24ghz slot 0 antenna {ext-ant-gain antenna_gain_value selection [internal external]} Example: Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 antenna selection internal	Configures 802.11b antenna hosted on slot 0 for a specific access point. • extant-gain: Configures the 802.11b external antenna gain. antenna_gain_value- Refers to the external antenna gain value in multiples of .5 dBi units. The valid range is from 0 to 40, the maximum gain being 20 dBi. • selection: Configures the 802.11b antenna selection (internal or external). Note • For APs supporting self-identifying antennas (SIA), the gain depends on the antenna, and not on the AP model. The gain is learned by the AP and there is no need for controller configuration. • For APs that do not support SIA, the APs send the antenna gain in the configuration payload, where the default antenna gain depends on the AP model. • Cisco Catalyst 9120E and 9130E APs support self-identifying antennas (SIA). Cisco Catalyst 9115E APs do not support SIA antennas. Although Cisco Catalyst 9115E APs work with SIA antennas, the APs do not auto-detect SIA antennas nor add the correct external gain.
Step 4	ap name <i>ap-name</i> dot11 24ghz slot 0 beamforming Example: Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 beamforming	Configures beamforming for the 2.4-GHz radio hosted on slot 0 for a specific access point.
Step 5	ap name <i>ap-name</i> dot11 24ghz slot 0 channel {channel_number <i>auto</i>} Example: Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 channel auto	Configures advanced 802.11 channel assignment parameters for the 2.4-GHz radio hosted on slot 0 for a specific access point.

	Command or Action	Purpose
Step 6	ap name <i>ap-name</i> dot11 24ghz slot 0 cleanair Example: Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 cleanair	Enables CleanAir for 802.11b radio hosted on slot 0 for a specific access point.
Step 7	ap name <i>ap-name</i> dot11 24ghz slot 0 dot11n antenna {A B C D} Example: Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 dot11n antenna A	Configures 802.11n antenna for 2.4-GHz radio hosted on slot 0 for a specific access point. Here, A: Is the antenna port A. B: Is the antenna port B. C: Is the antenna port C. D: Is the antenna port D.
Step 8	ap name <i>ap-name</i> dot11 24ghz slot 0 shutdown Example: Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 shutdown	Disables 802.11b radio hosted on slot 0 for a specific access point.
Step 9	ap name <i>ap-name</i> dot11 24ghz slot 0 txpower {tx_power_level auto} Example: Device# ap name AP-SIDD-A06 dot11 24ghz slot 0 txpower auto	Configures transmit power level for 802.11b radio hosted on slot 0 for a specific access point. - tx_power_level: Is the transmit power level in dBm. The valid range is from 1 to 8. auto: Enables auto-RF.

5-GHz Radio Support

Configuring 5-GHz Radio Support for the Specified Slot Number

Before you begin

Note The term 802.11a radio or 5-GHz radio will be used interchangeably in this document.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Device# enable	Enters privileged EXEC mode.
Step 2	ap name <i>ap-name</i> dot11 5ghz slot 1 SI Example: Device# ap name AP-SIDD-A06 dot11 5ghz slot 1 SI	Enables Spectrum Intelligence (SI) for the dedicated 5-GHz radio hosted on slot 1 for a specific access point. Here, 1 refers to the Slot ID.
Step 3	ap name <i>ap-name</i> dot11 5ghz slot 1 antenna ext-ant-gain antenna_gain_value Example: Device# ap name AP-SIDD-A06 dot11 5ghz slot 1 antenna ext-ant-gain	Configures external antenna gain for 802.11a radios for a specific access point hosted on slot 1. antenna_gain_value—Refers to the external antenna gain value in multiples of .5 dBi units. The valid range is from 0 to 40, the maximum gain being 20 dBi. Note - For APs supporting self-identifying antennas (SIA), the gain depends on the antenna, and not on the AP model. The gain is learned by the AP and there is no need for controller configuration. - For APs that do not support SIA, the APs send the antenna gain in the configuration payload, where the default antenna gain depends on the AP model. - Cisco Catalyst 9120E and 9130E APs support self-identifying antennas (SIA). Cisco Catalyst 9115E APs do not support SIA antennas. Although Cisco Catalyst 9115E APs work with SIA antennas, the APs do not auto-detect SIA antennas nor add the correct external gain.
Step 4	ap name <i>ap-name</i> dot11 5ghz slot 1 antenna mode [omni sectorA sectorB] Example: Device# ap name AP-SIDD-A06 dot11 5ghz slot 1 antenna mode sectorA	Configures the antenna mode for 802.11a radios for a specific access point hosted on slot 1.

	Command or Action	Purpose
--	-------------------	---------

Step 5	ap name <i>ap-name</i> dot11 5ghz slot 1 antenna selection [internal external] Example: Device# ap name AP-SIDD-A06 dot11 5ghz slot 1 antenna selection internal	Configures the antenna selection for 802.11a radios for a specific access point hosted on slot 1.
Step 6	ap name <i>ap-name</i> dot11 5ghz slot 1 beamforming Example: Device# ap name AP-SIDD-A06 dot11 5ghz slot 1 beamforming	Configures beamforming for the 5-GHz radio hosted on slot 1 for a specific access point.
Step 7	ap name <i>ap-name</i> dot11 5ghz slot 1 channel { <i>channel_number</i> auto width [20 40 80 160]} Example: Device# ap name AP-SIDD-A06 dot11 5ghz slot 1 channel auto	Configures advanced 802.11 channel assignment parameters for the 5-GHz radio hosted on slot 1 for a specific access point. Here, <i>channel_number</i> – Refers to the channel number. The valid range is from 1 to 173.
Step 8	ap name <i>ap-name</i> dot11 5ghz slot 1 cleanair Example: Device# ap name AP-SIDD-A06 dot11 5ghz slot 1 cleanair	Enables CleanAir for 802.11a radio hosted on slot 1 for a given or specific access point.
Step 9	ap name <i>ap-name</i> dot11 5ghz slot 1 dot11n antenna { A B C D } Example: Device# ap name AP-SIDD-A06 dot11 5ghz slot 1 dot11n antenna A	Configures 802.11n for 5-GHz radio hosted on slot 1 for a specific access point. Here, • A– Is the antenna port A. • B– Is the antenna port B. • C– Is the antenna port C. • D– Is the antenna port D.
Step 10	ap name <i>ap-name</i> dot11 5ghz slot 1 rrm channel <i>channel</i> Example: Device# ap name AP-SIDD-A06 dot11 5ghz slot 1 rrm channel 2	Is another way of changing the channel hosted on slot 1 for a specific access point. Here, <i>channel</i> – Refers to the new channel created using 802.11h channel announcement. The valid range is from 1 to 173, provided 173 is a valid channel in the country where the access point is deployed.

Step 11	ap name <i>ap-name</i> dot11 5ghz slot 1 shutdo wn Example:	Disables 802.11a radio hosted on slot 1 for a s pecific access point.
----------------	---	--

	Command or Action	Purpose
	Device# ap name AP-SIDD-A06 dot11 5ghz s lot 1 shutdown	
Step 12	ap name <i>ap-name</i> dot11 5ghz slot 1 txpower <i>{tx_power_level auto}</i> Example: Device# ap name AP-SIDD-A06 dot11 5ghz s lot 1 txpower auto	Configures 802.11a radio hosted on slot 1 for a specific access point. <i>tx_power_level</i>– Is the transmit power level i n dBm. The valid range is from 1 to 8. auto– Enables auto-RF.

6-GHz Radio Support

Configuring 6-GHz Radio Support for the Specified Slot Number

Before you begin

- Static channel must be set before changing the channel width.
- As there are no external antenna APs, as by regulatory requirements, antennas have to be captive (internal always) for 6-GHz.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Device# enable	Enters privileged EXEC mode.
Step 2	ap name <i>ap-name</i> dot11 6ghz slot 3 antenna port {A B C D} Example: Device# ap name <i>Cisco-AP</i> dot11 6ghz slot 3 antenna port A	Configures the antenna port for 802.11 6-Ghz radios for a specific access point. Here, A: Is the antenna port A. B: Is the antenna port B. C: Is the antenna port C. D: Is the antenna port D.
Step 3	ap name <i>ap-name</i> dot11 6ghz slot 3 antenna selection [internal external] Example: Device# ap name <i>Cisco-AP</i> dot11 6ghz slot 1 antenna selection internal	Configures the antenna selection, either internal or external, for 802.11 6-Ghz radios for a specific access point. Note For APs supporting self-identifying antennas (SIA), the gain depends on the

	Command or Action	Purpose
		antenna, and not on the AP model. The gain is learned by the AP and there is no need for controller configuration. - For APs that do not support SIA, the APs send the antenna gain in the configuration payload, where the default antenna gain depends on the AP model. - Cisco Catalyst 9120E and 9130E APs support self-identifying antennas (SIA). Cisco Catalyst 9115E APs do not support SIA antennas. Although Cisco Catalyst 9115E APs work with SIA antennas, the APs do not auto-detect SIA antennas nor add the correct external gain.

Step 4	ap name <i>ap-name</i> dot11 6ghz slot 3 channel {<i>channel_number</i> auto width [160 20 40 80]} Example: Device# ap name <i>Cisco-AP</i> dot11 6ghz slot 3 channel auto	Configures advanced 802.11 channel assignment parameters for the 6-GHz radio hosted on slot 3 for a specific access point. Here, <i>channel_number</i>: Refers to the channel number. The valid range is from 1 to 233.
Step 5	ap name <i>ap-name</i> dot11 6ghz slot 3 dot11ax bss-color {<i>bss-color-number</i> auto} Example: Device# ap name <i>Cisco-AP</i> dot11 6ghz slot 3 dot11ax bss-color auto	Enables basic service set (BSS) color for 802.11 6-GHz radio for a given or specific access point. Here, <i>bss-color-number</i>: Refers to the BSS color number. The valid range is from 1 to 63.
Step 6	ap name <i>ap-name</i> dot11 6ghz slot 3 radio role {auto manual {client-serving monitor sniffer}} Example: Device# ap name <i>Cisco-AP</i> dot11 6ghz slot 3 radio role auto	Configures the 802.11 6-GHz radio role, which is either auto or manual.
Step 7	ap name <i>ap-name</i> dot11 6ghz slot 3 rrm channel <i>channel</i> Example: Device# ap name <i>Cisco-AP</i> dot11 6ghz slot 3 rrm channel 1	Configures a new channel using 802.11h channel announcement. Here, <i>channel</i>: Refers to the new channel created using 802.11h channel announcement. The valid range is from 1 to 233.
Step 8	ap name <i>ap-name</i> dot11 6ghz slot 3 shutdown Example:	Disables the 802.11 6-GHz radio on the Cisco AP.

	Command or Action	Purpose
	Device# ap name <i>Cisco-AP</i> dot11 6ghz slot 3 shutdown	
Step 9	ap name <i>ap-name</i> dot11 6ghz slot 3 txpower { <i>tx_power_level</i> auto } Example: # ap name AP-SIDD-A06 dot11 5ghz slot 1 tx power auto	Configures 802.11 6-GHz Tx power level. <i>tx_power_level</i>: Is the transmit power level in dBm. The valid range is from 1 to 8. auto: Enables auto-RF.

Information About Dual-Band Radio Support

- The Dual-Band (XOR) radio in Cisco 2800, 3800, 4800, and the 9120 series AP models offer the ability to serve 2.4-GHz or 5-GHz bands or passively monitor both the bands on the same AP. These APs can be configured to serve clients in 2.4-GHz and 5-GHz bands, or serially scan both 2.4-GHz and 5-GHz bands on the flexible radio while the main 5-GHz radio serves clients.
- Cisco Catalyst Wireless 9166 AP (CW9166) now has XOR function for a dual 5-GHz 4x4 or 5-GHz 4x4 and 6-GHz 4x4 radios. These radios can also be configured as client serving, monitor or as a sniffer interface like the earlier XOR radios.
- Cisco APs models up and through the Cisco 9120 APs are designed to support dual 5-GHz band operations with the i model supporting a dedicated Macro/Micro architecture and the e and p models supporting Macro/Macro. The CW9166I supports Macro/Macro cell.
- When a radio moves between bands (from 2.4-GHz to 5-GHz and vice versa), clients need to be steered to get an optimal distribution across radios. When an AP has two radios in the 5-GHz band, client steering algorithms contained in the Flexible Radio Assignment (FRA) algorithm are used to steer a client between the same band co-resident radios.

The XOR radio support can be steered manually or automatically:

- Manual steering of a band on a radio—The band on the XOR radio can only be changed manually.
- Automatic client and band steering on the radios is managed by the FRA feature that monitors and changes the band configurations as per site requirements.

Note

- RF measurement will not run when a static channel is configured on slot 1. Due to this, the dual band radio slot 0 will move only with 5-GHz radio and not to the monitor mode.
- When slot 1 radio is disabled, RF measurement will not run, and the dual band radio slot 0 will be only on 2.4-GHz radio.

Note

Only one of the 5-GHz radios can operate in the UNII band (100 – 144), due to an AP limitation to keep the power

budget within the regulatory limit.

Configuration

Configuring Default XOR Radio Support

Before you begin

Note The default radio points to the XOR radio hosted on slot 0.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Device# enable	Enters privileged EXEC mode.
Step 2	ap name <i>ap-name</i> dot11 dual-band antenna ext-ant-gain <i>antenna_gain_value</i> Example: Device# ap name <i>ap-name</i> dot11 dual-band antenna ext-ant-gain 2	Configures the 802.11 dual-band antenna on a specific Cisco access point. <i>antenna_gain_value</i> : The valid range is from 0 to 40.
Step 3	ap name <i>ap-name</i> [no] dot11 dual-band shutdown Example: Device# ap name <i>ap-name</i> dot11 dual-band shutdown	Shuts down the default dual-band radio on a specific Cisco access point. Use the no form of the command to enable the radio.
Step 4	ap name <i>ap-name</i> dot11 dual-band role manual client-serving Example: Device# ap name <i>ap-name</i> dot11 dual-band role manual client-serving	Switches to client-serving mode on the Cisco access point.
Step 5	ap name <i>ap-name</i> dot11 dual-band band 24ghz Example: Device# ap name <i>ap-name</i> dot11 dual-band band 24ghz	Switches to 2.4-GHz radio band.
Step 6	ap name <i>ap-name</i> dot11 dual-band txpower {<i>transmit_power_level</i> auto} Example: Device# ap name <i>ap-name</i> dot11 dual-band txpower 2	Configures the transmit power for the radio on a specific Cisco access point. Note When an FRA-capable radio (slot 0 on 9120 AP [for instance]) is set to Auto, you cannot configure static channel and Txpower on this radio.

	Command or Action	Purpose
--	-------------------	---------

		If you want to configure static channel and Txpower on this radio, you will need to change the radio role to Manual Client-Serving mode. This note is not applicable for Cisco Catalyst Wireless 9166 AP (CW9166).
Step 7	ap name <i>ap-name</i> dot11 dual-band channel <i>channel-number</i> Example: Device# ap name <i>ap-name</i> dot11 dual-band channel 2	Enters the channel for the dual band. <i>channel-number</i>—The valid range is from 1 to 173.
Step 8	ap name <i>ap-name</i> dot11 dual-band channel auto Example: Device# ap name <i>ap-name</i> dot11 dual-band channel auto	Enables the auto channel assignment for the dual-band.
Step 9	ap name <i>ap-name</i> dot11 dual-band channel width{20 MHz 40 MHz 80 MHz 160 MHz} Example: Device# ap name <i>ap-name</i> dot11 dual-band channel width 20 MHz	Chooses the channel width for the dual band.
Step 10	ap name <i>ap-name</i> dot11 dual-band cleanair Example: Device# ap name <i>ap-name</i> dot11 dual-band cleanair	Enables the Cisco CleanAir feature on the dual-band radio.
Step 11	ap name <i>ap-name</i> dot11 dual-band cleanair band{24 GHz 5 GHz} Example: Device# ap name <i>ap-name</i> dot11 dual-band cleanair band 5 GHz Device# ap name <i>ap-name</i> [no] dot11 dual-band cleanair band 5 GHz	Selects a band for the Cisco CleanAir feature. Use the no form of this command to disable the Cisco CleanAir feature.

Step 12	ap name <i>ap-name</i> dot11 dual-band dot11n antenna {A B C D} Example: Device# ap name <i>ap-name</i> dot11 dual-band dot11n antenna A	Configures the 802.11n dual-band parameters for a specific access point.
----------------	--	--

	Command or Action	Purpose
Step 13	show ap name <i>ap-name</i> auto-rf dot11 dual-band Example: Device# show ap name <i>ap-name</i> auto-rf dot11 dual-band	Displays the auto-RF information for the Cisco access point.
Step 14	show ap name <i>ap-name</i> wlan dot11 dual-band Example: Device# show ap name <i>ap-name</i> wlan dot11 dual-band	Displays the list of BSSIDs for the Cisco access point.

Configuring XOR Radio Support for the Specified Slot Number (GUI)

Procedure

- **Step 1** Click Configuration > Wireless > Access Points.
- **Step 2** In the Dual-Band Radios section, select the AP for which you want to configure dual-band radios. The AP name, MAC address, CleanAir capability and slot information for the AP are displayed. If the Hyperlocation method is HALO, the antenna PID and antenna design information are also displayed.
- **Step 3** Click Configure.
- **Step 4** In the General tab, set the Admin Status as required.
- **Step 5** Set the CleanAir Admin Status field to Enable or Disable.
- **Step 6** Click Update & Apply to Device.

Configuring XOR Radio Support for the Specified Slot Number

Procedure

	Command or Action	Purpose
Step 1	enable Example: Device# enable	Enters privileged EXEC mode.

	Command or Action	Purpose
Step 2	ap name <i>ap-name</i> dot11 dual-band slot 0 antenna ext-ant-gain <i>external_antenna_gain_value</i> Example: Device# ap name AP-SIDD-A06 dot11 dual-band slot 0 antenna ext-ant-gain 2	Configures dual-band antenna for the XOR radio hosted on slot 0 for a specific access point. <i>external_antenna_gain_value</i> – Is the external antenna gain value in multiples of .5 dBi unit. The valid range is from 0 to 40. Note - For APs supporting self-identifying antennas (SIA), the gain depends on the antenna, and not on the AP model. The gain is learned by the AP and there is no need for controller configuration. - For APs that do not support SIA, the APs send the antenna gain in the configuration payload, where the default antenna gain depends on the AP model.
Step 3	ap name <i>ap-name</i> dot11 dual-band slot 0 band {24ghz 5ghz} Example: Device# ap name AP-SIDD-A06 dot11 dual-band slot 0 band 24ghz	Configures current band for the XOR radio hosted on slot 0 for a specific access point.
Step 4	ap name <i>ap-name</i> dot11 dual-band slot 0 channel {<i>channel_number</i> auto width [160 20 40 80]} Example: Device# ap name AP-SIDD-A06 dot11 dual-band slot 0 channel 3	Configures dual-band channel for the XOR radio hosted on slot 0 for a specific access point. <i>channel_number</i>– The valid range is from 1 to 165.
Step 5	ap name <i>ap-name</i> dot11 dual-band slot 0 cleanair band {24Ghz 5Ghz} Example: Device# ap name AP-SIDD-A06 dot11 dual-band slot 0 cleanair band 24Ghz	Enables CleanAir features for dual-band radios hosted on slot 0 for a specific access point.

Step 6	ap name <i>ap-name</i> dot11 dual-band slot 0 dot11n antenna {A B C D} Example: Device# ap name AP-SIDD-A06 dot11 dual-band slot 0 dot11n antenna A	Configures 802.11n dual-band parameters hosted on slot 0 for a specific access point. Here, • A– Enables antenna port A. • B– Enables antenna port B. • C– Enables antenna port C. • D– Enables antenna port D.
---------------	--	--

	Command or Action	Purpose
Step 7	ap name <i>ap-name</i> dot11 dual-band slot 0 role {auto manual [client-serving monitor]} Example: Device# ap name AP-SIDD-A06 dot11 dual-band slot 0 role auto	Configures dual-band role for the XOR radio hosted on slot 0 for a specific access point. The following are the dual-band roles: • auto– Refers to the automatic radio role selection. • manual– Refers to the manual radio role selection.
Step 8	ap name <i>ap-name</i> dot11 dual-band slot 0 shutdown Example: Device# ap name AP-SIDD-A06 dot11 dual-band slot 0 shutdown Device# ap name AP-SIDD-A06 [no] dot11 dual-band slot 0 shutdown	Disables dual-band radio hosted on slot 0 for a specific access point. Use the no form of this command to enable the dual-band radio.
Step 9	ap name <i>ap-name</i> dot11 dual-band slot 0 txpower {tx_power_level auto} Example: Device# ap name AP-SIDD-A06 dot11 dual-band slot 0 txpower 2	Configures dual-band transmit power for XOR radio hosted on slot 0 for a specific access point. • <i>tx_power_level</i>– Is the transmit power level in dBm. The valid range is from 1 to 8. • auto– Enables auto-RF.

Receiver Only Dual-Band Radio Support

Information About Receiver Only Dual-Band Radio Support

- This feature configures the dual-band Rx-only radio features for an access point with dual-band radios.
- This dual-band Rx-only radio is dedicated for Analytics, Hyperlocation, Wireless Security Monitoring, and BLE AoA*.
- This radio will always continue to serve in monitor mode, therefore, you will not be able to make any channel and tx-rx configurations on the 3rd radio.

Configuring Receiver Only Dual-Band Parameters for Access Points

Enabling CleanAir with Receiver Only Dual-Band Radio on a Cisco Access Point (GUI)

Procedure

- **Step 1** Choose Configuration > Wireless > Access Points.
- **Step 2** In the Dual-Band Radios settings, click the AP for which you want to configure the dual-band radios.
- **Step 3** In the General tab, enable the CleanAir toggle button.
- **Step 4** Click Update & Apply to Device.

Enabling CleanAir with Receiver Only Dual-Band Radio on a Cisco Access Point

Procedure

	Command or Action	Purpose
Step 1	enable Example: Device# enable	Enters privileged EXEC mode.
Step 2	ap name <i>ap-name</i> dot11 rx-dual-band slot 2 cleanair band {24Ghz 5Ghz} Example: Device# ap name AP-SIDD-A06 dot11 rx-dual-band slot 2 cleanair band 24Ghz Device# ap name AP-SIDD-A06 [no] dot11 rx-dual-band slot 2 cleanair band 24Ghz	Enables CleanAir with receiver only (Rx-only) dual-band radio on a specific access point. Here, 2 refers to the slot ID. Use the no form of this command to disable CleanAir.

Disabling Receiver Only Dual-Band Radio on a Cisco Access Point (GUI)

Procedure

- **Step 1** Choose Configuration > Wireless > Access Points.
- **Step 2** In the Dual-Band Radios settings, click the AP for which you want to configure the dual-band radios.
- **Step 3** In the General tab, disable the CleanAir Status toggle button.
- **Step 4** Click Update & Apply to Device.

Disabling Receiver Only Dual-Band Radio on a Cisco Access Point

Procedure

	Command or Action	Purpose
Step 1	enable Example: Device# enable	Enters privileged EXEC mode.
Step 2	ap name <i>ap-name</i> dot11 rx-dual-band slot 2 shutdown Example: Device# ap name AP-SIDD-A06 dot11 rx-dual-band slot 2 shutdown Device# ap name AP-SIDD-A06 [no] dot11 rx-dual-band slot 2 shutdown	Disables receiver only dual-band radio on a specific Cisco access point. Here, 2 refers to the slot ID. Use the no form of this command to enable receiver only dual-band radio.

Configuring Client Steering (CLI)

Before you begin

Enable Cisco CleanAir on the corresponding dual-band radio.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Device# enable	Enters privileged EXEC mode.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	wireless macro-micro steering transition-threshold balancing-window <i>number-of-clients</i>(0-65535) Example: Device(config)# wireless macro-micro steering transition-threshold balancing-window 10	Configures the micro-macro client load-balancing window for a set number of clients.

	Command or Action	Purpose
--	-------------------	---------

Step 4	wireless macro-micro steering transition-threshold client count <i>number-of-clients(0-65535)</i> Example: Device(config)# wireless macro-micro steering transition-threshold client count 10	Configures the macro-micro client parameters for a minimum client count for transition.
Step 5	wireless macro-micro steering transition-threshold macro-to-micro <i>RSSI-in-dBm(-128-0)</i> Example: Device(config)# wireless macro-micro steering transition-threshold macro-to-micro -100	Configures the macro-to-micro transition RSSI.
Step 6	wireless macro-micro steering transition-threshold micro-to-macro <i>RSSI-in-dBm(-128-0)</i> Example: Device(config)# wireless macro-micro steering transition-threshold micro-to-macro -110	Configures the micro-to-macro transition RSSI.
Step 7	wireless macro-micro steering probe-suppression aggressiveness <i>number-of-cycles(-128-0)</i> Example: Device(config)# wireless macro-micro steering probe-suppression aggressiveness -110	Configures the number of probe cycles to be suppressed.
Step 8	wireless macro-micro steering probe-suppression hysteresis <i>RSSI-in-dBm</i> Example: Device(config)# wireless macro-micro steering probe-suppression hysteresis -5	Configures the macro-to-micro probe in RSSI. The range is between -6 to -3.
Step 9	wireless macro-micro steering probe-suppression probe-only Example: Device(config)# wireless macro-micro steering probe-suppression probe-only	Enables probe suppression mode.

Step 10	wireless macro-micro steering probe-suppression probe-auth Example:	Enables probe and single authentication suppression mode.
----------------	--	---

	Command or Action	Purpose
	Device(config)# wireless macro-micro steering probe-suppression probe-auth	
Step 11	show wireless client steering Example: Device# show wireless client steering	Displays the wireless client steering information.

Verification

Verifying Cisco Access Points with Dual-Band Radios

To verify the access points with dual-band radios, use the following command:

Device# show ap dot11 dual-band summary

AP Name Subband Radio Mac Status Channel Power Level Slot ID Mode

- 4800 All 3890.a5e6.f360 Enabled (40)* *1/8 (22 dBm) 0 Sensor
- 4800 All 3890.a5e6.f360 Enabled N/A N/A 2 **Monitor**

Frequently Asked Questions (FAQ)

Q: What is the range of valid values for antenna gain in multiples of .5 dBi units?

A: The valid range for antenna gain values is from 0 to 40 dBi, with a maximum gain of 20 dBi.

Documents / Resources

	CISCO AP-SIDD-A06 Parameters for Access Points [pdf] User Guide AP-SIDD-A06, AP-SIDD-A06 Parameters for Access Points, Parameters for Access Points, Access Points
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.