




## COMET P8552 Web Sensors User Manual

[Home](#) » [COMET](#) » COMET P8552 Web Sensors User Manual 



**Web Sensor with PoE – two channels with binary inputs**  
**QUICK START MANUAL**  
**P8552 P8652 P8653**

### Contents

- [1 PRODUCT DESCRIPTION](#)
- [2 INSTALLATION AND OPERATION](#)
- [3 DEVICE SETUP](#)
- [4 ERROR STATES AND TROUBLESHOOTING](#)
- [5 SAFETY INSTRUCTIONS](#)
- [6 Technical Specification](#)
- [7 Binary inputs](#)
- [8 External Probes](#)
- [9 Device Connection Procedure](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)

## PRODUCT DESCRIPTION

Web Sensors P8552, P8652 and P8653 with Ethernet connection are designed to measure temperature and relative humidity of the air.

The devices are equipped with two connectors for connection of the temperature and humidity external probes and three binary inputs for two states signals. The dry contact or two-state voltage signal can be connect to the binary input. The first binary input of the sensor P8653 is intended for the flood detector LD-81 connection. The devices are powered from an external power supply adapter. Web Sensors P8652, P8653 supports also Power over Ethernet (PoE).

Measured values can be read and then processed using an Ethernet connection. The following formats of Ethernet communication are supported: www pages with user-design possibility, Modbus TCP protocol, SNMPv1 protocol,

SOAP protocol and XML. The instrument may send also a warning message if the measured value exceeds adjusted limit. The messages can be sent up to 3 e-mail addresses or to Syslog server and can be sent by SNMP Trap too. The alarm states are also displayed on the websites. The device setup can be made by the TSensor software (see [www.cometsystem.com](http://www.cometsystem.com)) and using the www interface.

Type	Measured value	Construction	PoE
P8552	T + RH + BIN	Two connectors for external probes and terminal block for three binary inputs	no
P8652	T + RH + BIN	Two connectors for external probes and terminal block for three binary inputs	yes
P8653	T + RH + BIN	Two connectors for external probes and terminal block for LD-81 detector and two binary inputs	yes

T...temperature, BIN... binary input, RH...relative humidity

## INSTALLATION AND OPERATION

The devices are designed for wall mounting with two screws or bolts. Pay attention to the location of the device and probe. Incorrect choice of working position could adversely affect accuracy and long-term stability of measured values. The Web Sensor with attached DSRH/C or DST/C probe install always vertically with the sensor cover downwards. Devices don't require any special operation and maintenance.

We recommend you periodic calibration for measurement accuracy validation.

## DEVICE SETUP


Contact your network administrator to obtain necessary information for the device connection into the network (IP address, default gateway, subnet mask) and check if there is no IP address conflict when you connect the device into network for the first time. IP address of each device is set by manufacturer to 192.168.1.213. Install the latest version of TSensor to your PC, connect the Ethernet cable and connect the power supply (see "Device connection procedure" on the other side of this data sheet).

Run the configuration software TSensor. Set the „Ethernet“ communication interface and press „Find Device“ button. According to MAC address (see device label) select device for configuration and by „Change IP Address“ button set new address according to network administrator instructions. Gateway IP address may not be entered if you want to use the device only in local network. After changing of IP address the device is restarted and new IP address is assigned. Restart of the device takes about 10 seconds.

The device setup can be made by the web interface. Main page will be shown when you insert device address into address bar of your web browser. Access to device setup is possible via tile Settings (see user manual).

To restore the Web Sensor to the factory default settings use the button inside the device.

Turn off the power supply and press the button (see picture). Turn on the power supply and keep the button pressed for 10 sec.



## ERROR STATES AND TROUBLESHOOTING





Device continuously checks its state during operation and if an error appears, the device sends the error message. The detailed description of the error messages is given in the user manual Chapter "Troubleshooting".

## **SAFETY INSTRUCTIONS**



- Don't connect or disconnect thermometers while power supply is on.
- Installation, electrical connection and commissioning should be performed by qualified personnel only.
- Use the power adapter according to technical specifications and approved according to relevant standards only.
- The external probe cable should be located as far as possible from potential interference sources.
- If it is necessary connect the device to the Internet, properly configured firewall must be used.
- The device should not be used for applications, where malfunction could cause to injury or damage to property.
- Devices contain electronic components, it needs to liquidate them according to legal requirements.
- To supplement the information provided in this data sheet, use the manuals and other documentations which are available at [www.cometsystem.com](http://www.cometsystem.com)

## **Technical Specification**

Device type	P8552	P8652	P8653
Supply voltage – coaxial connector 5.1 x 2.1mm, (+) pole in the middle	4.9 to 6.1 Vdc	4.9 to 6.1 Vdc	4.9 to 6,1 Vdc
Power over Ethernet according to IEEE 802.3af, PD Class 0	no	yes	yes
Power consumption	approximately 1 W	approximately 1 W	approximately 1W
Temperature measuring range	according the probe *	according the probe *	according the probe *
Accuracy of temperature measurement	according the probe *	according the probe *	according the probe *
Relative humidity measuring range	according the probe *	according the probe *	according the probe *
Accuracy of relative humidity measurement	according the probe *	according the probe *	according the probe *
Temperature operating range (humidity 0 to 100%RH, no condensation)	-30 to +80°C	-20 to +60°C	-20 to +60°C
Protection class	IP30	IP30	IP30
Recommended calibration interval	according the probe *	according the probe *	according the probe *
Electromagnetic compatibility according to	EN 61326-1	EN 61326-1	EN 61326-1
Mounting position	any position **	any position **	any position **
Weight	140 g	145 g	145 g (LD-81 — 60 g)
Dimensions [mm]			
			

## Binary inputs


- 3 binary inputs without galvanic isolation
- the type of input (*Dry contact* / *Voltage input*) is selectable at device setup

#### Dry contact



Terminal voltage with open contact	3.3 V
Current through closed contact	< 0.1 mA
Resistance of the contact	< 5 kΩ

#### Napěťový vstup



Voltage level for „LOW”	< 1.0 V
Voltage level for „HIGH”	> 2.5 V
Internal resistance of the voltage source	< 2 kΩ
Input voltage range	0 to 30 V
Reverse polarity protection	yes

#### Flood detector LD-81 (P8653 only)



- LD-81 temperature operating range: -10 to +40°C
- detector cable length: 2.5 m \*

#### P8552, P8652 - input terminal



binary input: BIN1 BIN2 BIN3

#### P8653 - input terminal



binary input: BIN1 BIN2 BIN3

\* see the Specification of external probes

\*\* the device with attached DSRH/C or DST/C probe install always vertically with the sensor cover downwards


## External Probes

Probe type	DSTG8/C	DSTGL 40/C	DSTR1 62/C	DSRHxx+	DSRHIC	DST/C
Temperature measuring range	-50 to +100°C	-30 to +80°C		0 to +50°C	0 to +50°C	-30 to +80°C
Accuracy of temperature measurement	$\pm 0.5^{\circ}\text{C}$ (-10 to +85°C) $\pm 2.0^{\circ}\text{C}$ (-50 to -10°C) $\pm 2.0^{\circ}\text{C}$ (+85 to +100°C)	$\pm 0.5^{\circ}\text{C}$ (-10 to +80°C) $\pm 2.0^{\circ}\text{C}$ (below -10°C)		$\pm 0.5^{\circ}\text{C}$	$\pm 0.5^{\circ}\text{C}$	$\pm 0.5^{\circ}\text{C}$ (-10 to +80°C) $\pm 2.0^{\circ}\text{C}$ (below -10°C)
Relative humidity measuring range	—	—		10 to 90 %RH *	10 to 90 %RH *	
Accuracy of humidity measurement		—		$\pm 3.5$ %RH **	$\pm 3.5$ %RH **	—
Temperature operating range	-50 to +125°C	-30 to +80°C		-30 to +80°C	-30 to +80°C	-30 to +80°C
Humidity operating range (no condensation)	0 to 100 %RH	0 to 100 %RH		0 to 100 %RH	0 to 100 %RH	0 to 100 %RH
Protection class	IP67	IP67		IP40	IP20	IP20
Recommended calibration interval	2 years	2 years		1 year	1 year	2 years
Cable length	1, 2, 5, 10 m	1, 2, 5, 10 m		1, 2, 5 m	—	—
Mounting position	any position	any position		any position	sensor cover downwards	sensor cover downwards
Dimensions of the sensor [mm]	$\varnothing 5.7 \times 40$	$\varnothing 5.7 \times 40$	$\varnothing 10 \times 25$	$\varnothing 18 \times 90$	$\varnothing 14 \times 100$	$\varnothing 14 \times 100$

\* the relative humidity measuring range is limited at temperatures below 0°C and above 50°C, see manual for probe


\*\* from 10 to 90%RH at temperature 25°C

## Device Connection Procedure



Specifications are subject to change without notice.  
IE-SNC-N-P8x52-05

## Documents / Resources

	<p><a href="#">COMET P8552 Web Sensors [pdf] User Manual</a> P8552 Web Sensors, P8552, Web Sensors, Sensors</p>
---	---

## References

- [Manufacturer of Dataloggers, Thermometers, Hygrometers, CO2 meters](#)
- [Manufacturer of Dataloggers, Thermometers, Hygrometers, CO2 meters](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.