



# cookworks T316DE Brush Illuminating 2 Slices Toaster SS Instruction Manual

[Home](#) » [cookworks](#) » cookworks T316DE Brush Illuminating 2 Slices Toaster SS Instruction Manual 

## Contents

- 1 cookworks T316DE Brush Illuminating 2 Slices Toaster SS
- 2 ELECTRICAL SAFETY
  - 2.1 WARNING!
- 3 PARTS
- 4 TO USE
- 5 CLEANING
- 6 TECHNICAL SPECIFICATION
- 7 PLUG/WIRING ADVICE
- 8 PRODUCT GUARANTEE
- 9 Documents / Resources
  - 9.1 References
- 10 Related Posts

**cookworks**

**cookworks T316DE Brush Illuminating 2 Slices Toaster SS**




## ELECTRICAL SAFETY

- You should only plug the appliance into a 220V-240V AC, 50Hz supply. Connecting it to other power sources may damage the appliance and will invalidate the guarantee.
- Switch off and unplug when not in use and before cleaning the appliance.
- Keep the appliance and its cord out of reach of children less than 8 years.
- Do not allow children to use the appliance without supervision.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep cable and plug and appliance dry and away from areas where it is likely to get splashed. Never immerse in water.
- Do not pull on the cable to disconnect from the main supply.
- Do not force bread that is too thick or wide into the toaster carriage. If bread becomes stuck in the toaster, switch it off and unplug it before removing it. Be careful, do not damage the internal components and never use sharp objects such as forks or knives to dislodge the item.
- Do not operate the appliance if damaged or after it malfunctions. In the event the supply cord is damaged, in order to avoid a hazard, it must only be replaced by a qualified service engineer, with a suitably approved part.
- This appliance must be positioned so that the plug is accessible and the plug socket is within easy reach of the power cord.
- This appliance must be plugged into an earthed socket outlet.

## WARNING!

- This appliance is intended exclusively for use in domestic households. It is not suitable for commercial use.
- Do not leave it unattended during use. Bread can catch fire if overdone.
- Do not use toasters directly under cupboards as this may damage the toaster and/or the cupboard. Always ensure a clear gap of at least 60cm above the toaster.
- Do not cover and allow the toaster to cool fully before storing.
- Do not operate the toaster using a timer or separate remote control.
- The surfaces of the toaster may become hot; wear oven gloves when handling the appliance during and immediately after use.
- Bread may burn, do not use the toaster on, near or under flammable materials (e.g. curtains) or heat-sensitive surfaces.
- Do not use without the crumb tray correctly fitted and closed completely. Do not allow crumbs to build up in the tray, the crumb tray should be cleaned regularly.
- Do not place foil-wrapped food in this toaster and remove all wrappings from food before toasting.
- Not suitable to toast bread and other foodstuffs coated or containing butter, other spreads or containing sugar and jams.
- When toasting raisins or other fruit bread, remove any loose raisins from the surface of the bread before placing in the toaster. This will help prevent pieces from falling into the toaster or sticking on the guard wire in the slot.
- To prevent jamming do not use your toaster with torn slices of bread. Make sure the size and thickness of the bread slices fit easily into the toast slots.

## PARTS



1. Carriage control lever
2. Housing
3. Reheat the button

4. Defrost button
5. Cancel button
6. Browning control knob
7. Crumb tray

## **TO USE**

1. Place the toaster on a stable, flat, heat-resistant surface and away from any flammable materials.
2. Fully unwind the cable and plug in.
3. Select the degree of browning required by adjusting the browning control knob. A lighter-colored toast will be obtained by selecting the lower settings (1 & 2) and a darker toast by selecting the higher settings (5 & 6).
4. After selecting an appropriate setting, place a slice of bread into each carriage and lower the toast by pressing down on the carriage handle. The indicator in the CANCEL button will illuminate. If the carriage does not stay down, check that the toaster is switched on at the socket.
5. The toast will automatically pop up when the toasting time has been completed. When using for the first time or changing bread types initially set the browning control at 3 and it is advisable to check at intervals to see if the desired browning level has been reached.
6. If using frozen bread, insert the bread into the carriage, lower the carriage and press the DEFROST button. The indicator in the DEFROST button will illuminate and the toasting cycle will be extended slightly. The bread will automatically pop up when toasted.
7. To reheat cold toast, insert the bread into the carriage, lower the carriage and press the REHEAT button. The indicator in the REHEAT button will illuminate, and the reheating cycle will start. The bread will automatically pop up when the cycle has been completed.
8. Toasting can be stopped at any time by pressing the CANCEL button, or by unplugging the toaster.

### **Notes:**

- Before using for the first time it is advisable to let the toaster complete several toasting cycles at the highest setting with no bread in the carriage. Allow the toaster to cool down between cycles.
- If the toast starts to smoke, press the CANCEL button immediately.
- Dry thin slices of bread will be toasted quicker than moist or thick slices and should be toasted on a lower setting.
- For best results when toasting crust slices, insert the bread so the crust side is nearest the outside of the toaster, and the cut side is nearest the middle of the toaster.
- Turn the browning control knob to a lower setting if you are toasting a single slice.

## **CLEANING**

Clean and empty the crumb tray on a regular basis. If the toaster is used frequently then it is recommended this is done weekly.

1. Switch off and unplug the toaster and allow it to cool.
2. Wipe external surfaces with a soft damp cloth and polish with a soft dry cloth. Do not use detergent or abrasives as these may scratch the surface.

3. Slide out the crumb tray from underneath the toaster, wipe clean and replace.
4. If there are pieces of bread remaining inside the toaster, turn the toaster upside down and gently shake.
5. Never touch the internal surfaces and always allow surfaces to fully dry before using the toaster again.

## TECHNICAL SPECIFICATION

Cookworks Brush Illuminating 2 Slices Toaster SS	
Model	T316DE
Rated Voltage & Frequency	220 – 240V AC 50/60Hz
Rated Power Input	950 – 1150W
Capacity	2 Slices
Class rating	I (earthed)
BS 1362 fuse	10A
Product dimensions (external)	271 x 163 x 209mm
Product weight (net)	1.57kg approx.

## RECYCLING ELECTRICAL PRODUCTS

You should now recycle your waste electrical goods and in doing so help the environment. This symbol means an electrical product should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal when finished with. Visit [www.recycle-more.co.uk](http://www.recycle-more.co.uk), click on “bank locator” and enter your postcode to find your nearest recycling site.

## PLUG/WIRING ADVICE

The wires in this mains lead are colored in accordance with the following UK electrical code:

- BLUE = NEUTRAL
- BROWN = LIVE
- GREEN + YELLOW = EARTH


### Non-rewireable plug

This appliance may be fitted with a “non-rewireable” plug. If you need to change the fuse in a “non-rewireable” plug, the fuse cover must be refitted. If the fuse cover is lost or damaged, the appliance must not be used.

### Rewireable plug

The colors of the wires in the main lead of this appliance may not correspond with the colored markings identifying the terminals in a rewireable plug. Rewireable plugs should only be replaced by a suitably competent person. If in doubt, consult a qualified electrician.

The BLUE wire must be connected to the terminal marked with the letter N The BROWN wire must be connected to the terminal marked with the letter L The GREEN & YELLOW wire must be connected to the terminal marked with the letter E or the earth symbol.



Produced in China. Argos Limited, 489-499 Avebury Boulevard, Milton Keynes, MK9 2NW. Argos (N.I.) Ltd, Forestside Shopping Centre, Upper Galwally, Belfast, United Kingdom, BT8 6FX. Argos Distributors (Ireland) Limited, Unit 7, Ashbourne Retail Park, Ballybin Road, Ashbourne, County Meath, Ireland  
[www.argos.co.uk/cookworks](http://www.argos.co.uk/cookworks) Tel: 0345 640 3030.

## PRODUCT GUARANTEE

This product is guaranteed against manufacturing defects for a period of 1-year.


This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will either be replaced, refunded or repaired free of charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual. A replacement copy of this instruction manual can be obtained from [www.argos-support.co.uk](http://www.argos-support.co.uk).
- It must be used solely for domestic purposes.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for incidental or consequential damages.
- The guarantee is in addition to and does not diminish your statutory or legal rights.

Guarantor: Argos Ltd 489-499 Avebury Boulevard Central Milton Keynes MK9 2NN [www.argos-support.co.uk](http://www.argos-support.co.uk).

## Documents / Resources

 <p>Cookworks Brush Illuminating 2 Slices Toaster SS</p> <p>Care &amp; Instruction Manual For Reference and follow any Please Read These instructions before use and return for each reference</p> <p>Item 3 2016/2021</p>	<p><a href="#">cookworks T316DE Brush Illuminating 2 Slices Toaster SS</a> [pdf] Instruction Manual T316DE, Brush Illuminating 2 Slices Toaster SS, Illuminating 2 Slices Toaster SS, 2 Slices Toaster SS, T316DE, Toaster SS</p>
---	---

References

-  [Everything you need to know to Recycle More](#)