

**COPELAND**  
**8DO**  
**Digital**  
**Output**  
**Board**



# COPELAND 8DO Digital Output Board Installation Guide

[Home](#) » [Copeland](#) » COPELAND 8DO Digital Output Board Installation Guide 

## Contents

- 1 [COPELAND 8DO Digital Output Board](#)
- 2 [Product Specifications](#)
- 3 [Product Usage Instructions](#)
- 4 [FAQs](#)
- 5 [Documents / Resources](#)
  - 5.1 [References](#)
- 6 [Related Posts](#)

**COPELAND**

## COPELAND 8DO Digital Output Board




## Product Specifications

- Product Name: 8DO (Digital Output) Board
- Power Requirement: Connected to power transformer
- Network Connection: RS485 I/O Network
- Board Number Setting: Rotary dials S1 & S2
- Termination Jumper Setting: RS485 termination jumpers





## Product Usage Instructions

1. Connect the 8DO board to the power transformer.
2. Connect the 8DO board to the RS485 I/O Network.
3. Set the board number using rotary dials S1 & S2:
  - Use switch S1 for the tens portion of the board number.
  - Use switch S2 for the ones portion of the board number.
  - Example: To set the board as 8DO #1, set S1 to zero and S2 to one.
4. Set the RS485 termination jumpers:
  - If at either end of a daisy chain, set jumpers UP.
  - Otherwise, set jumpers DOWN.
5. **NOTE:** If you change any dip switch settings while the board is powered, disconnect the power and repower the board to reset.

- Connect board to power transformer.
- Connect 8DO to the RS485 I/O Network.
- Use the rotary dials S1 & S2 to set the board number. Use switch S1 to set the “tens” portion of the board number, and S2 as the “ones” portion of the board number. Example: to set the board as 8DO #1, set S1 to zero and S2 to one.
- Set RS485 termination jumpers UP if at either end of a daisy chain. Otherwise, set jumpers DOWN.



**NOTE:** If you change any dip switch settings while the board is powered, disconnect the power and repower the board to reset.



**NOTE:** This sheet is intended for use as a quick reference only. All installation technicians should read the installation and operation manuals for complete information.

- 026-2015 R1
- ©2024 Copeland LP.

## FAQs


**Q: Where can I find complete installation and operation manuals?**

A: Visit our website at [copeland.com/en-us/products/controls-monitoring-systems](https://copeland.com/en-us/products/controls-monitoring-systems) for complete information.

**Q: How can I get technical support?**

A: For Technical Support, call [833-409-7505](tel:833-409-7505) or email [ColdChain.TechnicalServices@Copeland.com](mailto:ColdChain.TechnicalServices@Copeland.com)

## Documents / Resources

	<p><a href="#">COPELAND 8DO Digital Output Board</a> [pdf] Installation Guide 8DO Digital Output Board, 8DO, Digital Output Board, Output Board, Board</p>
---	--

## References

- [User Manual](#)

### Manuals+ Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.