



COSMO COS-965AGFC 36 in. Professional Style Range User Manual

[Home](#) » [Cosmo](#) » COSMO COS-965AGFC 36 in. Professional Style Range User Manual 

Contents

- 1 COSMO COS-965AGFC 36 in. Professional Style Range**
- 2 RANGE SAFETY**
 - 2.1 Fire Hazard
 - 2.2 Tip Over Hazard
- 3 PARTS AND FEATURES**
- 4 BURNER PARTS**
- 5 CONTROL PANEL**
 - 5.1 36" MODELS
- 6 CLOCK AND TIMER**
- 7 SETTING THE CLOCK AND TIMER**
 - 7.1 Setting the Clock
 - 7.2 Setting the Timer
 - 7.3 Oven Timed Cooking
 - 7.4 Programming the End Cooking Time
- 8 COOKTOP USE**
 - 8.1 IGNITION AND OPERATION OF THE BURNERS
 - 8.2 POWER FAILURE
 - 8.3 COOKWARE
- 9 OVEN USE**
 - 9.1 CONTAINER TABLE
- 10 COOKING WITH THE GAS OVEN**
 - 10.1 BAKING AND ROASTING
 - 10.2 BROILING
 - 10.3 TEMPERATURE CONTROL
 - 10.4 BAKE
 - 10.5 BROIL
- 11 FEATURES CONTROL**
 - 11.1 Light
 - 11.2 OVEN TIPS AND TECHNIQUES
 - 11.3 BAKE CHART
 - 11.4 ROAST CHART
- 12 RANGE CARE**
 - 12.1 CLEANING
 - 12.2 EXTERIOR PORCELAIN ENAMEL SURFACES
 - 12.3 EXTERIOR STAINLESS STEEL
 - 12.4 OVEN DOOR EXTERIOR
 - 12.5 PORCELAIN-COATED GRATES AND CAPS
 - 12.6 BURNER SPREADER
 - 12.7 COOKTOP CONTROL KNOBS
 - 12.8 CONTROL PANEL
 - 12.9 OVEN CAVITY
 - 12.10 OVEN RACKS AND ROASTING RACKS
 - 12.11 BROILER PAN
- 13 TROUBLESHOOTING**
 - 13.1 BAKING AND ROASTING PROBLEMS
- 14 COOKTOP**
 - 14.1 TROUBLESHOOTING
 - 14.2 OVEN
- 15 WARRANTY AND SERVICE**
- 16 Documents / Resources**
 - 16.1 References
- 17 Related Posts**



COSMO COS-965AGFC 36 in. Professional Style Range



THANK YOU FOR YOUR PURCHASE

Thank you for your purchase. We know that you have many brands and products to choose from and we are honored to know that you have decided to take one of our products into your home and hope that you enjoy it. COSMO Appliances are designed according to the strictest safety and performance standard for the North American market. We follow the most advanced manufacturing philosophy. Each appliance leaves the factory after thorough quality inspection and testing. Our distributors and our service partners are ready to answer any questions you may have regarding how to install, use and care for your products. We hope that this manual will help you learn to use the product in the safest and most effective manner. Before using this product, please read through this manual carefully. Keep this user manual in a safe place for future reference. Please ensure that other persons using this product are familiar with these instructions as well. If you have any questions or concerns, please contact the dealer from whom you purchased it, or contact our Customer Support at: 1-888-784-3108.

RANGE SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages. This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others. All safety messages will follow the safety alert symbol and either the word "DANGER," "WARNING" or "CAUTION."

These words mean:

DANGER: An imminently hazardous situation. You could be killed or seriously injured if you don't immediately follow instructions.

WARNING: A potentially hazardous situation which, if not avoided, could result in death or serious bodily injury.

CAUTION: A potentially hazardous situation which, if not avoided, may result in moderate or minor injury.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

Fire Hazard

If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS**
 - Do not try to light any appliance.
 - Do not touch any electrical switch.
 - Do not use any phone in your building.
 - Clear the room, building, or area of all occupants.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.

State of California Proposition 65 Warnings:

WARNING: This product contains one or more chemicals known to the State of California to cause cancer.

WARNING: This product contains one or more chemicals known to the State of California to cause birth defects or other reproductive harm.

Tip Over Hazard

A child or adult can tip the range and be killed. Connect anti-tip bracket to rear range foot. Reconnect the anti-tip bracket, if the range is moved. See the installation instructions for details. Failure to follow these instructions can result in death or serious burns to children and adults.

Making sure the anti-tip bracket is installed:

- Slide range forward.
- Look for the anti-tip bracket securely attached to floor.
- Slide range back so rear range foot is under anti-tip bracket

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire or damage when using the range, follow basic precautions, including the following:

- **WARNING:** TO REDUCE THE RISK OF TIPPING OF THE RANGE, THE RANGE MUST BE SECURED BY PROPERLY INSTALLED ANTI-TIP DEVICES. TO CHECK IF THE DEVICES ARE INSTALLED PROPERLY, SLIDE RANGE COMPLETELY FORWARD, LOOK FOR ANTI-TIP BRACKET SECURELY ATTACHED TO THE FLOOR BEHIND THE RANGE AND SLIDE RANGE COMPLETELY BACK UNTIL THE REAR RANGE FOOT IS UNDER ANTI-TIP BRACKET.
- **CAUTION:** Do not store items of interest to children in cabinets above a range or on the back guard of a range
 - children climbing on the range to reach items could be seriously injured.
- Do Not Leave Children Alone

- Children should not be left alone or unattended in area where the range is in use. They should never be allowed to sit or stand on any part of the range.
- **Wear Proper Apparel**
 - Loose-should never be worn while using the range.
- **User Servicing**
 - Do not repair or replace any part of recommended in the manual. All other servicing should technician.
- **Storage in or on the Range**
 - Flammable materials should not be stored in an oven or near surface units.
- Do Not Use Water on Grease or use dry chemical or foam-type extinguisher.
- **Use Only Dry Potholders**
 - Moist or damp potholders on hot surfaces may result in burns from steam. Do not let potholder touch hot heating elements. Do not use a towel or other bulky cloth.
- **Warning:** NEVER use this appliance as a space heater to heat or warm the room. Doing so may result in carbon monoxide poisoning and overheating of the oven.
- **Warning:** NEVER cover any slots, holes or passages in the oven bottom or cover an entire rack with materials such as aluminum foil. Doing so blocks airflow through the oven and may cause carbon monoxide poisoning. Aluminum foil linings may also trap heat, causing a fire hazard.
- Never Leave Surface Units Unattended at High Heat Settings
 - Boil over causes smoking and greasy spillovers that may ignite.
- Glazed Cooking Utensils
 - Only certain types of glass, glass/ceramic, ceramic, earthenware, or other glazed utensils are suitable for range-top service without breaking due to the sudden change in temperature.
- Utensil Handles Should Be Turned Inward and Not Extend Over Adjacent Surface Units
 - To reduce the risk of burns, ignition of flammable materials, and spillage due to unintentional contact with the utensil, the handle of a utensil should be positioned so that it is turned inward, and does not extend over adjacent surface units.
- Use Care When Opening Door
 - Let hot air or steam escape before removing or replacing food.
- Do Not Heat Unopened Food Containers
 - Build-up of pressure may cause container to burst and result in injury.
- Keep Oven Vent Ducts Unobstructed.
- Placement of Oven Racks
 - Always place oven racks in desired location while oven is cool. If rack must be moved while oven is hot, do not let potholder contact hot heating element in oven.
- **DO NOT TOUCH HEATING ELEMENTS OR INTERIOR SURFACES OF OVEN**
 - Heating elements may be hot even though they are dark in color. Interior surfaces of an oven become hot enough to cause burns. During and after use, do not touch, or let clothing or other flammable materials contact heating elements or interior surfaces of oven until they have had sufficient time to cool. Other surfaces of the appliance may become hot enough to cause burns – among these surfaces are oven vent openings and surfaces near these openings, oven doors, and windows of oven doors.
- Proper Installation

- The range, when installed, must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code, ANSI/NFPA 70. In Canada, the range must be electrically grounded in accordance with Canadian Electrical Code. Be sure the range is properly installed
- Disconnect the electrical supply before servicing the appliance.
- Injuries may result from the misuse of appliance doors or drawers such as stepping, leaning, or sitting on the doors or drawers. Maintenance – Keep range area clear and free from combustible materials, vapors and liquids.
- top burner be adjusted so it does not extend beyond the edge of the cooking utensil.

For self-cleaning ranges

- Do Not Clean Door Gasket –The door gasket is essential for a good seal. Care should be taken not to rub, damage, or move the gasket.
- Do Not Use Oven Cleaners –No commercial oven cleaner or oven liner protective coating of any kind should be used in or around any part of the oven.
- Clean Only Parts Listed in Manual.
The broiler tray and utensils must be removed from the compartment and excessive spillage wiped off before initiating the cleaning cycle.


For units with ventilating hood

- Clean Ventilating Hoods Frequently – Grease should not be allowed to accumulate on food.
- When flashes coked under the vent hood, turn the fan on.

READ AND SAVE THESE INSTRUCTIONS

PARTS AND FEATURES


This manual covers several different models. The range you have purchased may have some or all of the items listed. The locations and appearances of the features shown here may not match those of your model.



- a Left Rear Surface Burner
- b Left Front Surface Burner c Oven Vent
- d Model and Serial Number Plate e Anti-tip Bracket
- f Grate
- g Right Rear Surface Burner
- h Right Front Surface Burner
- i Control Panel j Door Gasket k Broil Burner
- l Oven Light
- m Bottom Burner (not visible) n Oven Door Window

Note: Please contact Customer Support for replacement parts or call us directly at 1-888-784-3108.

BURNER PARTS




- a Control Knob Off Position

- b Burner Cap
- c Burner Head
- d Electrode
- e Flame Detector (On Some Models)

CONTROL PANEL

36" MODELS



ON FIRST USE: press the center function button to put the oven in manual mode before using.

CLOCK AND TIMER


Your model has a digital display with three Control buttons.

IMPORTANT: In the event of a power failure, all settings including the time display will be lost. When the power is returned, the bar above Timer Set and 12:00 will be displayed. In order to operate the oven again, press the center function button to put the oven in manual mode.

For instructions on how to use your range, scan QR Code:



SETTING THE CLOCK AND TIMER



Setting the Clock

1. When first connected to AC power or after a power outage, the display will blink "12:00" and the Clock indicator will blink. You can enter the Time Setting mode manually by pressing and releasing the Function button until the Clock indicator blinks.



2. To set the correct time, press the + or – button to advance forward or backward until the correct time is displayed. When finished, press the Function button, or wait five seconds; the time will be set.



IMPORTANT: Clock must be set in order for the oven functions to work.

Setting the Timer

1. Enter the Time Setting mode by pressing the Function button once; the Timer indicator will light.



2. Set the desired timer time using the + or – button to advance forward or backward until the desired time is displayed. The timer will count down and beep when it is finished.



Oven Timed Cooking

To start cooking time, set the TIMER to desired amount of time. This can be done before or during the middle of the oven heating.

1. Press and release the Function button until the Start indicator blinks.
2. Set the amount of time desired by pressing the + or -button until the desired timing is displayed, for a maximum of 10 hours.
3. Press the Function button again to set.

If the oven is not on yet, set the Temperature and Cooking knobs as desired (see pages 17 to 18 for descriptions and operation) and place the food in the oven.

4. When the set duration has been reached, the timer will beep and oven will stop heating.

Rotate the Temperature and Cooking knobs to their OFF positions, and then press the Function button to turn off the beeping.

Programming the End Cooking Time

To set end cooking time, set the TIMER to desired shut off time:

1. Press the Function button again until the End indicator blinks.



2. Set the end cooking time by pressing the + or – button until the desired end cooking time is displayed. Press the Function button again to set.
3. When the end time of cooking is reached, the timer will beep and the oven will stop heating



Rotate the Temperature and Cooking knobs to their OFF positions, and then press the Function button to turn off the beeping.


COOKTOP USE

Read the instructions before installing or using this appliance.

1. This appliance shall be installed in accordance with the regulations in force and only used in a well-ventilated space.
2. The use of a gas-cooking appliance results in the production of heat and moisture in the room in which it is installed. Ensure that the kitchen is well ventilated: keep natural ventilation clear or install a mechanical ventilation device (mechanical extractor hood).
3. Prolonged intensive use of the appliance may call for additional ventilation, for example opening of a window, or more effective ventilation, for example increasing the level of mechanical ventilation present.

IGNITION AND OPERATION OF THE BURNERS

In order to ignite a burner, push down on the knob while rotating it counterclockwise, until the knob indicator is aligned with the ignite icon.



For models with a safety valve – Once the flame is lit, hold the knob depressed for about 3-4 seconds until the device keeps the burner automatically lit. If the burner fails to ignite, wait one minute for the gas to dissipate before attempting to reignite. Adjust the flame intensity by rotating the knob counterclockwise from MAX (maximum) to MIN (minimum). To turn off the burner, rotate the knob clockwise until the indicator on the knob is with OFF.

POWER FAILURE

In case of prolonged power failure, the surface burners can be lit manually. Hold match near a burner and turn knob counterclockwise until the indicator is aligned MAX. After the burner is lit, turn knob to desired setting. The electric igniter must not be actuated for longer than 15 seconds. Should the burner light, or should the burner be unintentionally turned off, immediately close the burner, and wait at least 1 minute before repeating. Once ignited, adjust the flame as desired. For lower gas consumption and a better result, use saucepans with a diameter matching the diameter of the burner, to avoid flames coming up around the sides of the saucepan. See the Container Table. Use only flat-bottomed pans. As soon as liquid starts to boil, turn the flame down to a level sufficient to maintain boiling.

COOKWARE

MATCH PAN DIAMETER TO FLAME SIZE


The flame should be the same size as the bottom of the pan or smaller. Do not use small pans with high flame settings as the flames can lick up the sides of the pan. Oversized pans that span two burners are placed front to rear, not side to side.

USE BALANCED PANS

Pans must sit level on the cooktop grate without rocking. Center the pan over the burner.

USE A LID THAT FITS PROPERLY

A well-fitting lid helps shorten the cooking time. Flat, heavy bottom pans provide even heat and stability.



OVEN USE

CONTAINER TABLE

Burner	Min Saucepan	Max Saucepan
Auxiliary	3.5" (9.0 cm)	6.3" (16 cm)
Semi-rapid	5.1" (13 cm)	7.1" (18 cm)
Rapid	5.9" (15 cm)	10.2" (26 cm)
Triple ring	8.3" (21 cm)	10.2" (26 cm)

COOKING WITH THE GAS OVEN

BAKING AND ROASTING

This oven features a gas burner located under the oven cavity which provides evenly distributed heat from the bottom of the oven. The heat rises naturally to bake food evenly. The heated air circulates naturally, cooking meats to a flavorful, crisp outside while keeping the inside tender and juicy.

BROILING

This oven features a gas burner located at the top of the oven cavity which provides evenly distributed heat from the top of the oven.

The broil burner will remain on until the Oven Control knob is turned to the off position.

TEMPERATURE CONTROL

The Temperature knob is used to select either the Bake or Broil Oven Mode.

BAKE

- Push in on the Temperature knob, and then turn the knob counterclockwise to automatically ignite the bake burner. Continue turning the knob to select the desired cooking temperature, between MIN (150°F) and MAX.

BROIL

- Push in on the Temperature control knob, and then turn the knob clockwise to automatically ignite the broil burner.

NOTE: The broil burner will remain on until the Temperature control is returned to the OFF position.

For instructions on how to use your range, scan QR Code:



FEATURES CONTROL

Light

The oven cavity light turns ON when the Light or Conv. Fan knob function is selected.

Conv (Convection) Fan

During convection cooking, the fan provides heated air circulation throughout the oven. The movement of heated air around the food can help to speed up cooking by penetrating the cooler outer surfaces. Food cooks more evenly, browning and crisping outer surfaces while sealing moisture inside.

OVEN TIPS AND TECHNIQUES

Baking is cooking with heated air. The lower bake burner is on which heats the air in the oven cavity, baking the food with naturally circulating hot air currents. Follow the recipe or convenience food directions for baking temperature, time and rack position. Baking time will vary with the temperature of ingredients and the size, shape and finish of the baking utensil.

General Guidelines

- For best results, bake food on a single rack with at least 1" – 1 ½" (2.5 – 3 cm) space between utensils and oven walls.
- Use one rack when selecting the bake mode.

- Check for doneness at the minimum time.
- Use metal bake ware (with or without a non stick finish), heatproof glass, glass-ceramic, pottery or other utensils suitable for the oven.
- When using heatproof glass, reduce temperature by 25°F (15°C) from recommended temperature.
- Use baking sheets with or without sides or jelly roll pans.
- Dark metal pans or nonstick coatings will cook faster with more browning. Insulated bake ware will slightly lengthen the cooking time for most foods.
- Do not use aluminum foil or disposable aluminum trays to line any part of the oven. Foil is an excellent heat insulator and heat will be trapped beneath it. Thi
- Avoid using the opened door as a shelf to place pans.
- See Troubleshooting for tips to Solving Baking and Roasting Problems.

BAKE CHART

FOOD ITEM	RACK POSITION	TEMP. °F (°C) (PREHEATED OVEN)	TIME (MIN)
Cake Cupcakes Bundt Cake An gel Food	2 1 1	350 (175) 350 (175) 350 (175)	19-22 40-45 35-39
Pie crust, fresh, 9"	2	400 (205)	45-50
Cookies Sugar Chocolate Chip Brownies	2 2 2	350 (175) 350 (175) 350 (175)	8-10 8-13 29-36
Breads			
Yeast rolls Biscuits	2 2	400 (205) 400 (205)	12-15 7-9
Pizza Frozen Fresh	2 2	400-450 (205-235) 475 (246)	23-26 15-18

- See Troubleshooting for tips to Solving Baking and Roasting Problems.

ROAST CHART

Roast should typically be 20 minutes per pound at 350°F (175°C).

MEATS	WEIGHT (lb)	OVEN TEMP. °F (°C)	RACK POSI TION	TIME (min. per lb)	INTERNAL TEMP . °F (°C)
Beef					145 (63) medium rare 160 (71) medium 145 (63) medium rare 160 (71) medium 145 (63) medium rare 160 (71) medium 145 (63) medium rare
Rib Roast	4-6	350 (175)	2	16-20	
				18-22	
Rib Eye Roast, (boneless)	4-6	350 (175)	2	16-20	
				18-22	
Rump, Eye, Tip, Sirloin (boneless)	3-6	350 (175)	2	16-20	
				18-22	
Tenderloin Roast	2-3	400 (205)	2	15-20	

MEATS	WEIGHT (lb)	OVEN TEMP. °F (°C)	RACK POSI TION	TIME (min. per lb)	INTERNAL TEMP . °F (°C)
Pork					
Loin Roast (boneless or bone-in)	5-8	350 (175)	2	16-20	160 (71) medium
Shoulder	3-6	350 (175)	2	20-25	160 (71) medium
Poultry					

Chicken whole	3-4	400 (205)	2	18-21	180 (82)
	12-15	350 (175)	1	10-14	180 (82)
	16-20	350 (175)	1	9-11	180 (82)
	21-25	350 (175)	1	6-10	180 (82)
Turkey Breast	3-8	350 (175)	1	15-20	170 (77)
Cornish Hen	1-1 ½	350 (175)	2	45-75 total	180 (82)
Lamb					
Half Leg	3-4	350 (175)	2	22-27	160 (71) medium
				28-33	170 (77) well
Whole Leg	6-8	350 (175)	1	22-27	160 (71) medium
				28-33	170 (77) well

WARNING: NEVER cover any slots, holes or passages in the oven bottom or cover an entire rack with materials such as aluminum foil. Doing so blocks airflow through the oven and may cause carbon monoxide poisoning. Aluminum foil linings may also trap heat, causing a fire hazard.

Reset all controls to the OFF position after using a programmable timing operation.

No attempt should be made to operate the appliance during power failure.

An air curtain or other overhead range hood, which operates by blowing a downward airflow onto a range shall not be used in conjunction with a gas range.

RANGE CARE

CLEANING

IMPORTANT:

Before cleaning, make sure all controls are off and the oven and cooktop are cool. Always follow label instructions on cleaning products. Soap, water and a soft cloth or sponge are suggested first unless otherwise noted. Do not use abrasive cleaning products.

Warning: Do not obstruct the flow of combustion and ventilated air.

EXTERIOR PORCELAIN ENAMEL SURFACES

Food spills containing acids, such as vinegar and tomato, should be cleaned as soon as the entire appliance is cool. These spills may affect the finish.

Cleaning Method:

Glass cleaner, mild liquid cleaner or nonabrasive scrubbing pad: Gently clean around the model and serial number plate. Harsh scrubbing may remove numbers.

EXTERIOR STAINLESS STEEL

NOTE: Do not use soap-filled scouring pads, abrasive cleaners, Cooktop Polishing Cream, steel-wool pads, gritty washcloths or some paper towels. Damage may occur, even with one-time or limited use.

Rub in direction of grain to avoid damaging.

Cleaning Method:

Liquid detergent or all-purpose cleaner: Rinse well with clean water and dry with soft, lint-free cloth.

Stainless Steel Cleaner and Polish

Vinegar for hard water spots

OVEN DOOR EXTERIOR

Cleaning Method:

Glass cleaner and paper towels or nonabrasive plastic scrubbing pad: Apply glass cleaner to soft cloth or sponge, not directly on panel.

PORCELAIN-COATED GRATES AND CAPS

- Clean as soon as cooktop, grates and caps are cool.
- Food spills containing acids, such as vinegar and tomato, should be cleaned as soon as the cooktop grates and caps are cool. These spills may affect the finish.
- To avoid chipping, do not bang grates and caps against each other or hard surfaces such as cast iron cookware.
- Do not reassemble caps on burners while wet.

Cleaning Method:

Nonabrasive plastic scrubbing pad and mildly abrasive cleanser

BURNER SPREADER

Wash the burner spreader frequently with boiling water and detergent to remove any deposits which could block the flame outlet. Before reinstalling, dry the burner spreader thoroughly so the burner will ignite properly.

COOKTOP CONTROL KNOBS

- Pull knobs straight away from control panel to remove.

- When replacing knobs, make sure knobs are in the Off position.

Cleaning Method:

Soap and water or dishwasher:

NOTE: Do not use steel wool, abrasive cleansers or oven cleaner. Do not soak knobs.

CONTROL PANEL**Cleaning Method:**

Glass cleaner and soft cloth or sponge: Apply glass cleaner to soft cloth or sponge, not directly on panel.

NOTE: Do not use abrasive cleaners, steel-wool pads, gritty washcloths or some paper towels. Damage may occur.

OVEN CAVITY

Food spills should be cleaned when oven cools. At high temperatures, foods react with porcelain, so staining, etching, pitting or faint white spots can occur.

Cleaning Method:

Mild detergent and warm water.

NOTE: Do not use oven cleaners.

OVEN RACKS AND ROASTING RACKS**Cleaning Method:**

Steel-wool pad

BROILER PAN**Cleaning Method:**

Mildly abrasive cleanser: Scrub with wet scouring pad.

Solution of ½ cup (125 mL) ammonia to 1 gal. (3.75 L) water: Soak for 20 minutes, and then scrub with scouring or steel-wool pad.

Oven cleaner: Follow product label instructions. Porcelain enamel only, not chrome Dishwasher

TROUBLESHOOTING

First try the solutions suggested here to possibly avoid the need of a service call.

BAKING AND ROASTING PROBLEMS

With any oven setting poor results can occur for many reasons other than a malfunctioning oven. Check the chart below for causes of the most common problems. Since the size, shape and material of baking utensils directly affect the baking results, the best solution may be to replace old baking utensils that have darkened and warped with age and use.

Baking Problem	Cause
----------------	-------

Food browns unevenly	<ul style="list-style-type: none"> • Oven not preheated • Aluminum foil on oven rack or oven bottom • Baking utensil too large for recipe • Pans touching each other or oven walls
Food too brown on bottom	<ul style="list-style-type: none"> • Oven not preheated • Using glass, dull or darkened metal pans • Incorrect rack position • Pans touching each other or oven walls
Food is dry or has shrunk excessively	<ul style="list-style-type: none"> • Oven temperature too high • Baking time too long • Oven door opened frequently • Pan size too large
Food is baking or roasting too slowly	<ul style="list-style-type: none"> • Oven temperature too low • Oven not preheated • Oven door opened frequently • Tightly sealed with aluminum foil • Pan size too small
Pie crusts do not brown on bottom or crust is soggy	<ul style="list-style-type: none"> • Baking time not long enough • Using shiny steel pans • Incorrect rack position • Oven temperature is too low
Cakes pale, flat and may not be done inside	<ul style="list-style-type: none"> • Oven temperature too low • Incorrect baking time • Cake tested too soon • Oven door opened too often • Pan size may be too large

Cakes high in middle with crack on top	<ul style="list-style-type: none"> • Oven temperature too high • Baking time too long • Pans touching each other or oven walls • Incorrect rack position • Pan size too small
Pie crust edges too brown	<ul style="list-style-type: none"> • Oven temperature too high • Edges of crust too thin

COOKTOP

PROBLEM	POSSIBLE CAUSE	SOLUTION
Burner will not ignite	There is no power to the cooktop	Plug into a grounded 3 prong outlet. Replace fuse or reset circuit breaker.
Burner will not operate	First time use. Air still in the gas line.	Turn on any one of the surface burner knobs to release air from the gas lines.
	Control knob is not set correctly.	Push in knob before turning to a setting.
	The burner port is clogged.	Clean burner port opening using a stiff, nylon toothbrush or a straightened paper clip.
Burner Flames	Burner port(s) are clogged.	Clean burner port opening using a stiff, nylon toothbrush or a straightened paper clip.

are uneven, yellow and/ or noisy	Burner caps are not positioned properly.	Place burner caps so that the alignment pins are properly aligned with the slots.
	Propane gas is being used.	The range should be converted to LP gas by a qualified technician.
Burner flame is too high or too low	Cooktop gas supply is not correct.	Ensure the range is set for the correct gas type. It is factory set for natural gas. If connected to LP gas the burners should be converted to LP gas with the orifice/injector kit supplied and the pressure regulator converted to the LP gas setting by a qualified technician.
	The gas pressure is not correct.	Make sure the pressure regulator is installed correctly and the gas line pressure is correct. See Installation Instructions.
Burner makes popping noises	The burner is wet.	Allow the burner to dry before using.
	The burner cap and/ or gas spreader is not positioned correctly.	Place burner caps so that the alignment pins are properly aligned with the slots.
Excessive heat around cookware on cooktop	The cookware is not the proper size for the burner.	Use cookware with a bottom surface approximately the same size as the cooking area and burner. Cookware should not extend more than 1" (2.5 cm) outside the cooking area. Adjust the flame so that it does not come up around the cookware.

TROUBLESHOOTING

Cooking	Using incorrect	See the “Cookware” section.
results are	cookware	
not what expected		
	The control knob is not set to the proper	See the “Controls” section.
	heat level.	

OVEN

PROBLEM	POSSIBLE CAUSE	SOLUTION
Oven is not heating	No power to the oven	Reset the circuit breaker or replace the fuse in the electrical box to your oven.
	Oven control not turned on	Make sure the oven temperature has been selected.
Oven is not cooking evenly	Not using the correct bake ware or oven rack position	Refer to cook charts for recommended rack position. Always reduce recipe temperature by 25 °F (15 °C) when baking with Convention Bake mode.
Oven display stays Off.	Power interruption	Turn off power at the main power supply (fuse or breaker box). Turn breaker back on. If condition persists, call for service.
Cooling fan continues to run after oven is turned off	The electronic components have not yet cooled sufficiently	The fan will turn off automatically when the electronic components have cooled sufficiently.
Oven light is not working properly	Light bulb loose or burned-out.	Reinsert or replace the light bulb. Touching the bulb with fingers may cause the bulb to burn out.
Oven light stays on	Door is not closing completely	Check for obstruction in oven door. Check to see if hinge is bent or door switch broken.
Cannot remove lens cover	Soil build-up around the lens cover.	Wipe lens cover area with a clean, dry towel prior to attempting to remove the lens cover.
Clock and timer are not working properly	No power to the oven	Reset the circuit breaker or replace the fuse in the electrical box to your oven.
Excessive Moisture		When using bake mode, preheat the oven first. Convection Bake and Convection Roast will eliminate any moisture in the oven.
Porcelain Chips	Porcelain interior is bumped by oven racks	When removing and replacing oven racks, always tilt racks upward and do not force them to avoid chipping the porcelain.

WARRANTY AND SERVICE

For full warranty details on this product please visit: <http://www.cosmoappliances.com/warranty>
TO RECEIVE WARRANTY SERVICE, YOUR
PRODUCT MUST BE REGISTERED. TO REGISTER,
VISIT: WWW.COSMOAPPLIANCES.COM/WARRANTY
SCAN TO REGISTER




IMPORTANT

Do Not Return This Product To The Store If
you have a problem with this product, please contact
Cosmo Customer Support at
+1(888)784-3108

Correct Disposal of this product:

This marking indicates that this appliance should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

Documents / Resources

	<p>COSMO COS-965AGFC 36 in. Professional Style Range [pdf] User Manual COS-965AGC, COS-965AGFC, 36 in. Professional Style Range, COS-965AGFC 36 in. Professional Style Range, Professional Style Range, Style Range</p>
---	---

References

- [C Cosmo Appliances | Luxury Ranges, Cooktops, Range Hoods](#)
- [C Warranty | Cosmo Appliances](#)